


**20" Side Discharge Rotary Mower
Model: 0287B**

Use: Grass Catcher Model 30-0215 (160747)
Replacement Bag (501882)



20" Side Discharge Rotary Mower Model: 0287B

Use: Grass Catcher Model 30-0215 (160747)
Replacement Bag (501882)

Ref. No.	JCPenney Part No.	Supplier Part No.	Description	Ref. No.	JCPenney Part No.	Supplier Part No.	Description
1	1286-1670	715011	Hitch Pin	30	1324-5030	157255	Bolt-Blade
2	1244-0087	071076	Handle-Upper	31	1297-5793	457168	Bolt-Engine
3	1300-2548	715037	Nut-Hex 1/4-20 Keps	32	1302-0746	132423	Spring
4	1302-0839	780536	Control-Throttle	33	1297-6106	461665	Washer-Lock
5	1138-1118	463935	Deflector	34	1324-5022	157420	Bolt-Wheel
6	1244-0004	151936	Bolt-Handle	35	1283-1509	715417	Washer-3/8 Flat
7	1286-1555	150235	Nut-Wing	36	1287-2438	498618	Wheel Assembly
8	1286-1597	150201	Washer-Curved	37	1297-6973	153650	Bolt-Shoulder
9	1244-0079	071563	Yoke	38	1297-6999	776500	Spring-Q.W.A.
10	1244-0012	110379	Tie-Cable	39	1286-1480	435529	Cap-Q.W.A.
11	1302-0805	764290	Rivet	40	1286-1340	777862	Arm-Q.W.A.
12	1244-0020	106914	Clip-Trailguard	41	1155-1827	428664	Plate-Q.W.A. RH Front, LH Rear
13	1304-9671	111609	Trailguard	42	1297-6197	151613	Bolt-No. 10-32 x 1/2 Hex
14	1302-2678	150623	Screw-Casing	43	1324-5113	051466	Cable-Engine Control
15	1300-6747	150318	Clamp-Casing	44	1289-0430	428714	Plate-Q.W.A. LH Front, RH Rear
16	1138-1092	109629	Bracket	45	1302-0862	152371	Rope Guide
17	1244-0129	107094	Bracket-Yoke, L.H.	46	1302-2827	001461	Decal-Blade Warning
	1285-5565	107086	Bracket-Yoke, R.H.	47	1308-0981	152074	Stop-Rope
18	1155-1181	144063	Decal-"Danger"	48	1304-0530	464305	Baffle
19	1302-2793	109470	Handle-Bail	49	1302-1597	715052	Bolt-1/4-20 x 1/2 Hex
20	1297-6288	151761	Pin	50	1302-9608	120048	Screw
21	1129-0277	457499	Bolt-1/4-20 x 1/2	51	1304-0738	133488	Deflector-Muffler
22	1304-0720	151753	Nut-Acorn	52	1072-7469	458687	Bolt-10-24 x 1/2 Hex
23	1244-0046	028977	Housing-22"	53	1159-7283	452318	Nut-10-24 Hex Locking
24	1286-1548	451492	Nut-3/8-16 Locking	54	1302-1589	460923	Washer - 1/4 Dia.
25	1286-1506	150276	Key	55	1304-5422	715508	Nut Hex 1/4-20 Locking
26	1297-5801	126466	Adapter-Blade	56	1302-2835	156919	Lockwasher-3/8 HD Split
27	1302-2694	030296	Blade-22"	57	1302-2918	760413	Decal - Starting Instructions
28	1286-1654	106005	Spacer-Adapter	58	1324-5048	153874	Bolt - 1/4-20 x 2-1/4 Hex
29	1300-6549	715607	Washer-3/8 Belleville			199166	Owner's Handbook

**NOTE: PARTS ARE RIGHT OR LEFT HAND AS VIEWED FROM THE OPERATOR POSITION
SPECIFICATIONS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE**

• INDICATES OPTIONAL EQUIPMENT