


**Model 82 F**  
**21" Rear Bagging Rotary Mower**  
Grass Catcher Included




**Model 82 F**  
**21" Rear Bagging Rotary Mower**  
**Grass Catcher Included**

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>
1	013391	Deck 21"	38	150623	Screw-Hex Head Sheet Metal #10x5/8
2	030338	Blade 21" Offset	39	156133	Shoulder Bolt-Wheel Rear
3	041392	Wheel 8x1.75	40	151613	Bolt-Hex Head SEMS 10-32x3/8
4	051227	Control-Throttle w/Cable	41	151795	Wing Nut 5/16-18
5	051524	Cable-Engine/Blade Control*	42	151936	Bolt-Curved Head Crg 5/16-18x2 1/4
6	071159	Handle Upper	43	152074	Rope Stop
7	071449	Handle Lower	44	152405	Bolt-Carriage 3/8-16x3/4
8	090589	Back Plate-Height Adjuster	45	156182	Washer-Plastic-Height Adjuster
9	091033	Wheel Arm Assembly	46	152421	Washer-Spring-Height Adjuster
10	156919	Lockwasher-3/8 H.D.	47	157255	Bolt-Blade 3/8-24x1
11	109298	Bail-Engine/Blade Control*	48	152371	Eyebolt-Rope Guide
12	105825	Baffle-Front	49	152637	Spacer-Catcher Latch
13	106005	Blade Washer	50	715607	Washer-Belleville
14	109546	Catcher Frame Bracket	51	152686	Spacer-Rear Wheel
15	109496	Trailing Shield Mounting Strip*	52	156125	Shoulder Bolt-Height Adjuster
16	108324	Catcher Latch	53	310151	Locknut-5/16-18 Nylock
17	127191	Baffle Assembly	54	450346	Bolt-Hex 5/16-18x3/4
18	097162	Handle Bracket-Right Hand	55	452318	Nut- #10-24 Hex Nylon Insert
19	097170	Handle Bracket-Left Hand	56	457168	Bolt-3/8-16x7/8 Thread Forming
20	110064	Bolt Cap-Plastic	57	458687	Bolt-Hex Head #10-24x1/2
21	110379	Cable Tie	58	714170	Decal-Model Number
22	111540	Plastic Tip-Height Adjuster	59	715011	Hairpin Cotter
23	111625	Trailing Shield-Plastic*	60	715037	Locknut 1/4-20 Keps
24	111724	Knob-Catcher Latch	61	715078	Nut-1/4-20 Flange Whiz
25	715524	Nut-3/8-16 Lock	62	451492	Nut-3/8-16 Top Lock Flange
26	126839	Door Assembly*	63	715292	Bolt-Hex Head 1/4-20x1
27	126466	Blade Adapter	64	715300	Washer-1/4
28	133371	Torsion Spring-Catcher Latch	65	156877	Washer-3/8
29	143115	Decal-Danger*	66	715508	Locknut 1/4-20 Top
30	002451	Decal-Door Caution*	67	451419	Locknut 1/4-20 Flanged Top
31	001206	Decal-Blade Warning*	68	110833	Spark Plug Cover
32	144899	Decal-Starting Instructions	69	155234	Eyebolt-1/4-20x2 1/4
33	150011	Bolt-Carriage 1/4-20x5/8 Gr.5	70	156851	Bolt-1/4-20x3/8 Shaved Head
34	150730	Shoulder Bolt-Wheel Front	71	156869	Screw-#10-32x3/8
35	150201	Washer-Curved 5/16	72	152223	Nut-5/16-24 Jam
36	150276	Woodruff Key No. 6	73	450379	Bolt-1/4-20x1 3/4 Hex
37	150318	Cable Clamp			

NOTE: PARTS ARE RIGHT OR LEFT HAND AS VIEWED FROM THE OPERATOR POSITION.  
 APPROXIMATE CUTTING HEIGHTS 1 1/8" TO 3 1/8".  
 SPECIFICATIONS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.



## Grass Catcher Assy. Instructions 21" Rear Bagging Rotary Mowers



INDEX NO.	PART NO.	DESCRIPTION
1	102640	CATCHER HOOP
2	096578	CATCHER FRAME
3	151464	CONNECTOR
4	160655	CATCHER BAG

Index No.	Part No.	Description
1	096578	Frame-Catcher
2	097188	Handle-Catcher
3	102640	Hoop-Catcher
4	112532	Catcher- Top
5	160895	Catcher-Bottom
6	151464	Connector
7	135491	Latch
8	452318	Nut #10-24 Nylock
9	459370	Screw #10-24x1 1/2 Round Hd.
10	715136	Washer #10 Flat

**⚠ DANGER** Do not attempt to attach or remove grass catcher while engine/blade is turning.

**⚠ WARNING** Do not operate the mower unless the entire grass catcher is in place.

**⚠ WARNING** Under normal usage grass catcher bag material is subject to deterioration and wear and should be checked frequently. Be sure that any replacement bag complies with manufacturer's specifications.