



MODEL A2011K-A2211K-A2031K-A2231K  
 AE2011AK-AE2211K  
 CA2011AK-CA2031AK-CA2231AK  
 EA2011AK-EA2231K

20"/22" SIDE DISCHARGE MOWER

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158



Mowers Without Height Adjusters

MODEL A2011K-A2211K-A2031K-A2231K  
 AE2011AK-AE2211K  
 CA2011AK-CA2031AK-CA2231AK  
 EA2011AK-EA2231K  
 20"/22" SIDE DISCHARGE MOWER  
 Grass Catcher Model: GC6AA P/N 161018  
 Repl. Bag: P/N 161158

Index No.	Part No.	Description	Index No.	Part No.	Description
1	019059	Deck 20"	23	157420	Wheel Bolt-Plastic Whl.-w/Hgt. Adj.
1	019760	Deck 22"		150060	Wheel Bolt-Steel Whl.-w/Hgt. Adj.
2	030031	Blade-20" Flat	24	150201	Washer-Curved 5/16
	030049	Blade-22" Flat	25	150235	Wingnut 5/16-18
3	Wheel Assembly*		26	150276	Woodruff Key #6
	041780	7" Plastic-White-Rib	27	150318	Cable Clamp
	041863	7" Steel-White-Rib	28	150623	Screw-Sheet Metal #10 x 5/8
	041848	8" Steel-White-Rib	29	156158	Wheel Bolt-Plastic Whl.-w/o Hgt. Adj.
	041772	8" Plastic-White-Rib		150730	Wheel Bolt-Steel Whl.-w/o Hgt. Adj.
4	051219	Control-Throttle w/Cable	30	162024	Bolt-Blade
5	052142	Cable-Engine Blade Control	31	001461	Decal-Blade Warning
6	071563	Handle-Lower	32	151928	Bolt-Curved Head 5/16-18 x 1 3/4
7	071076	Handle-Upper	33	152074	Rope Stop
	071084	Handle-Upper Vinyl Grip	34	152371	Rope Guide
	072181	Handle-Upper Cushion Grip	35	153650	Shoulder Bolt-Hgt. Adj.*
8	101519	Baffle 20/22"	36	428664	Back Plate-Height Adjuster R.H. Front L.H. Rear*
9	104687	Bail-Engine/Blade Control	37	428714	Back Plate-Height Adjuster L.H. Front R.H. Rear*
	109470	Bail-Engine/Blade Control Vinyl Grip	38	452318	Nut-#10-24 HX Nylon Insert
10	106336	Washer-Blade Adapter	39	457168	Bolt-3/8-16 x 7/8 Thread Forming
11	106914	Clip-Trailing Shield	40	457499	Bolt-1/4-20 x 1/2 Thread Forming
12	088369	Handle Bracket-Right Hand	41	462093	Washer-Flat 1/4"
13	088377	Handle Bracket-Left Hand	42	458687	Bolt-Hex Head #10-24 x 1/2
14	394619	Chute Deflector Assembly	43	777862	Wheel Lever-Height Adjuster*
15	110379	Cable Tie	44	715011	Hairpin Cotter
16	111405	Trailing Shield-20/22" w/o Hgt. Adj.	45	715037	Nut-Keps 1/4-20
	111421	Trailing Shield-20/22" w/Hgt. Adj.	46	715045	Bolt-Hex Head 1/4-20 x 3/4*
17	114462	Plastic Tip-Setting Lever*	47	156406	Locknut 3/8-16 Flange Lock*
18	133231	Blade Adapter	48	715201	Bolt-Hex 3/8-16 x 3/4 w/o Hgt. Adj.
19	144063	Decal-Danger	49	715607	Washer-Belleville*
20	009415	Decal-Blade Warning (Rectangle)	50	715417	Washer 3/8 SAE*
21	715557	Decal-Starting Instructions	51	715508	Locknut 1/4-20 Top
22	153874	Bolt-1/4-20 x 2 1/4 Hex	52	776500	Setting Lever-Height Adjuster*

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with
- Parts are right or left hand as viewed from the operator's position
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice