


Model: A3222L
A3222ESL
 22" Single Stage
 3 HP 2 Cycle Snowthrower



P/L 689893
 S/N 601476
 601450

603191
 602904

Model: A3222L
A3222ESL
22" Single Stage 3 HP 2 Cycle Snowthrower

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	712620	Auger Assembly NOTE Individual parts for this assembly are available to authorized service centers.	70	677690	Decal - Deflector
2	772749	Bracket - Control Panel Support	71	762302	Shield - Heat Engine
3	452383	Nut - Tinnerman	72	447995	Tab - Cover L.H.
4	715490	Nut - 5/16-18 Top Lock	73	762443	Shield - Blower Engine Plastic
5	423756	Bearing - Auger	74	764225	Pop Rivet 3/16 x 3/8
6	153601	Bolt - 1/4-20 x 3/4 Thread Forming	75	662221	Axle
7	715508	Nut - 1/4-20 Top Lock	76	150771	Washer - 7/8 x 13/32
8	159574	Screw - 8-32 x 3/8 Hex Washer Hd	77	663807	Spring - Idler Arm
9	789883	Retaining Ring	78	679621	Decal - Control Panel
10	712588	Shaft Assembly - Auger	79	715524	Nut - 3/8-16 Center Lock Jam
11	672006	Housing - Collector/Auger	80	159020	Bolt - 3/8-16 x 1-1/2 Hex
12	041129	Wheel - 6" Plastic	81	663872	Idler Arm
13	657502	Handle - Upper	82	672923	Idler Pulley
14	657510	Handle - Lower	83	697334	Frame Assembly
15	107912	Bail - Control	84	419820	Pulley - Engine
16	713768	Grip - Engine Start	85	672469	Pulley - Auger
17	630186	Switch - Ignition	86	708768	Belt
18	310102	Nut - 5/8-32 Ign	87	663799	Cable Bracket
19	311241	Washer - 5/8 Lock Ign	88	673467	Gas Tank
20	153734	Washer - Back-Up	89	432625	Filter - Fuel
21	715136	Washer - #10 Flat	90	645705	Primer - Fuel
22	772616	Bracket - Cable Mounting	91	763383	Clevis - U-Joint
23	780437	Control - Choke	92	457192	Screw - 10-32 x 1/2 Thread Forming
24	645721	Cable - Clutch Control	93	772566	Detent - Chute Adjustment
25	697607	Panel - Back	94	152579	Nut - 5/16 Push
26	697151	Cover - Engine	95	459339	Eyebolt
27	697482	Cover Assembly - Belt	96	715185	Washer - 5/16 Flat
28	423749	Bushing - Starter Rope	97	489088	Pin - Roll 5/32 x 3/4
29	150276	Key - Woodruff	98	489260	Pin - Roll 5/32 x 7/8
30	156935	Bolt - Shoulder 3/8-16 x 1	99	672915	Knob
31	303859	Clamp - Hose 1/2	100	751172	Connector - U-Joint
32	447888	Clamp - Choke	101	775676	Spring - Detent
33	450353	Bolt - 1/4-20 x 1-1/4 Hex	102	664854	Crank - Chute Deflector
34	450429	Bolt - 5/16-18 x 5/8	103	418053	Shaft - Sprocket
35	151936	Bolt - 5/16-18 x 2-1/4 Curved	104	707844	Sprocket - Drive
36	159608	Set Screw 5/16	105	312256	Bolt - 5/16-18 x 1-3/4 Carriage
37	110379	Tie - Cable	106	790725	Retainer - Bearing
38	662197	Washer - Back Up	107	152975	Washer - 5/16 Ext Tooth Lock
39	113589	Knob 5/16	108	672873	Deflector - Chute
40	452375	Nut - Tinnerman	109	672345	Cap - Hub
41	816082	Nut - 3/8-24 Palnut	110	764217	Pop Rivet - 1/8
42	452318	Nut - 10-24 Hex Nylok	111	154534	Pop Rivet - 3/16
43	715052	Bolt - 1 4-20 x 1/2 Hex	112	764241	Eyelet
44	150623	No. 10 x 5/8 Special Screw	113	673541	Chute Gear/Ring (black)
45	712976	Chute Assembly	114	310151	Nut - 5/16 Lock
46	462309	Washer - 3/8	115	672865	Chute
47	459347	Screw - 10-9 x 5/8 Hex Washer Head	116	672550	Bar - Scraper
48	459354	Screw - 10-9 x 5/8 Flat Head	117	673202	Cap - Fuel
49	459446	Screw - 10-24 x 1-1/2 Hex	118	677948	Decal - OPEI B71.3-1984
50	155218	Screw - 10-24 x 1/2 Hex	119	459784	Screw - 8-32 x 1/2
51	459487	Screw - Engine Choke	120	133488	Deflector - Muffler
52	679324	Decal - Chute Control	121	677906	Decal - Starting Instructions
53	460584	Washer - 1/4	122	715037	Nut - 1/4-20 Keps
54	152553	Washer - Hardened 1/2	123	468652	Spacer - 5/8-.385 x .187
55	154211	Washer - Spring 1/2	124	458539	Screw - # 10-24 x 3/8 Thread Forming
56	461004	Washer - 1/4 Curved	125	468660	Spacer - 1/2 x .065 x 1"
57	150201	Washer - 5/16 Curved	126	760512	Decal - Auger Control
58	153510	Washer - 5/16 Internal Lock	127	677914	Card-First Time Starting
59	463984	Baffle - Auger Housing	128	678003	Decal - 2 Cycle Certified Oil
60	672840	Fuel Line - Short 2"	129	672329	Hose - 10" Primer
61	672832	Fuel Line - Long 11.5"	130	154161	Clamp - Hose 1/8
62	645713	Nut - Primer	131	672311	'Y' Nipple
63	712018	U-joint Assembly	132	677682	Decal - Auger Housing
64	489955	Pin - Roll 5/21 x 5/8	133	687319	Tag - Break-in Oil
65	715029	Cotter Pin	134	714212	Decal - Rating Plate
66	304352	Keys - Switch	135	423327	Bushing - Heyco
67	697359	Bracket - Engine Support	136	408922	Starter - Electric ES116 Optional
68	630251	Wire - Magneto Ground	137	645903	Tab - Cover R.H.
69	462051	Washer - .129 ID	138	713776	Cap - Handle
			139	310045	Nut - 5/16-18

WHEN ORDERING PARTS, USE PART NUMBER, NOT REFERENCE NUMBER

INSTRUCTIONS FOR ORDERING PARTS... SNOW THROWER PARTS can be ordered from the dealer from whom your snow thrower was purchased or from an authorized parts distributor or service station. Be sure to specify the part number, not reference number, and the description of each required item - also, the model and serial number of your snow thrower. If, for any reason you are unable to obtain the desired part from the dealer or service station - direct your order to our factory. Prices of parts may be obtained from dealer or factory. Send check or money order with order for parts, or request C O D shipment. To the price of the part add \$4.00 for postage and/or handling. All prices are quoted f.o.b. at Harvard, Illinois. Items that are too large or bulky to be mailed will be shipped freight or express with transportation charges collect. Refer to parts list (exploded view of snow thrower).

P/L 689893
S/N 601476 603191
601450 602904