



22" SIDE DISCHARGE ROTARY MOWER

MODEL: HA5Q22-J

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158



22" SIDE DISCHARGE ROTARY MOWER
MODEL: HA5Q22-J
 Grass Catcher Model: GC6AA P/N 161018
 Repl. Bag: P/N 161158

Index No.	Part No.	Description	Index No.	Part No.	Description
1	019059	Deck 20"	23	150060	Wheel Bolt - Steel Whl. - w/Hght. Adj.
	021931	Deck 22"		157420	Wheel Bolt - use with 041780 Wheel
2	030031	Blade-20" Flat		150730	Wheel Bolt - Steel Whl. w/o Hght. Adj.
	030049	Blade-22" Flat	24	150201	Washer-Curved 5/16
3		Wheel Assembly*	25	150235	Wingnut 5/16-18
	041525	7" Plastic - White - Diamond Nylon Bearing (3-spoke)	26	150276	Woodruff Key #6
	041780	7" Plastic - White - Rib	27	157552	Cable Clamp
	041806	7" Steel-White-Rib-Flange Bearing	28	155366	Screw #10-24 x 5/8 HWH
	042432	8" Plastic-White-Diamond-Nylon Bearing (3-spoke)	29	157255	Bolt-Blade
	041848	8" Steel-White-Rib-Flange Bearing	30	381442	Clamp - Tinnerman
4	052217	Control-Throttle w/Cable	31	151928	Bolt-Curved Head 5/16-18 x 1-3/4
5	052209	Cable-Engine/Blade Control	32	152074	Rope Stop
6	071563	Handle-Lower	33	152371	Rope Guide
7	071084	Handle-Upper Coated	34	153650	Shoulder Bolt-Height Adjuster*
	071076	Handle-Upper	35	428664	Back Plate-Height Adjuster R.H. Front L.H. Rear*
8	101519	Baffle-Deck*	36	428714	Back Plate-Height Adjuster L.H. Front R.H. Rear*
9	104687	Bail-Engine/Blade Control	37	452318	Nut-#10-24 HX Nylon Insert
10	106005	Washer-Blade Adapter	38	457168	Bolt-3/8-16 x 7/8 Thread Forming
11	106914	Clip-Trailing Shield	39	457499	Bolt-1/4-20 x 1/2 Thread Forming
12	088369	Handle Bracket-Right Hand	40	462093	Washer-Flat 1/4
13	088377	Handle Bracket-Left Hand	41	458687	Bolt-Hex Head #10-24 x 1/2
14	394619	Chute Deflector Assembly	42	715417	Washer-3/8 Flat
15	110379	Cable Tie	43	715011	Hairpin Cotter
16	114421	Trailing Shield - 20/22" w/Hgt. Adj.	44	715037	Nut-Keps 1/4-20
	114405	Trailing Shield - 20/22" w/o Hgt. Adj.	45	715045	Bolt-Hex Head 1/4-20 x 3/4
17	114462	Plastic Tip-Setting Lever*	46	451492	Nut-3/8-16 Top Lock Flange
18	126466	Blade Adapter	47	715607	Washer-Belleville
19	144063	Decal-Danger	48	777862	Wheel Lever-Height Adj.*
20	001206	Decal-Blade Warning	49	715508	Locknut 1/4-20 Top
21	715557	Decal-Starting Instructions	50	776500	Setting Lever-Height Adjuster*
22	153874	Bolt - 1/4-20 x 2-1/4 Hex Head	51	156919	Washer-Lock

• INDICATES OPTIONAL EQUIPMENT

• INDICATES OPTIONAL EQUIPMENT

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.