


**MODEL RS5LCG**  
**5 HP Counter Rotating Rear Tine Tiller**



**MODEL RS5LCC**  
5 HP Counter Rotating Rear Tine Tiller


Index No.	Part No.	Description
1	*	Engine - 5 H.P.
2	151340	Nut - hex lock 5/16-18 flange
3	623439	Bolt - hex 5/16-18 x 2-1/2
4	156208	Set screw 5/16-18 x 1/4
5	154369	Bolt - hex shoulder 3/8-16 x 1-1/4
6	159285	Ring - retaining
7	157305	Set screw 1/4-20 x 1/4
8	150151	Bolt - hex 5/16-18 x 3/4
9	457176	Bolt - hex 3/8-16 x 1-1/4
10	311118	Washer - split lock 5/16
11	312058	Bolt - hex 5/16-18 x 1
12	468710	Spacer
13	460311	Bolt - hex 5/16-18 x 1-3/4
14	530436	Cable - engaging, tine drive
15	156273	Washer - flat #10
16	530394	Cable - engaging, ground drive
17	014670	Lever - shaft, on transmission
18	551713	Decal - Place Free Hand Here
19	555243	Keeper - belt, upper
20	555318	Bracket - angle
21	616144	Bolt - hex 1/4-28 x 1/2
22	098897	Lever - shift
23	555342	Roller - cable
24	555359	Guide - cable
25	616359	Knob - shift lever
26	098905	Rod - shift
27	098913	Connector - shift rod/lever
28	098863	Pulley - wheel drive transmission
29	317016	Pin - cotter
30	098871	Pulley - drive, on engine
31	014639	Plate - engine/weight mount
32	014696	Frame - chassis
33	571828	Guide - shift lever
34	575142	Bracket - shift rod
35	571786	Plate - front weight
36	572131	Support - cable
37	572156	Bracket - cable
38	014647	Cover - belts and pulleys
39	014654	Support - rear bearing
40	317040	Hairpin cotter
41	615534	Key - woodruff #9
42	557447	Collar - axle
43	615617	Bolt - hex 1/2-13 x 2-3/4
44	715185	Washer - flat 5/16
45	459776	Set screw 5/16-18 x 7/16
46	615831	Bolt - hex 5/16-18 x 1-1/4
47	616094	Bolt - hex 1/4-20 x 2-1/2

Index No.	Part No.	Description
48	616227	Hairpin cotter
49	616276	Key - square 3/16 x 1-3/8
50	616342	Nut - hex lock 5/16-18
51	715508	Nut - hex lock 1/4-20
52	616508	Washer - flat 5/16
53	616532	Pin - clevis
54	616581	Nut - hex ctr lock 1/2-13
55	616565	Seal - dust
56	584110	Seal - felt ring
57	616839	Key - square 3/16 x 1-7/8
58	616854	Washer - flat 3/8 special
59	616870	Pulley - drive, tiller tines
60	152553	Washer - flat 3/8
61	617514	Bolt - hex self tap 5/16-18 x 5/8
62	617795	Bearing - drive shaft
63	617811	Flange - bearing retainer
64	617878	Bushing - pilot, idler arm
65	617886	Bushing - idler arm
66	584086	Chain - drive 53 links
67	584128	Belt - wheel drive
68	171264**	Transmission - wheel drive (Tecumseh/Peerless Model 700-033)
69	622118	Wheel - drive, w/tire RH
70	622126	Wheel - drive, w/tire LH
71	099044	Axle - drive wheels w/sprocket
72	618975	Bearing - axle
73	014761	Flange - bearing retainer
74	620021	Sprocket - axle drive
75	622407	Belt - tine drive
76	622647	Spring - tine drive idler
77	623181	Shaft - drive, tiller tines
78	620807	Ring - retaining
79	623447	Spacer
80	624908	Nut - hex lock 3/8-16
81	158089	Screw - hex self tap 1/4-20 x 1/2
82	715078	Nut - hex 1/4-20 whiz flange
83	775817	Spring - idler
84	170530	Pulley - idler
85	571661	Arm - tine idler
86	156885	Stud - belt keeper
87	572149	Arm - drive idler
88	715300	Washer - flat 1/4
89	551846	Decal - CAUTION Disengage
90	715094	Washer - split lock 1/4
91	158956	Washer - flat 1/4
92	552836	Shield - dirt
93	557298	Keeper - belt, engine
94	155218	Screw - hex #10 - 16 x 1/2 SD
95	715490	Nut - hex top lock 5/16-18

\*Contact engine manufacturer's authorized service dealer for parts and warranty.

\*\*Contact Tecumseh/Peerless authorized service dealer or distributor for parts and warranty.

**MODEL RS5LCG**  
5 HP Counter Rotating Rear Tine Tiller




**MODEL RS5LCG**  
**5 HP Counter Rotating Rear Tine Tiller**

Index No.	Part No.	Description	Index No.	Part No.	Description
1	150250	Bolt - hex 5/16-18 x 1-1/2	36	615831	Bolt - hex 5/16-18 x 1-1/4
2	310003	Nut - hex 1/2-13	37	151340	Nut - hex lock 5/16-18 flange
3	615922	Bolt - hex 1/2-13 x 1-3/4	38	616177	Screw - hex #10-24 x 1/2
4	158089	Screw - hex self tap 1/4-20 x 1/2	39	616227	Hairpin Cotter
5	156075	Washer - flat 1/2	40	616243	Spring - clutch pin
6	616581	Nut - hex lock 1/2-13	41	616276	Key - square 3/16 x 1-3/8
7	457176	Bolt - hex 3/8-16 x 1-1/4	42	616342	Nut - hex lock 5/16-18
8	530436	Cable - engaging, tine drive	43	715508	Nut - hex lock 1/4-20
9	530394	Cable - engaging, ground drive	44	616532	Pin - clevis
10	617787	Spacer - latch	45	616615	Nut - hex lock #10-24
11	530444	Control - throttle w/cable	46	616870	Pulley - transmission drive
12	551648	Decal - CAUTION	47	617126	Hairpin Cotter
13	551655	Decal - WARNING	48	617514	Screw - tapping 5/16-18 x 5/8
14	551671	Decal - Grd Drive, Tine	49	619221	Grip - handle
15	555235	Keeper - belt, lower	50	620310	Pusher - depth bar
16	555433	Lever - clutch, ground drive	51	621235	Pin - clutch lever
17	555441	Lever - clutch, tine drive	52	621870	Transmission - tine drive
18	555165	Pull Bar - handle latch	53	622183	Hinge - dirt flap
19	575050	Tine Assembly	54	622662	Cover - clutch lever
20	571323	Bracket - transmission	55	623058	Spring - depth bar
21	571372	Support - dirt shield	56	620195	Knob - handle lock
22	571380	Tine Assembly	57	624908	Nut - hex lock 3/8-16
23	571414	Bracket - dirt shield	58	620203	Spring - pull bar
24	571984	Plate - side RH	59	312058	Bolt - hex 5/16-18 x 1
25	571992	Plate - side LH	60	621672	Tie - cable
26	575068	Tine Assembly	61	715078	Nut - hex lock 1/4-20 whiz
27	575076	Shield - dirt	62	621003	Clip - throttle cable
28	571679	Bar - skid	63	156208	Set screw 5/16-18 x 1/4
29	571687	Bar - depth	64	556225	Tine - 13" RH
30	571729	Tine Assembly	65	556233	Tine - 13" LH
31	014753	Handle	66	615633	Nut - hex 3/8-24
32	574236	Flap - dirt	67	615666	Washer - split lock 3/8
33	616854	Washer - flat 3/8	68	617720	Hub - tines w/cup
34	616508	Washer - flat 5/16	69	622290	Hub - tines
35	620187	Spacer - pull bar pin	70	624940	Bolt - hex 3/8-24 x 1 GR5

**MODEL RS5LCG**  
5 HP Counter Rotating Rear Tine Tiller

**TINE DRIVE TRANSMISSION**



**MODEL RS5LCG**  
**5 HP Counter Rotating Rear Tine Tiller**

**TINE DRIVE TRANSMISSION**

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>
1	311118	Lockwasher - 5/16 split	15	617084	Shaft - worm
2	615500	Plug - pipe	16	624262	Worm
3	616417	Washer - thrust	17	616979	Transmission housing w/bearings and seals
4	616425	Ring - retaining	18	423731	Bearing - needle
5	616433	Plug - "O" ring	19	616383	Seal - oil
6	616441	Ring - "O"	20	616391	Seal - double oil
7	616755	Gasket - gear cover	21	616524	Bearing - needle
8	617019	Bolt - 5/16-18 x 7/8 HX HD	22	617001	Cover assembly
9	623504	Collar - pin retainer	23	572289	Cover
10	616466	Pin - 3/8 x 2 drive-lok	24	617530	Cone - bearing
11	617845	Axle	25	617548	Cup - bearing
12	619536	Wheel - worm	26	617522	Sleeve - bearing
13	620898	Bearing assembly - worm	27	621870	Transmission assembly
14	155515	Pin - 1/4 x 1-1/8			

**NOTE:** Fill transmission with (not shown) P/N 432849 gear lube and replace P/N 615500 plug-pipe with P/N 616912 vented pipe-plug.