


MODEL WRB21K WRBS21K WRB210K
 21" REAR-BAGGING MOWER
 Grass Catcher Included - see p. 13



SEE GRASS
 CATCHER ASSEMBLY
 INSTRUCTIONS FOR
 CATCHER PARTS

MODEL WRB21K WRBS21K WRB210K
 21" REAR-BAGGING MOWER
 Grass Catcher Included - see p. 13

Index No.	Part No.	Description	Index No.	Part No.	Description
1	018630	Deck—21"	32	009415	Decal—Blade Warning
2	110833	Cover-Spark Plug	33	715557	Decal—Starting Instructions
3	030338	Blade—21"	34	150011	Bolt—Carriage 1/4-20 x 5/8 Gr. 5
4		Wheel Assemblies*	35	457168	Bolt—3/8-16 x 7/8 Thread Forming
	040741	8" Plastic-White-Cog-Nylon Bearing	36	382325	Shoulder Bolt—Wheel Front
	041111	8" Steel-White-Rib-Flange Bearing	37	150201	Washer—Curved 5/16
	042432	8" Plastic-White-Diamond-Nylon Bearing	38	150235	Wing Nut 5/16-18
	043018	8" Plastic-White-Diamond	39	150276	Woodruff Key #6
5	052472	Control—Throttle w/Cable	40	150318	Cable Clamp
6	052787	Cable—Engine/Blade Control	41	150623	Screw—Hex Head Sheet Metal #10 x 5/8
7	071076	Handle—Upper	42	382333	Shoulder Bolt—Wheel Rear
	071084	Handle Upper-Coated	43	157255	Bolt—Blade 3/8-24 x 1 Gr. 5
8	071449	Handle—Lower	44	452318	Locknut—10-24 Hex
9	091249	Back Plate—Height Adjuster	45	151928	Bolt—Curved Head Crg 5/16-18 x 1-3/4
10	085019	Wheel Arm Assy	46	152074	Rope Stop
11	715508	Locknut 1/4-20 Top	47	152405	Bolt—Carriage 3/8-16 x 3/4
12	104687	Bail—Engine/Blade Control	48	156182	Washer—Plastic—Height Adjuster
13	105825	Baffle—Front	49	152421	Washer—Spring—Height Adjuster
14	085100	Baffle Assembly-Rear	50	156125	Shoulder Bolt—Height Adjuster
15	106005	Blade Washer	51	152371	Rope Guide
16	156877	Washer-3/8 Hardened	52	152637	Spacer—Catcher Latch
17	109546	Catcher Frame Bracket	53	715607	Washer - 3/8 Belleville
18	108324	Catcher Latch	54	152686	Spacer—Rear Wheel
19	109496	Trailing Shield Mounting Strip	55	310151	Locknut—5/16-18 Nylok
20	097162	Handle Bracket—Right Hand	56	450346	Bolt-5/16-18 x 3/4
21	097170	Handle Bracket—Left Hand	57	458687	Bolt—Hex Head 10-24 x 1/2
22	153874	Bolt - 1/4 - 20 x 2 1/4 Hex Head	58	111856	Cap — Bolt
23	110379	Cable Tie	59	715011	Hitch Pin #3
24	111633	Trailing Shield—Plastic	60	715037	Locknut 1/4-20 Keps
25	110510	Plastic Tip—Height Adjuster	61	156406	Nut-3/8-16 Flange TopLock
26	111724	Knob—Catcher Latch	62	715292	Bolt—Hex Head 1/4-20 x 1
27	013706	Door Assembly	63	462093	Washer 1/4"
28	126466	Blade Adapter	64	156919	Lockwasher 3/8 HD Split
29	133371	Torsion Spring—Catcher Latch	65	715078	Nut-Flange Whiz 1/4-20
30	143115	Decal—Danger	66	715524	Nut-3/8-16 Lock
31	795039	Decal—Door Warning	67	156851	Bolt 1/4-20 x3/8 Shaved HD

• INDICATES OPTIONAL EQUIPMENT

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only Genuine Factory Replacement Parts (OEM) that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- Do not operate the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.