



120H00

Illustrated Parts List

Model Series

120H00

TYPE NUMBERS
0100 through 0114.

TABLE OF CONTENTS


Alternator	4
Air Cleaner	4
Blower Housing/Shrouds	5
Camshaft	2
Carburetor	3
Controls	4
Crankshaft	2
Cylinder	2
Electric Starter	5
Electrical	4
Engine Sump	2
Exhaust System	4
Flywheel	5
Flywheel Brake	4
Fuel Supply	3
Governor Spring	4
Ignition	4
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewinds	5
Rewind Starter	7
Valves	2

PRINTED IN U.S.A.








COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.


120H00







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
6678-2 Assemblies include all parts shown in frames. 09/29/2004



120H00



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
6678-4 Assemblies include all parts shown in frames. **09/29/2004**



120H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697322	Cylinder Assembly	25	790359	Piston Assembly (Standard) (Used After Code Date 04031400).	32	691664	Screw (Connecting Rod)
2	399269	Kit-Bushing/Seal (Magneto Side)				32A	695759	Screw (Connecting Rod)
3	★299819	Seal-Oil (Magneto Side)				33	262651	Valve-Exhaust
4	493279	Sump-Engine				34	262652	Valve-Intake
5	691160	Head-Cylinder				35	691270	Spring-Valve (Intake)
7	★Ø692249	Gasket-Cylinder Head				36	691270	Spring-Valve (Exhaust)
8	695250	Breather Assembly				37	694086	Guard-Flywheel
9	★Ø272481	Gasket-Breather				40	692194	Retainer-Valve
10	691125	Screw (Breather Assembly)				43	691997	Slinger-Governor/Oil
11	691781	Tube-Breather				45	690548	Tappet-Valve
12	★692232	Gasket-Crankcase				46	691449	Camshaft
13	690912	Screw (Cylinder Head)				50	497465	Manifold-Intake
15	691680	Plug-Oil Drain (Square Socket)				51	★272199	Gasket-Intake
16	691451	Crankshaft				54	691650	Screw (Intake Manifold)
		Note	26	790360	Ring Set (Standard) (Used After Code Date 04031400).	55	691421	Housing-Rewind Starter
		691452 Crankshaft Used on Type No(s). 0108, 0109, 0113.				58	697316	Rope-Starter (Cut To Required Length)
		691455 Crankshaft Used on Type No(s). 0112.				60	281434	Grip-Starter Rope
20	★399781	Seal-Oil (PTO Side)				65	690837	Screw (Rewind Starter)
22	691092	Screw (Crankcase Cover/Sump)				73	691222	Screen-Rotating
23	692315	Flywheel (Rewind Start)				78	691108	Screw (Flywheel Guard)
23A	691992	Flywheel (Electric Start)				81	691740	Lock-Muffler Screw
24	222698	Key-Flywheel				95	691636	Screw (Throttle Valve)
			27	691866	Lock-Piston Pin	97	696565	Shaft-Throttle
			28	499423	Pin-Piston (Standard)	104	●691242	Pin-Float Hinge
			29	499424	Rod-Connecting (Standard)	117	494870	Jet-Main (Standard)
						118	497315	Jet-Main (High Altitude)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION				
121	498260	Kit-Carburetor Overhaul	269	691026	Wire-Control (Cut to Required Length)	425A	690670	Screw (Air Cleaner Cover)				
125	498170	Carburetor	270	691027	Nut (Control Wire Casing)	443A	692523	Screw (Air Cleaner Primer Base)				
127	●694468	Plug-Welch (3/8" Diameter)	271	691028	Lever-Control	445A	491588	Filter-Air Cleaner Cartridge				
130	696564	Valve-Throttle	276	◆271716	Washer-Sealing	455	695161	Cup-Flywheel				
133	398187	Float-Carburetor	287	690940	Screw (Dipstick Tube)	456	692299	Plate-Pawl Friction				
134	●398188	Kit-Needle/Seat	300	496106	Muffler (Super Lo Tone Tuned)	459	281505	Plate-Ratchet				
137	◆693981	Gasket-Float Bowl	304A	696307	Housing-Blower	474	691991	Alternator				
146	690979	Key-Timing			Note	505	691251	Nut (Governor Control Lever)				
159	691753	Bracket-Air Cleaner Primer			696419	Housing-Blower	510	494147	Drive-Starter			
163★◆	272653	Gasket-Air Cleaner				Used on Type No(s). 0108.	513	692358	Clutch-Drive			
187	691050	Line-Fuel (Cut to Required Length)				696420	Housing-Blower	523	495264	Dipstick		
187A	691371	Line-Fuel (Molded)					Used on Type No(s). 0113.	524	★692296	Seal-Dipstick Tube		
188	690877	Screw (Control Bracket)	305	691108	Screw (Blower Housing)	306	690450	Shield-Cylinder	525	495265	Tube-Dipstick	
190	690940	Screw (Fuel Tank)	307	690345	Screw (Cylinder Shield)	309	695550	Motor-Starter	529	691923	Grommet	
202	691829	Link-Mechanical Governor	310	692327	Bolt (Starter Motor)	332	690662	Nut (Flywheel)	544	690786	Armature-Starter	
209B	691291	Spring-Governor (Red)	333	802574	Armature-Magneto	334	691061	Screw (Magneto Armature)	545	492919	Washer Set (Starter Motor)	
		Note	337	802592	Plug-Spark	356	692390	Wire-Stop	562	92613	Bolt (Governor Control Lever)	
		691292	Spring-Governor (Black)	358	497316	Gasket Set-Engine	363	19069	Puller-Flywheel	563	691138	Screw (Debris Guard Screen)
			Used on Type No(s). 0108, 0113.	365	692524	Screw (Carburetor)	365	692524	Screw (Carburetor)	564	690664	Screw (Control Cover)
222	692031	Bracket-Control (Remote/Manual Friction)(Primer)	383	89838	Wrench-Spark Plug	383	89838	Wrench-Spark Plug	584	697734	Cover-Breather Passage	
227	690783	Lever-Governor Control	404	690272	Washer (Governor Crank)	404	690272	Washer (Governor Crank)	585	★691879	Gasket-Breather Passage	
265	690798	Clamp-Casing							592	690800	Nut (Rewind Starter)	
267	691044	Screw (Casing Clamp)							597	691696	Screw (Pawl Friction Plate)	
268	691025	Casing-Control Wire (Cut to Required Length)							601	95162	Clamp-Hose (Green)	
									604	691757	Cover-Control	
									608	497680	Starter-Rewind	

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

120H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
613	691340	Screw (Muffler)	801	690782	Cap-Drive	972B	693377	Tank-Fuel (Plastic)
615	690340	Retainer-Governor Shaft	802	695267	Cap-End	975	493640	Bowl-Float
616	698801	Crank-Governor	803	695266	Housing-Starter	976	694395	Primer-Carburetor
617★◆270344		Seal-O Ring (Intake Manifold)	842	★691031	Seal-O Ring (Dipstick Tube)	977	498261	Gasket Set-Carburetor
621	692310	Switch-Stop	843	691884	Sleeve-Lever (Speed Control)	997	696310	Shield-Debris
633◆691321		Seal-Choke/Throttle Shaft	847	692017	Dipstick/Tube Assembly	1005	691346	Fan-Flywheel
635	66538	Boot-Spark Plug	851	493880	Terminal-Spark Plug	1019	696438	Kit-Label
651	690345	Screw (Starter Gear Cover)	869	691155	Seat-Valve (Intake)	1036	790412	Label-Emission (Used After Code Date 04063000).
668	★493823	Spacer (Includes 2)	870	690380	Seat-Valve (Exhaust)			Note 695111 Label- Emission (Used Before Code Date 04070100).
670	692294	Spacer-Fuel Tank	871	262001	Bushing-Valve Guide (Exhaust)			790413 Label- Emission (Used On Engines With D1 Trim) (Used After Code Date 04063000).
676E	393760	Deflector-Muffler (Side Out)			Note 63709 Bushing-Valve Guide (Intake)			697378 Label- Emission (Used On Engines With D1 Trim) (Used Before Code Date 04070100).
677	690661	Screw (Muffler Deflector)	883	★∅691881	Gasket-Exhaust			
684	690345	Screw (Breather Passage Cover)	910	691094	Stud (Alternator)			
689	691855	Spring-Friction	922	691831	Spring-Brake			
697	691127	Screw (Drive Cap)			Note 692135 Spring-Brake Used on Type No(s). 0113.			
703	696309	Clip	923	691994	Brake			
718	690959	Pin-Locating			Note 695891 Brake Used on Type No(s). 0113.	1058	275177	Manual-Owner's
741	790345	Gear-Timing (Use Without Woodruff Key)	925	690595	Cover-Linkage	1059	692311	Kit-Screw/Washer
		Note 691830 Gear-Timing (Uses Woodruff Key)	937	691325	Spline-Starter	1095	498528	Gasket Set-Valve
742	93941	Retainer-E Ring	949	696306	Guard-Debris Screen	1119	691648	Screw (Alternator)
745	691648	Screw (Brake)	957	397974	Cap-Fuel Tank (Plastic)	1210	498144	Pulley/Spring Assembly (Pulley)
783	691918	Gear-Pinion (Starter Drive) (19 Teeth)	966A	496116	Base-Air Cleaner Primer	1211	498144	Pulley/Spring Assembly (Spring)
783A	691269	Gear-Pinion (12 Teeth)	967A	493537	Filter-Pre Cleaner	1229	696308	Extension-Blower Housing
784	692341	Cover-Starer Gear	968B	692298	Cover-Air Cleaner	1330	270962	Manual-Repair
785	692352	Gasket-Starer Cover	970	691681	Screw (Air Cleaner Primer Bracket)			
789B	696546	Harness-Wiring						

★ Included in Engine Gasket Set-Ref. No.358.

◆ Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.