



Illustrated Parts List

Model Series

121000

TYPE NUMBERS
0112.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets – Carburetor	4
Kits/Gaskets – Engine	2
Kits/Gaskets – Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6

PRINTED IN U.S.A.












COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.




1019 LABEL KIT

1058 OWNER'S MANUAL







1330 REPAIR MANUAL




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3247-2 Assemblies include all parts shown in frames. 12/12/2004






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3247-3 Assemblies include all parts shown in frames.





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3247-5 Assemblies include all parts shown in frames.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3247-6 Assemblies include all parts shown in frames. 12/12/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699510	Cylinder Assembly	27	691866	Lock-Piston Pin	109	690023	Shaft-Choke (Straight Handle)
2	399269	Kit-Bushing/Seal (Magneto Side)	28	499423	Pin-Piston	117	690048	Jet-Main (Standard)
3	★299819	Seal-Oil (Magneto Side)	29	690124	Rod-Connecting	118	498976	Jet-Main (High Altitude)
5	699486	Head-Cylinder	30	692562	Dipper-Connecting Rod	121	696998	Kit-Carburetor Overhaul
7	★∅698210	Gasket-Cylinder Head	32	691664	Screw (Connecting Rod)	122	★693749	Spacer-Carburetor
11	692600	Tube-Breather (Flat Panel Air Cleaner)	32A	695759	Screw (Connecting Rod)	125	698474	Carburetor
12	★699485	Gasket-Crankcase	33	499642	Valve-Exhaust	127	●691739	Plug-Welch
13	699482	Screw (Cylinder Head)	34	499641	Valve-Intake	130	691181	Valve-Throttle
15	691686	Plug-Oil Drain (Square Head)	35	691304	Spring-Valve (Intake)	133	398187	Float-Carburetor
15A	691682	Plug-Oil Drain (Flush)	36	691304	Spring-Valve (Exhaust)	134	●398188	Kit-Needle/Seat
16	699445	Crankshaft	37	699661	Guard-Flywheel	137	●693981	Gasket-Float Bowl
18	699804	Cover-Crankcase	40	692194	Retainer-Valve	146	690979	Key-Timing
20	★692550	Seal-Oil (PTO Side)	45	690977	Tappet-Valve	155	★698214	Plate-Cylinder Head
21	281658	Cap-Oil Fill	46	693404	Camshaft	161	699207	Base-Air Cleaner (Flat Panel Air Cleaner)
22	699478	Screw (Crankcase Cover/ Sump)	51	★●∅692555	Gasket-Intake (2 Required)	163	★●696024	Gasket-Air Cleaner (Flat Panel Air Cleaner)
23	699488	Flywheel	55	691422	Housing-Rewind Starter	186	692317	Connector-Hose
24	222698	Key-Flywheel	58	693389	Rope-Starter (Cut to Required Length)	187	691050	Line-Fuel (Cut to Required Length)
25	690021	Piston Assembly (Standard)	59	490653	Grip-Insert	187A	692601	Line-Fuel (Molded)
		Note	60	490652	Grip-Starter Rope (2 Piece)	188	699479	Screw (Control Bracket)
		694168 Piston Assembly (.020" Oversize)	78	699205	Screw (Flywheel Guard)	190	699220	Screw (Fuel Tank)
26	499631	Ring Set (Standard)	95	691636	Screw (Throttle Valve)	192	694543	Adjustor-Rocker Arm
		Note	97	690024	Shaft-Throttle	209	692571	Spring-Governor
		692786 Ring Set (.020" Oversize)	98	398185	Kit-Idle Speed (Carburetor)	209A	691278	Spring-Governor
			104	●691242	Pin-Float Hinge	219	693578	Gear-Governor
			108	692567	Valve-Choke			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

121000

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
220	691724	Washer (Governor Gear)	356A	692390	Wire-Stop	621	692310	Switch-Stop
222B	699591	Bracket-Control	358	699638	Gasket Set-Engine	632	693408	Spring/Link-Mechanical Governor
227	692573	Lever-Governor Control	363	19069	Puller-Flywheel	633	◆◆693867	Seal-Choke/Throttle Shaft
238	691300	Valve-Cap	365	699484	Screw (Carburetor)	633A	◆◆691321	Seal-Choke/Throttle Shaft
265	691024	Clamp-Casing	383	19374	Wrench-Spark Plug	635	692076	Boot-Spark Plug
267	699492	Screw (Casing Clamp)	415	693463	Plug	663	699206	Screw (Control Panel)
268	691025	Casing-Control Wire (72" Long) (Cut to Required Length)	425	699208	Screw (Air Cleaner Cover)	668	694257	Spacer
269	691026	Wire-Control (78" Long) (Cut to Required Length)	427	694255	Nut (Control Bracket)	689	691855	Spring-Friction
270	691027	Nut (Control Wire Casing)	445	491588	Filter-Air Cleaner Cartridge (Flat Panel)	692	690572	Spring-Detent
271	691028	Lever-Control	455	692591	Cup-Flywheel	718	690959	Pin-Locating
271B	695743	Lever-Control	456	692299	Plate-Pawl Friction	741	692565	Gear-Timing
276	◆271716	Washer-Sealing	459	281505	Pawl-Ratchet	742	692564	Retainer-E Ring
281	699639	Panel-Control	504	694254	Washer Set-Friction	746	692566	Gear-Idler
300	693593	Muffler	505	691251	Nut (Governor Control Lever)	773	694258	Retainer
304	699598	Housing-Blower	552	692346	Bushing-Governor Crank	830	694544	Stud-Rocker Arm
305	699480	Screw (Blower Housing)	562	691119	Bolt (Governor Control Lever)	832	693583	Guard-Muffler
306	693610	Shield-Cylinder	597	691696	Screw (Pawl Friction Plate)	836	699203	Screw (Muffler Guard)
307	699483	Screw (Cylinder Shield)	601	95162	Clamp-Hose	836A	699632	Screw (Muffler Guard)
332	699359	Nut (Flywheel)	608	693394	Starter-Rewind	851	493880	Terminal-Spark Plug
333	695711	Armature-Magneto	613	699209	Screw (Muffler)	868	★∅692044	Seal-Valve
334	699477	Screw (Magneto Armature)	615	692576	Retainer-Governor Shaft	883	★691893	Gasket-Exhaust
337	491055	Plug-Spark	616	692547	Crank-Governor	914	699481	Screw (Rocker Cover) (Bottom)
			619	699230	Screw (Cylinder Head Plate)	914A	692557	Screw (Rocker Cover) (Top)
						914B	697551	Screw (Rocker Cover) (Center)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3247-8

Assemblies include all parts shown in frames.

12/12/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
957	694261	Cap–Fuel Tank	1005	692592	Fan–Flywheel	1070	699201	Screw
958	698180	Valve–Fuel Shut Off	1019	694852	Kit–Label			(Flywheel Fan)
968	692584	Cover–Air Cleaner (Flat Panel Air Cleaner)	1022	★∅691890	Gasket–Rocker Cover	1095	698215	Gasket Set–Valve
			1023	499924	Cover–Rocker Arm	1210	498144	Pulley/Spring Assembly
971	690370	Screw (Air Cleaner Base)	1026	790287	Rod–Push			(Pulley)
972	694260	Tank–Fuel	1029	691230	Arm–Rocker	1211	498144	Pulley/Spring Assembly
975	493640	Bowl–Float	1034	691343	Guide–Push Rod			(Spring)
977	697001	Gasket Set–Carburetor	1036	790634	Label–Emission	1330	272147	Repair Manual
993	∅694088	Gasket–Cylinder Head Plate	1058	275092	Owner’s Manual			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3247–9

Assemblies include all parts shown in frames.

12/12/2004