

121A00

Illustrated Parts List

Model Series

121A00

TYPE NUMBERS
0101 through 0323.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Exhaust System	5
Flywheel	6
Fuel Supply	5
Governor Spring	5
Ignition	5
Kits/Gaskets – Carburetor	4
Kits/Gaskets – Engine	2
Kits/Gaskets – Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6

PRINTED IN U.S.A.





COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.

121A00



1019 LABEL KIT

1058 OWNER'S MANUAL







1330 REPAIR MANUAL





287






15A






24




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5711-2 Assemblies include all parts shown in frames. 10/20/2004








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5711-4 Assemblies include all parts shown in frames. 10/20/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5711-5 Assemblies include all parts shown in frames. 10/20/2004



1036 EMISSION LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
1	699505	Cylinder Assembly	25	499627	Piston Assembly (Standard)	78	699205	Screw (Flywheel Guard)	
2	399269	Kit-Bushing/Seal (Magneto Side)			————— Note —————	95	691636	Screw (Throttle Valve)	
3	★299819	Seal-Oil (Magneto Side)			692789		97	690024	Shaft-Throttle
5	699486	Head-Cylinder			Assembly (.020" Oversize)		98	398185	Kit-Idle Speed
7	★∅698210	Gasket-Cylinder Head	26	499631	Ring Set (Standard)	104	●691242	Pin-Float Hinge	
11A	693647	Tube-Breather (High Mount Air Cleaner)			————— Note —————	108	692567	Valve-Choke	
11B	790632	Tube-Breather (Ultra Low Air Cleaner)			692786		109A	693628	Shaft-Choke
12	★699485	Gasket-Crankcase	27	691866	Lock-Piston Pin	109C	790624	Shaft-Choke	
13	699482	Screw (Cylinder Head)	28	499423	Pin-Piston	117	698344	Jet-Main (Standard)	
15	691686	Plug-Oil Drain	29	690124	Rod-Connecting			Used on Type No(s). 0277.	
15A	691682	Plug-Oil Drain	30	692562	Dipper-Connecting Rod			————— Note —————	
16	699452	Crankshaft Used on Type No(s). 0277, 0323.	32	691664	Screw (Connecting Rod)			690048	Jet-Main (Standard)
		————— Note —————	32A	695759	Screw (Connecting Rod)			Used on Type No(s). 0101, 0323.	
		699443	33	499642	Valve-Exhaust	118	694176	Jet-Main (High Altitude)	
		Used on Type No(s). 0101.	34	499641	Valve-Intake			Used on Type No(s). 0277.	
17	692517	Bearing-Ball	35	691304	Spring-Valve (Intake)			————— Note —————	
18	699804	Cover-Crankcase Used on Type No(s). 0277, 0323.	36	691304	Spring-Valve (Exhaust)			498976	Jet-Main (High Altitude)
18A	699672	Cover-Crankcase Used on Type No(s). 0101.	37	699661	Guard-Flywheel			Used on Type No(s). 0101, 0323.	
20	★692550	Seal-Oil (PTO Side)	40	692194	Retainer-Valve	121	696998	Kit-Carburetor Overhaul	
21	281658	Cap-Oil Fill	45	690977	Valve-Tappet	122	◆◆693749	Spacer-Carburetor	
22	699478	Screw (Crankcase Cover)	46	696813	Camshaft	125	698475	Carburetor Used on Type No(s). 0277.	
23	699488	Flywheel	51	★◆◆∅692555	Gasket-Intake (2 Required)			————— Note —————	
24	222698	Key-Flywheel	55	691422	Housing-Rewind Starter			698474	Carburetor Used on Type No(s). 0101, 0323.
			58	693389	Rope-Starter				
			59	490653	Insert-Grip				
			60	490652	Grip-Starter Rope				
			65	699228	Screw (Rewind Starter)				

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

121A00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
127	◆691739	Plug–Welch	267	699492	Screw (Casing Clamp)	415	693463	Plug
130	691181	Valve–Throttle				425A	699492	Screw (Air Cleaner Cover)
133	398187	Float–Carburetor	268	691025	Casing–Control Wire (72" Long)	427	694255	Nut (Control Bracket)
134	398188	Kit–Needle/Seat				445	491588	Filter–Air Cleaner Cartridge
137	◆◆693981	Gasket–Float Bowl	269	691026	Wire–Control (78" Long)	445A	697029	Filter–Air Cleaner Cartridge
146	690979	Key–Timing				455	692591	Cup–Flywheel
155	698214	Plate–Cylinder Head	270	691027	Nut (Control Wire Casing)	456	692299	Plate–Pawl Friction
161A	790631	Base–Air Cleaner	271	691028	Lever–Control	459	281505	Pawl–Ratchet
163★◆◆696024		Gasket–Air Cleaner (Ultra Low Air Cleaner)	271A	694256	Lever–Control	467	691668	Knob–Air Cleaner
163A★◆◆696979		Gasket–Air Cleaner (High Mount Air Cleaner)	276	271716	Washer–Sealing	504	694254	Washer Set–Friction
186	692317	Hose–Connector	281	699639	Plate–Trim	505	691251	Nut (Governor Control Lever)
187	691050	Line–Fuel (Cut to Required Length)	287	699629	Screw (Dipstick Tube)	523	693618	Dipstick
187A	692601	Line–Fuel (Molded)	300	693593	Muffler	524	281370	Seal–Dipstick Tube
187B	693401	Line–Fuel (Molded)	304	699598	Housing–Blower	552	692346	Bushing–Governor Crank
188	699479	Screw (Control Bracket)	305	699480	Screw (Blower Housing)	562	691119	Bolt (Governor Control Lever)
190	699220	Screw (Fuel Tank)	306	693610	Shield–Cylinder	597	691696	Screw (Pawl Friction Plate)
192	694543	Adjustor–Rocker Arm	307	699483	Screw (Cylinder Shield)	601	95162	Clamp–Hose
209	692571	Spring–Governor	332	699359	Nut (Flywheel)	608	693394	Starter–Rewind
209A	691278	Spring–Governor	333	695711	Armature–Magneto	613	699209	Screw (Muffler)
209	692571	Spring–Governor	334	699477	Screw (Magneto Armature)	615	692576	Retainer–Governor Shaft
209A	691278	Spring–Governor	337	691043	Plug–Spark	616	692547	Crank–Governor
219	693578	Gear–Governor	356	693651	Wire–Stop	619	699230	Screw (Cylinder Head)
220	691724	Washer (Governor Gear)	356A	692390	Wire–Stop	621	692310	Switch–Stop
222	699589	Bracket–Control	358	699638	Gasket Set–Engine	632	693408	Spring/Link–Mechani- cal Governor
227	692573	Gear–Governor	363	19069	Puller–Flywheel			
238	691300	Cap–Valve	365	692568	Screw (Carburetor)			
265	691024	Clamp–Casing	383	19374	Wrench–Spark Plug			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711–8

Assemblies include all parts shown in frames.

10/20/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
633	●693867	Seal-Choke/Throttle Shaft	914	699481	Screw (Rocker Cover) (Bottom)	1022	691890	Gasket-Rocker Cover
633A	●691321	Seal-Choke/Throttle Shaft	914A	692557	Screw (Rocker Cover) (Top)	1023	499924	Cover-Rocker
635	692076	Boot-Spark Plug	914B	697551	Screw (Rocker Cover) (Center)	1026	790287	Rod-Push
663	699206	Screw (Control Panel)	951	790630	Lever-Choke	1029	691230	Arm-Rocker
668	694257	Spacer	957	694261	Cap-Fuel Tank	1034	691343	Guide-Push Rod
689	691855	Spring-Friction	958	698180	Valve-Fuel Shut Off	1036	790634	Label-Emission (Used After Code Date 04063000).
692	690572	Spring-Detent	961	698304	Screw (Air Cleaner Bracket)	————— Note —————		
717	693462	Bracket-Air Cleaner	967	493537	Filter-Pre Cleaner	699946	Label-Emission (Used Before Code Date 04070100 and After Code Date 03093000).	
718	690959	Pin-Locating	967A	273356	Filter-Pre Cleaner	697004	Label-Emission (Used Before Code Date 03100100).	
741	695087	Gear-Timing	968A	693460	Cover-Air Cleaner	1058	275092	Owner's Manual
742	692564	Ring-Retaining	968B	790633	Cover-Air Cleaner	1070	699201	Screw (Flywheel Fan)
746	692566	Gear-Idler	971	690370	Screw (Air Cleaner Base)	1095	698215	Gasket Set-Valve
773	694258	Retainer	971A	690349	Screw (Air Cleaner Base)	1210	498144	Pulley/Spring Assembly (Pulley)
830	694544	Stud-Rocker Arm	971B	699629	Screw (Air Cleaner Base)	1211	498144	Pulley/Spring Assembly (Spring)
832	693583	Guard-Muffler	972	694260	Tank-Fuel	1330	272147	Repair Manual
836	699203	Screw (Muffler Guard)	975	493640	Bowl-Float			
836A	699632	Screw (Muffler Guard)	977	697001	Gasket Set-Carburetor			
842	691031	Seal-O Ring (Dipstick Tube)	993	694088	Gasket-Cylinder Head Plate			
847	693617	Dipstick/Tube Assembly	1005	692592	Fan-Flywheel			
851	493880	Terminal-Spark Plug	1019	694852	Kit-Label			
868	692044	Seal-Valve						
875	697030	Base-Air Cleaner						
883	★691893	Gasket-Exhaust						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.