

127H00

Illustrated Parts List Model Series 127H00

TYPE NUMBERS
0110.

TABLE OF CONTENTS


Air Cleaner	4
Blower Housing/Shrouds	5
Camshaft	2
Carburetor	3
Controls	4
Crankshaft	2
Cylinder	2
Electrical	4
Engine Sump	2
Exhaust System	4
Flywheel	5
Fuel Supply	3
Governor Spring	4
Ignition	4
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewind Starter	5
Valves	2







PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.


127H00








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3241-2 Assemblies include all parts shown in frames. 09/29/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3241-3 Assemblies include all parts shown in frames. 09/29/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3241-4 Assemblies include all parts shown in frames. 09/29/2004



1036 EMISSION LABEL

127H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697322	Cylinder Assembly	32	691664	Screw (Connecting Rod)	133	398187	Float-Carburetor
2	399269	Kit-Bushing/Seal (Magneto Side)	32A	695759	Screw (Connecting Rod)	134	●398188	Kit-Needle/Seat
3	★299819	Seal-Oil (Magneto Side)	33	262651	Valve-Exhaust	137	◆693981	Gasket-Float Bowl
4	493279	Sump-Engine	34	262652	Valve-Intake	146	690979	Key-Timing
5	691160	Head-Cylinder	35	691270	Spring-Valve (Intake)	159	691753	Bracket-Air Cleaner Primer
7	★∅692249	Gasket-Cylinder Head	36	691270	Spring-Valve (Exhaust)	163	★◆272653	Gasket-Air Cleaner
8	695250	Breather Assembly	37	694086	Guard-Flywheel	187	691050	Line-Fuel (Cut to Required Length)
9	★∅696125	Gasket-Breather	40	692194	Retainer-Valve	188	693399	Screw (Control Bracket)
10	691125	Screw (Breather Assembly)	43	691997	Slinger-Governor/Oil	190	690940	Screw (Fuel Tank)
11	691781	Tube-Breather	45	690548	Tappet-Valve	202	691829	Link-Mechanical Governor
12	★692232	Gasket-Crankcase	46	691449	Camshaft	209B	691291	Spring-Governor
13	690912	Screw (Cylinder Head)	50	497465	Manifold-Intake	222	692031	Bracket-Control (Remote/Manual Friction)(Primer)
15	691680	Plug-Oil Drain (Square Socket)	51	★272199	Gasket-Intake	227	690783	Lever-Governor Control
16	691452	Crankshaft	54	691650	Screw (Intake Manifold)	265	690798	Clamp-Casing
20	★399781	Seal-Oil (PTO Side)	55	691421	Housing-Rewind Starter	267	691044	Screw (Casing Clamp)
22	691092	Screw (Crankcase Cover/ Sump)	58	697316	Rope-Starter (Cut To Required Length)	268	691072	Casing-Control Wire (Cut to Required Length)
23A	691992	Flywheel	60	281434	Grip-Starter Rope	269	691589	Wire-Control (Cut to Required Length)
24	222698	Key-Flywheel	65	690837	Screw (Rewind Starter)	270	691027	Nut (Control Wire Casing)
25	790359	Piston Assembly (Standard)	78	691108	Screw (Flywheel Guard)	271	691028	Lever-Control
		Note _____	81	691740	Lock-Muffler Screw	276	◆271716	Washer-Sealing (Main Jet)
		697341 Piston Assembly (.020" Oversize)	81	691740	Lock-Muffler Screw	287	690940	Screw (Dipstick Tube)
26	790360	Ring Set (Standard)	95	691636	Screw (Throttle Valve)	300	692038	Muffler (Super Lo Tone)
		Note _____	97	696565	Shaft-Throttle	304A	696307	Housing-Blower
		499427 Ring Set (.020" Oversize)	104	●691242	Pin-Float Hinge	305	691108	Screw (Blower Housing)
27	691866	Lock-Piston Pin	117	498978	Jet-Main (Standard)			
28	499423	Pin-Piston (Standard)	118	497466	Jet-Main (High Altitude)			
29	499424	Rod-Connecting (Standard)	121	498260	Kit-Carburetor Overhaul			
			125	498170	Carburetor (Primer System)			
			127	●694468	Plug-Welch			
			130	696564	Valve-Throttle			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3241-6

Assemblies include all parts shown in frames.

09/29/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
306	690450	Shield—Cylinder	592	690800	Nut (Rewind Starter)	870	690380	Seat—Valve (Exhaust)
307	690345	Screw (Cylinder Shield)	597	691696	Screw (Pawl Friction Plate)	871	262001	Bushing—Valve Guide (Exhaust)
332	690662	Nut (Flywheel)	601	95162	Clamp—Hose	———— Note ————		
333	802574	Armature—Magneto	604	691757	Cover—Control	63709		Bushing—Valve Guide (Intake)
334	691061	Screw (Magneto Armature)	608	497680	Starter—Rewind	883	★∅691881	Gasket—Exhaust
337	802592	Plug—Spark	613	691340	Screw (Muffler)	925	690595	Cover—Linkage
356	692390	Wire—Stop	615	690340	Retainer—Governor Shaft	949	696306	Guard—Debris Screen
358	497316	Gasket Set—Engine	616	698801	Crank—Governor	957	397974	Cap—Fuel Tank (Plastic)
363	19069	Flywheel Puller	617	★◆270344	Seal—O Ring (Intake Manifold)	966A	496116	Base—Air Cleaner Primer
365	692524	Screw (Carburetor)	621	692310	Switch—Stop	967A	493537	Filter—Pre Cleaner
383	89838	Wrench—Spark Plug	633	◆◆691321	Seal—Choke/Throttle Shaft (Throttle)	968B	692298	Cover—Air Cleaner
404	690272	Washer (Governor Crank)	635	66538	Boot—Spark Plug	970	691669	Screw (Air Cleaner Primer Bracket)
425A	690670	Screw (Air Cleaner Cover)	668	★493823	Spacer	972B	693377	Tank—Fuel (Plastic)
443A	692523	Screw (Air Cleaner Primer Base)	670	692294	Spacer—Fuel Tank	975	493640	Bowl—Float
445A	491588	Filter—Air Cleaner Cartridge	676E	393760	Deflector—Muffler	976	694395	Primer—Carburetor
455	695161	Cup—Flywheel	677	690661	Screw (Muffler Deflector)	977	498261	Gasket Set—Carburetor
456	692299	Plate—Pawl Friction	684	690345	Screw (Breather Passage Cover)	997	696310	Shield—Debris
459	281505	Plate—Ratchet	689	691855	Spring—Friction	1005	691346	Fan—Flywheel
505	691251	Nut (Governor Control Lever)	703	696309	Clip	1019	696438	Kit—Label
523	495264	Dipstick	718	690959	Pin—Locating	1036	790411	Label—Emission
524	★692296	Seal—Dipstick Tube	741	790345	Gear—Timing (Use Without Woodruff Key)	1058	275177	Manual—Owner's
525	495265	Tube—Dipstick	———— Note ————		1059	692311	Kit—Screw/Washer	
529	691923	Grommet	691830		1095	498528	Gasket Set—Valve	
562	92613	Bolt (Governor Control Lever)	691830		1210	498144	Pulley/Spring Assembly (Pulley)	
563	691138	Screw (Debris Guard Screen)	842	★691031	Seal—O Ring (Dipstick Tube)	1211	498144	Pulley/Spring Assembly (Spring)
564	690664	Screw (Control Cover)	847	692047	Dipstick/Tube Assembly	1229	696308	Extension—Blower Housing
584	697734	Cover—Breather Passage	851	493880	Terminal—Spark Plug	1330	270962	Manual—Repair
585	★691879	Gasket—Breather Passage	868	697338	Seal—Valve			
			869	691155	Seat—Valve (Intake)			

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

∅ Included in Valve Gasket Set—Ref. No.1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.