

**128H00**

# Illustrated Parts List

## Model Series

# 128H00

TYPE NUMBERS  
0281.

### TABLE OF CONTENTS


Air Cleaner .....	4
Blower Housing/Shrouds .....	5
Camshaft .....	2
Carburetor .....	3
Controls .....	4
Crankshaft .....	2
Cylinder .....	2
Electrical .....	4
Engine Sump .....	2
Exhaust System .....	4
Flywheel .....	5
Fuel Supply .....	3
Governor Spring .....	4
Ignition .....	4
Kits/Gaskets .....	2 & 3
Lubrication .....	2
Piston Group .....	2
Rewind Starter .....	5
Valves .....	2







PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.










# 128H00








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3242-2 Assemblies include all parts shown in frames. 09/30/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3242-3 Assemblies include all parts shown in frames. 09/30/2004





1036 EMISSION LABEL

# 128H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697322	Cylinder Assembly	32	691664	Screw (Connecting Rod)	133	398187	Float-Carburetor
2	399269	Kit-Bushing/Seal (Magneto Side)	32A	695759	Screw (Connecting Rod)	134	●398188	Kit-Needle/Seat
3	★299819	Seal-Oil (Magneto Side)	33	262651	Valve-Exhaust	137	◆693981	Gasket-Float Bowl
4	493279	Sump-Engine	34	262652	Valve-Intake	146	690979	Key-Timing
5	691160	Head-Cylinder	35	691270	Spring-Valve (Intake)	159	691753	Bracket-Air Cleaner Primer
7	★∅692249	Gasket-Cylinder Head	36	691270	Spring-Valve (Exhaust)	163	★◆272653	Gasket-Air Cleaner
8	695250	Breather Assembly	37	694086	Guard-Flywheel	187	691050	Line-Fuel (Cut to Required Length)
9	★∅696125	Gasket-Breather	40	692194	Retainer-Valve	188	693399	Screw (Control Bracket)
10	691125	Screw (Breather Assembly)	43	691997	Slinger-Governor/Oil	190	690940	Screw (Fuel Tank)
11	691781	Tube-Breather	45	690548	Tappet-Valve	202	691829	Link-Mechanical Governor
12	★692232	Gasket-Crankcase	46	691449	Camshaft	209B	691291	Spring-Governor
13	690912	Screw (Cylinder Head)	50	497465	Manifold-Intake	222	692031	Bracket-Control (Remote/Manual Friction)(Primer)
15	691680	Plug-Oil Drain (Square Socket)	51	★272199	Gasket-Intake	227	690783	Lever-Governor Control
16	691451	Crankshaft	54	691650	Screw (Intake Manifold)	265	690798	Clamp-Casing
20	★399781	Seal-Oil (PTO Side)	55	691421	Housing-Rewind Starter	267	691044	Screw (Casing Clamp)
22	691092	Screw (Crankcase Cover/ Sump)	58	697316	Rope-Starter (Cut To Required Length)	268	691072	Casing-Control Wire (Cut to Required Length)
23A	691992	Flywheel	60	281434	Grip-Starter Rope	269	691589	Wire-Control (Cut to Required Length)
24	222698	Key-Flywheel	65	690837	Screw (Rewind Starter)	270	691027	Nut (Control Wire Casing)
25	790359	Piston Assembly (Standard)	78	691108	Screw (Flywheel Guard)	271	691028	Lever-Control
		<b>Note</b> _____	81	691740	Lock-Muffler Screw	276	◆271716	Washer-Sealing (Main Jet)
		697341 Piston Assembly (.020" Oversize)	95	691636	Screw (Throttle Valve)	287	690940	Screw (Dipstick Tube)
26	790360	Ring Set (Standard)	97	696565	Shaft-Throttle	300A	494343	Muffler (Square Lo Tone)
		<b>Note</b> _____	104	●691242	Pin-Float Hinge	304A	696307	Housing-Blower
		499427 Ring Set (.020" Oversize)	117	498978	Jet-Main (Standard)	305	691108	Screw (Blower Housing)
27	691866	Lock-Piston Pin	118	497466	Jet-Main (High Altitude)			
28	499423	Pin-Piston (Standard)	121	498260	Kit-Carburetor Overhaul			
29	499424	Rod-Connecting (Standard)	125	498170	Carburetor (Primer System)			
			127	●694468	Plug-Welch			
			130	696564	Valve-Throttle			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
306	690450	Shield—Cylinder	585	★691879	Gasket—Breather Passage	870	690380	Seat—Valve (Exhaust)
307	690345	Screw (Cylinder Shield)	592	690800	Nut (Rewind Starter)	871	262001	Bushing—Valve Guide (Exhaust)
332	690662	Nut (Flywheel)	597	691696	Screw (Pawl Friction Plate)	————— <b>Note</b> —————		
333	802574	Armature—Magneto	601	95162	Clamp—Hose	63709		Bushing—Valve Guide (Intake)
334	691061	Screw (Magneto Armature)	604	691757	Cover—Control	883	★∅691881	Gasket—Exhaust
337	802592	Plug—Spark	608	497680	Starter—Rewind	925	690595	Cover—Linkage
356	692390	Wire—Stop	613A	691653	Screw (Muffler)	949	696306	Guard—Debris Screen
358	497316	Gasket Set—Engine	615	690340	Retainer—Governor Shaft	957	397974	Cap—Fuel Tank (Plastic)
363	19069	Flywheel Puller	616	698801	Crank—Governor	966A	496116	Base—Air Cleaner Primer
365	692524	Screw (Carburetor)	617	★◆270344	Seal—O Ring (Intake Manifold)	967A	493537	Filter—Pre Cleaner
383	89838	Wrench—Spark Plug	621	692310	Switch—Stop	968B	692298	Cover—Air Cleaner
404	690272	Washer (Governor Crank)	633	◆◆691321	Seal—Choke/Throttle Shaft (Throttle)	970	691669	Screw (Air Cleaner Primer Bracket)
425A	690670	Screw (Air Cleaner Cover)	635	66538	Boot—Spark Plug	972B	693377	Tank—Fuel (Plastic)
443A	692523	Screw (Air Cleaner Primer Base)	668	★493823	Spacer	975	493640	Bowl—Float
445A	491588	Filter—Air Cleaner Cartridge	670	692294	Spacer—Fuel Tank	976	694395	Primer—Carburetor
455	695161	Cup—Flywheel	684	690345	Screw (Breather Passage Cover)	977	498261	Gasket Set—Carburetor
456	692299	Plate—Pawl Friction	689	691855	Spring—Friction	997	696310	Shield—Debris
459	281505	Plate—Ratchet	703	696309	Clip	1005	691346	Fan—Flywheel
505	691251	Nut (Governor Control Lever)	718	690959	Pin—Locating	1019	696438	Kit—Label
523	495264	Dipstick	741	790345	Gear—Timing (Use Without Woodruff Key)	1036	790411	Label—Emission
524	★692296	Seal—Dipstick Tube	————— <b>Note</b> —————		1058	275177	Manual—Owner's	
525	495265	Tube—Dipstick	691830		1059	692311	Kit—Screw/Washer	
529	691923	Grommet	842	★691031	Gear—Timing (Uses Woodruff Key)	1095	498528	Gasket Set—Valve
562	92613	Bolt (Governor Control Lever)	847	692047	Seal—O Ring (Dipstick Tube)	1210	498144	Pulley/Spring Assembly (Pulley)
563	691138	Screw (Debris Guard Screen)	851	493880	Dipstick/Tube Assembly	1211	498144	Pulley/Spring Assembly (Spring)
564	690664	Screw (Control Cover)	868	697338	Terminal—Spark Plug	1229	696308	Extension—Blower Housing
584	697734	Cover—Breather Passage	869	691155	Seal—Valve (Intake)	1330	270962	Manual—Repair

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

∅ Included in Valve Gasket Set—Ref. No.1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**