



# Illustrated Parts List

## Model Series

# 12B600

TYPE NUMBERS  
0100 through 0104.

### TABLE OF CONTENTS


Air Cleaner .....	5
Blower Housing/Shrouds .....	6
Camshaft .....	2
Carburetor .....	4
Controls .....	5
Crankshaft .....	2
Cylinder .....	2
Cylinder Head .....	3
Engine Sump .....	2
Exhaust System .....	5
Flywheel .....	6
Fuel Supply .....	4
Governor Spring .....	5
Ignition .....	5
Lubrication .....	2
Piston Group .....	2
Rewind Starter .....	6

PRINTED IN U.S.A.






COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

# 12B600







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 6726-2 Assemblies include all parts shown in frames. 10/08/2004




**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**  
**6726-3** Assemblies include all parts shown in frames. **10/08/2004**

# 12B600




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 6726-4 Assemblies include all parts shown in frames. 10/08/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 6726-5 Assemblies include all parts shown in frames. 10/08/2004

# 12B600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
6726-6 Assemblies include all parts shown in frames. 10/08/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
1	692670	Cylinder Assembly	25	790359	Piston Assembly (Standard) (Used After Code Date 04040400).	36	691304	Spring-Valve (Exhaust)		
2	399269	Kit-Bushing/Seal (Magneto Side)			<b>Note</b> _____	37	694086	Guard-Flywheel		
3	★299819	Seal-Oil (Magneto Side)			690021 Piston Assembly (Standard) (Used Before Code Date 04040500).	40	692194	Retainer-Valve		
4	493279	Sump-Engine			694167 Piston Assembly (.010" Oversize)	43	691997	Slinger-Governor/Oil		
5	695276	Head-Cylinder			694168 Piston Assembly (.020" Oversize)	45	690977	Tappet-Valve		
7	★△695166	Gasket-Cylinder Head			694169 Piston Assembly (.030" Oversize)	46	694039	Camshaft		
8	495786	Breather Assembly	26	790360	Ring Set (Standard) (Used After Code Date 04040400).	51★◆△692799		Gasket-Intake		
9	★272481	Gasket-Breather			<b>Note</b> _____	55	691421	Housing-Rewind Starter		
10	691125	Screw (Breather Assembly)			499631 Ring Set (Standard) (Used Before Code Date 04040500).	58	697316	Rope-Starter (Cut To Required Length)		
11	499675	Tube-Breather			692785 Ring Set (.010" Oversize)	60	281434	Grip-Starter Rope		
12	★692232	Gasket-Crankcase			692786 Ring Set (.020" Oversize)	65	690837	Screw (Rewind Starter)		
13	691137	Screw (Cylinder Head)			692787 Ring Set (.030" Oversize)	78	691108	Screw (Flywheel Guard)		
15	691680	Plug-Oil Drain (Square Socket)				95	691636	Screw (Throttle Valve)		
16	691457	Crankshaft				97	499682	Shaft-Throttle (Metal)		
20	★399781	Seal-Oil (PTO Side)						<b>Note</b> _____		
22	691092	Screw (Crankcase Cover/Sump)						790121 Shaft-Throttle (Plastic)		
23	692693	Flywheel Used on Type No(s) 0100.				104	◆691242	Pin-Float Hinge		
23A	696569	Flywheel Used on Type No(s) 0104.				117	498981	Jet-Main (Standard) (Used After Code Date 03110600).		
24	222698	Key-Flywheel						<b>Note</b> _____		
			27	691866	Lock-Piston Pin			498978 Jet-Main (Standard) (Used Before Code Date 03110700).		
			28	499423	Pin-Piston			118	497466	Jet-Main (High Altitude) (Used After Code Date 03110600).
			29	499424	Rod-Connecting			<b>Note</b> _____		
			32	691664	Screw (Connecting Rod)			498975 Jet-Main (High Altitude) (Used Before Code Date 03110700).		
			32A	695759	Screw (Connecting Rod)					
			33	499642	Valve-Exhaust					
			34	499641	Valve-Intake					
			35	691304	Spring-Valve (Intake)					

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△Included in Valve Gasket Set-Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 12B600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
121	692703	Kit-Carburetor Overhaul	269	691026	Wire-Control (Cut To Required Length)	455	695161	Cup-Flywheel
122	◆692799	Spacer-Carburetor	270	691027	Nut (Control Wire Casing)	456	692299	Plate-Pawl Friction
125	694202	Carburetor	271	691028	Lever-Control	459	281505	Pawl-Ratchet
127	●694468	Plug-Welch	276	◆271716	Washer-Sealing	505	691251	Nut (Governor Control Lever)
130	691203	Valve-Throttle	287	690940	Screw (Dipstick Tube)	523	499621	Dipstick
		<b>Note</b>	300D	696526	Muffler-Exhaust	524	★692296	Seal-Dipstick Tube
		696564 Valve-Throttle (Used With Plastic Throttle Shaft)	304	696527	Housing-Blower	525	495265	Tube-Dipstick
133	398187	Float-Carburetor	305	691108	Screw (Blower Housing)	529A	691923	Grommet
134	●398188	Kit-Needle/Seat			<b>Note</b>	562	691119	Bolt (Governor-Control Lever)
137	◆693981	Gasket-Float Bowl			691138 Screw (Blower Housing)	563	691138	Screw (Debris Guard Screen)
146	690979	Key-Timing	306	691232	Shield-Cylinder	564	693808	Screw (Control Cover)
163A	◆692667	Gasket-Air Cleaner	307	690345	Screw (Cylinder Shield)	584	697734	Cover-Breather Passage
187	691050	Line-Fuel (Cut to Required Length)	332	690662	Nut (Flywheel)	585	★691879	Gasket-Breather Passage
188	691147	Screw (Control Bracket)	333	802574	Armature-Magneto	592	690800	Nut (Rewind Starter)
190	690940	Screw (Fuel Tank)	334	691061	Screw (Magneto Armature)	597	691696	Screw (Pawl Friction Plate)
192	694543	Adjuster-Rocker Arm	337	692051	Plug-Spark	601	95162	Clamp-Hose
202	691303	Link-Mechanical Governor	356	692390	Wire-Stop	604	692669	Cover-Control
209	691290	Spring-Governor Used on Type No(s). 0100.	358	694090	Gasket Set-Engine	608	497680	Starter-Rewind
		<b>Note</b>	363	19069	Puller-Flywheel	613	691108	Screw (Muffler)
		691291 Spring-Governor Used on Type No(s). 0104.	365	691136	Screw (Carburetor)	613A	691140	Screw (Muffler)
222A	693378	Bracket-Control	383	19374	Wrench-Spark Plug	615	690340	Retainer-Governor Shaft
227	691467	Lever-Governor Control	404	690272	Washer (Governor Crank)	616	698801	Crank-Governor
238	691300	Cap-Valve	425	690670	Screw (Air Cleaner Cover)	619	691108	Screw (Cylinder Head Plate)
265	690798	Clamp-Casing	443	691637	Screw (Air Cleaner Primer Base)	621	692310	Switch-Stop
267	691044	Screw (Casing Clamp)	443A	692523	Screw (Air Cleaner Primer Base)	633A	◆691321	Seal-Choke/Throttle Shaft (Throttle Shaft)
268	691025	Casing-Control Wire (Cut To Required Length)	445	491588	Filter-Air Cleaner Cartridge	635	66538	Boot-Spark Plug

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
670	692294	Spacer–Fuel Tank	914	691108	Screw (Rocker Cover)	1036	790635	Label–Emission (Used After Code Date 04063000).
684	690345	Screw (Breather Passage Cover)	949	696306	Guard–Debris Screen			———— <b>Note</b> ————
689	691855	Spring–Friction	957	692046	Cap–Fuel Tank (Plastic)			<b>696767</b> Label– Emission
703	696309	Clip	966	692673	Base–Air Cleaner Primer			(Used Before Code Date 04070100 and After Code Date 01070100).
718	690959	Pin–Locating	967	493537	Filter–Pre Cleaner			<b>695109</b> Label– Emission
741	790345	Gear–Timing (Use Without Woodruff Key)	968	692298	Cover–Air Cleaner			(Used Before Code Date 01070200).
		———— <b>Note</b> ————	972	693377	Tank–Fuel (Plastic)			
		<b>691830</b> Gear–Timing (Uses Woodruff Key)	975	493640	Bowl–Float			
830	694544	Stud–Rocker Arm	976	694395	Primer–Carburetor			
842	★691031	Seal–O Ring (Dipstick Tube)	977	692704	Gasket Set–Carburetor	1058	274979	Manual–Owner’s
843	691884	Sleeve–Lever	997	696310	Shield–Debris	1059	692311	Kit–Screw/Washer
847	692047	Dipstick/Tube Assembly	1005	691346	Fan–Flywheel	1095	694091	Gasket Set–Valve
851	493880	Terminal–Spark Plug	1019	696438	Kit–Label	1210	498144	Pulley/Spring Assembly (Pulley)
868	★Δ692044	Seal–Valve	1022	★Δ691890	Gasket–Rocker Cover	1211	498144	Pulley/Spring Assembly (Spring)
883	★Δ691893	Gasket–Exhaust	1023	499624	Cover–Rocker Arm			
886	696268	Gasket Set–Cylinder Head/Plate	1026	692045	Rod–Push			
			1029	691230	Arm–Rocker	1330	272147	Manual–Repair
			1034	691343	Guide–Push Rod			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

ΔIncluded in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**