



# Illustrated Parts List

## Model Series

# 12C300

TYPE NUMBERS  
0131 through 0279.

### TABLE OF CONTENTS

<b>Blower Housing/Shrouds</b> .....	6
<b>Camshaft</b> .....	2
<b>Carburetor</b> .....	4
<b>Controls</b> .....	5
<b>Crankcase Cover</b> .....	2
<b>Crankshaft</b> .....	2
<b>Cylinder</b> .....	2
<b>Cylinder Head</b> .....	3
<b>Electric Starter</b> .....	5
<b>Exhaust System</b> .....	6
<b>Flywheel</b> .....	6
<b>Fuel Supply</b> .....	4
<b>Governor Spring</b> .....	5
<b>Ignition</b> .....	5
<b>Kits/Gaskets – Carburetor</b> .....	4
<b>Kits/Gaskets – Engine</b> .....	2
<b>Kits/Gaskets – Valves</b> .....	3
<b>Lubrication</b> .....	2
<b>Piston Group</b> .....	2
<b>Rewind Starter</b> .....	5

PRINTED IN U.S.A.














COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

# 12C300





1019 LABEL KIT

1058 OWNER'S MANUAL







1330 REPAIR MANUAL





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 5722-2 Assemblies include all parts shown in frames. 10/20/2004



**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**  
**5722-3** Assemblies include all parts shown in frames. **10/20/2004**




*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*  
 5722-4 Assemblies include all parts shown in frames. 10/20/2004





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 5722-5 Assemblies include all parts shown in frames. 10/20/2004

# 12C300



1036 EMISSION LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
5722-6 Assemblies include all parts shown in frames. 10/20/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699510	Cylinder Assembly	32	691664	Screw (Connecting Rod)	121	696998	Kit-Carburetor Overhaul
2	399269	Kit-Bushing/Seal (Magneto Side)	32A	695759	Screw (Connecting Rod)	122	●693749	Spacer-Carburetor
3	★299819	Seal-Oil (Magneto Side)	33	499642	Valve-Exhaust	125A	695727	Carburetor
5	699486	Head-Cylinder	34	499641	Valve-Intake	127	●694468	Plug-Welch
7	★∅698210	Gasket-Cylinder Head	35	691304	Spring-Valve (Intake)	127A	●691739	Plug-Welch
11B	695745	Tube-Breather	36	691304	Spring-Valve (Exhaust)	130	691181	Valve-Throttle
12	★699485	Gasket-Crankcase	37	699661	Guard-Flywheel	133	398187	Float-Carburetor
13	699482	Screw (Cylinder Head)	40	692194	Retainer-Valve	134	●398188	Kit-Needle/Seat
15	691686	Plug-Oil Drain	45	690977	Tappet-Valve	137	●●693981	Gasket-Float Bowl
15B	695757	Plug-Oil Drain	46	693404	Camshaft	146	690979	Key-Timing
16	699454	Crankshaft	51	★◆∅692555	Gasket-Intake (2 Required)	155	698214	Plate-Cylinder Head
18	699804	Cover-Crankcase	55A	696710	Housing-Rewind Starter	186	692317	Connector-Hose
20	★692550	Seal-Oil (PTO Side)	58	693389	Rope-Starter (Cut To Required Length)	187B	693401	Line-Fuel (Molded)
21	281658	Cap-Oil Fill	60B	699334	Grip-Starter Rope	188	699479	Screw (Control Bracket)
22	699478	Screw (Crankcase Cover/ Sump)	65	699228	Screw (Rewind Starter)	190	699220	Screw (Fuel Tank)
23	699516	Flywheel	65A	699851	Screw (Rewind Starter)	192	694543	Ball-Rocker Arm
24	222698	Key-Flywheel	78	699205	Screw (Flywheel Guard)	209	692571	Spring-Governor
25	690021	Piston Assembly (Standard)	95	691636	Screw (Throttle Valve)	209A	691278	Spring-Governor
		<b>Note</b>	97	690024	Shaft-Throttle	219	693578	Gear-Governor
		694168 Piston Assembly (.020" Oversize)	98	398185	Kit-Idle Speed	220	691724	Washer (Governor Gear)
26	499631	Ring Set (Standard)	104	●691242	Pin-Float Hinge	222	699592	Bracket-Control
		<b>Note</b>	108	695807	Valve-Choke	227	692573	Lever-Governor Control
		692786 Ring Set (.020" Oversize)	109B	695729	Shaft-Choke	238	691300	Cap-Valve
27	691866	Lock-Piston Pin	117	690048	Jet-Main (Standard)	268	691072	Control Wire Casing (Cut to Required Length)
28	499423	Pin-Piston	118	498977	Jet-Main (High Altitude)	269	691589	Control Wire (Cut to Required Length)
29	690124	Rod-Connecting				270	691027	Nut (Control Wire Casing)
30	692562	Dipper-Connecting Rod				271	691028	Lever-Control
						271A	698038	Lever-Control

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No.1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 12C300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
276	♦♦271716	Washer–Sealing	427	694255	Nut (Control Bracket)	621	692310	Switch–Stop
281A	696684	Panel–Control	441	694262	Bracket–Oil Fill	632	692653	Spring/Link– Mechanical Governor
300	699512	Muffler Used on Type No(s). 0207, 0208, 0279.	449	699629	Screw (Oil Fill Bracket)	633	♦♦693867	Seal–Choke/Throttle Shaft (Choke)
		<b>Note</b>	455	692591	Cup–Flywheel	633A	♦♦691321	Seal–Choke/Throttle Shaft (Throttle)
		699511 Muffler Used on Type No(s). 0131.	456	692299	Plate–Pawl Friction	635A	692927	Boot–Sparkplug
304	699598	Housing–Blower	459	281505	Pawl–Ratchet	663	699854	Screw (Control Panel)
305	699480	Screw (Blower Housing)	472	696691	Knob–Choke Shaft	668	694257	Spacer
306A	695710	Shield–Cylinder	474	694457	Alternator	689	691855	Spring–Friction
307	699483	Screw (Cylinder Shield)	485	695755	Knob–Control	692	690572	Spring–Detent (Choke)
307A	699234	Screw (Cylinder Shield)	493A	695744	Bracket–Mounting	718	690959	Pin–Locating
309A	696818	Motor–Starter Used on Type No(s). 0131, 0207.	504	694254	Washer Set–Friction	731	696690	Hood–Snow
		<b>Note</b>	505	691251	Nut (Governor Control Lever)	741	695087	Gear–Timing
		699786 Motor–Starter Used on Type No(s). 0208.	523	693618	Dipstick	742	692564	Retainer–E Ring
318	690370	Screw (Mounting Bracket)	524	281370	Seal–Dipstick Tube	746	692566	Gear–Idler
332	699359	Nut (Flywheel)	528	695746	Hose–Primer	773	694258	Retainer
333	695711	Armature–Magneto	552	692346	Bushing–Governor Crank	819	699233	Screw (Muffler Bracket)
334	699477	Screw (Magneto Armature)	562	691119	Bolt (Governor Control Lever)	823	699209	Screw (Muffler Adapter)
337	491055	Spark–Plug	597	691696	Screw (Pawl Friction Plate)	824	696017	Gasket–Heat Shield
356K	695731	Wire–Stop	598	220624	Shim–End Play	830	694544	Stud (Rocker Arm)
358	699638	Set–Engine Gasket	601	95162	Clamp–Hose	832A	699313	Guard–Muffler
363	19069	Puller–Flywheel	604A	695749	Cover–Control	836B	699209	Screw (Muffler Guard)
365	699484	Screw (Carburetor)	608A	699335	Starter–Rewind	836C	699234	Screw (Muffler Guard)
383	19374	Wrench–Spark Plug	613	697812	Screw (Muffler)	842	691031	Seal–O Ring (Dipstick Tube)
			613A	699230	Screw (Muffler)	847	693617	Dipstick/Tube Assembly
			615	692576	Retainer–Governor Shaft			
			616	692547	Crank–Governor			
			619	699230	Screw (Cylinder Head Plate)			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

5722–8

Assemblies include all parts shown in frames.

10/20/2004



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
851	493880	Terminal-Spark Plug	976	790221	Primer-Carburetor (Snap Fit)	1054	280275	Tie-Cable
863	699849	Bracket-Muffler			————— <b>Note</b> —————	1058	275697	Owner's Manual
864	699232	Adapter-Muffler				1070	699201	Screw (Flywheel Fan)
868	★∅692044	Seal-Valve				1095	698215	Gasket Set-Valve
883	★692237	Gasket-Exhaust	977	697001	Gasket Set-Carburetor	1119	699772	Screw (Alternator)
883A	★691893	Gasket-Exhaust	990	695756	Key-Set	1196	696692	Screw (Snow Hood)
892	695747	Switch-Key	993	★∅694088	Gasket-Cylinder Head Plate	1196A	699854	Screw (Snow Hood)
914	699481	Screw (Rocker Cover) (Bottom)	998	696683	Pipe-Oil	1210	498144	Pulley/Spring Assembly (Pulley)
914A	692557	Screw (Rocker Cover) (Top)	1005	692592	Fan-Flywheel	1211	498144	Pulley/Spring Assembly (Spring)
914B	697551	Screw (Rocker Cover) (Center)	1019	695751	Kit-Label	1224	696824	Nut (Carburetor Primer)
930	696709	Guard-Rewind	1022	★∅691890	Gasket-Rocker Cover	1230	699847	Screw (Control Bracket)
957	695737	Cap-Fuel Tank Used on Type No(s). 0131.	1023	499924	Cover-Rocker Arm	1251	696699	Shield-Snow
957A	698109	Cap-Fuel Tank Used on Type No(s). 0207, 0208, 0279.	1026	790287	Rod-Push	1252	699234	Screw (Snow Shield)
972	698110	Tank-Fuel Used on Type No(s). 0207, 0208, 0279.	1029	691230	Arm-Rocker	1330	272147	Repair Manual
		————— <b>Note</b> —————	1034	691343	Guide-Push Rod			
		695728 Tank-Fuel Used on Type No(s). 0131.	1036	790634	Label-Emission (Used After Code Date 04063000).			
975	493640	Bowl-Float			————— <b>Note</b> —————			
					699946 Label-Emission (Used Before Code Date 04070100 and After Code Date 03093000).			
					697004 Label-Emission (Used Before Code Date 03100100).			

★ Included in Engine Gasket Set-Ref. No.358.  
 ● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.  
 ∅ Included in Valve Gasket Set-Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**