

# 12D300

## Illustrated Parts List

### Model Series

# 12D300

TYPE NUMBERS  
0007 through 0019.

### TABLE OF CONTENTS

Blower Housing/Shrouds .....	6
Camshaft .....	2
Carburetor .....	4
Controls .....	5
Crankcase Cover .....	2
Crankshaft .....	2
Cylinder .....	2
Cylinder Head .....	3
Electric Starter .....	5
Exhaust System .....	6
Flywheel .....	6
Fuel Supply .....	4
Governor Spring .....	5
Ignition .....	5
Kits/Gaskets – Carburetor .....	4
Kits/Gaskets – Engine .....	2
Kits/Gaskets – Valves .....	3
Lubrication .....	2
Piston Group .....	2
Rewind Starter .....	5

PRINTED IN U.S.A.

















COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted,  
in any form or by any means, electronic or mechanical, including photocopying,  
recording or by any information storage and retrieval system, without permission  
in writing from Briggs & Stratton Corporation.

# 12D300





1019 LABEL KIT

1058 OWNER'S MANUAL









1330 REPAIR MANUAL










Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
5723-2 Assemblies include all parts shown in frames. 07/22/2004




**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**  
**5723-3** Assemblies include all parts shown in frames. **07/22/2004**








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 5723-5 Assemblies include all parts shown in frames.

# 12D300



1036 EMISSION LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
5723-6 Assemblies include all parts shown in frames. 07/22/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
1	699505	Cylinder Assembly	26	499631	Ring Set (Standard)	95	691636	Screw (Throttle Valve)	
2	399269	Kit-Bushing/Seal (Magneto Side)			————— <b>Note</b> —————	97	690024	Shaft-Throttle	
3	★299819	Seal-Oil (Magneto Side)			692786	Ring Set (.020" Oversize)	98	398185	Kit-Idle Speed
5	699486	Head-Cylinder	27	691866	Lock-Piston Pin	104	●691242	Pin-Float Hinge	
7	★∅698210	Gasket-Cylinder Head	28	499423	Pin-Piston	108	695807	Valve-Choke	
11B	695745	Tube-Breather	29	690124	Rod-Connecting	109B	695729	Shaft-Choke	
12	★699485	Gasket-Crankcase	30	692562	Dipper-Connecting Rod	117	690048	Jet-Main (Standard)	
13	699482	Screw (Cylinder Head)	32	691664	Screw (Connecting Rod)	118	498977	Jet-Main (High Altitude)	
15	691686	Plug-Oil Drain	32A	695759	Screw (Connecting Rod)	121	696998	Kit-Carburetor Overhaul	
16	699451	Crankshaft Used on Type No(s). 0009, 0019.	33	499642	Valve-Exhaust	122	●693749	Spacer-Carburetor	
		————— <b>Note</b> —————	34	499641	Valve-Intake	125A	695727	Carburetor	
		699445	35	691304	Spring-Valve (Intake)	127	●694468	Plug-Welch	
		Crankshaft Used on Type No(s). 0007, 0017, 0018.	36	691304	Spring-Valve (Exhaust)	127A	●691739	Plug-Welch	
18	699804	Cover-Crankcase	37	699661	Guard-Flywheel	130	691181	Valve-Throttle	
18B	699677	Cover-Crankcase	40	692194	Retainer-Valve	133	398187	Float-Carburetor	
20	★692550	Seal-Oil (PTO Side)	45	690977	Tappet-Valve	134	●398188	Kit-Needle/Seat	
20A	★691952	Seal-Oil (PTO Side)	46	693404	Camshaft	137	●●693981	Gasket-Float Bowl	
21	281658	Cap-Oil Fill	46A	694831	Camshaft	146	690979	Key-Timing	
22	699478	Screw (Crankcase Cover/Sump)	51	★●∅692555	Gasket-Intake	155	698214	Plate-Cylinder Head	
23	699516	Flywheel	55A	696710	Housing-Rewind Starter	186	692317	Connector-Hose	
24	222698	Key-Flywheel	58	693389	Rope-Starter (Cut To Required Length)	187	691050	Line-Fuel (Cut To Required Length)	
25	499627	Piston Assembly (Standard)	60B	699334	Grip-Starter Rope	187A	692601	Line-Fuel (Molded)	
		————— <b>Note</b> —————	65	699228	Screw (Rewind Starter)	188	699479	Screw (Control Bracket)	
		692789	65A	699851	Screw (Rewind Starter)	190	699220	Screw (Fuel Tank)	
		Piston Assembly (.020" Oversize)	78	699205	Screw (Flywheel Guard)	192	694543	Ball-Rocker Arm	
						209	692571	Spring-Governor	
						209A	691278	Spring-Governor	
						219	693578	Gear-Governor	

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 12D300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
220	691724	Washer (Governor Gear)	365	699484	Screw (Carburetor)	619	699230	Screw (Cylinder Head Plate)
222	699592	Bracket–Control	383	19374	Wrench–Spark Plug	621	692310	Switch–Stop
227	692573	Lever–Governor Control	427	694255	Nut (Control Bracket)	632	692653	Spring/Link– Mechanical Governor
238	691300	Cap–Valve	441	694262	Bracket–Oil Fill	633	◆693867	Seal–Choke/Throttle Shaft (Choke)
268	691072	Control Wire Casing (Cut to Required Length)	449	699629	Screw (Oil Fill Bracket)	633A	◆691321	Seal–Choke/Throttle Shaft (Throttle)
269	691589	Control Wire (Cut to Required Length)	455	692591	Cup–Flywheel	635A	692927	Boot–Sparkplug
270	691027	Nut (Control Wire Casing)	456	692299	Plate–Pawl Friction	663	699854	Screw (Control Panel)
271	691028	Lever–Control	459	281505	Pawl–Ratchet	668	694257	Spacer
271A	698038	Lever–Control	472	696691	Knob–Choke Shaft	689	691855	Spring–Friction
276	◆271716	Washer–Sealing	485	695755	Knob–Control	692	690572	Spring–Detent (Choke)
281A	696684	Panel–Control	493A	695744	Bracket–Mounting	718	690959	Pin–Locating
300	699511	Muffler	504	694254	Washer Set–Friction	731	696690	Hood–Snow
304	699598	Housing–Blower	505	691251	Nut (Governor Control Lever)	741	695087	Gear–Timing
305	699480	Screw (Blower Housing)	523	693618	Dipstick	742	692564	Retainer–E Ring
306A	695710	Shield–Cylinder	524	281370	Seal–Dipstick Tube	746	692566	Gear–Idler
307	699483	Screw (Cylinder Shield)	528	695746	Hose–Primer	773	694258	Retainer
307A	699234	Screw (Cylinder Shield)	552	692346	Bushing–Governor Crank	819	699233	Screw (Muffler Bracket)
309A	696818	Motor–Starter	562	691119	Bolt (Governor Control Lever)	823	699209	Screw (Muffler Adapter)
318	690370	Screw (Mounting Bracket)	597	691696	Screw (Pawl Friction Plate)	824	696017	Gasket–Heat Shield
332	699359	Nut (Flywheel)	598	220624	Shim–End Play	830	694544	Stud (Rocker Arm)
333	695711	Armature–Magneto	601	95162	Clamp–Hose	842	691031	Seal–O Ring (Dipstick Tube)
334	699477	Screw (Magneto Armature)	604A	695749	Cover–Control	847	693617	Dipstick/Tube Assembly
337	491055	Spark–Plug	608A	699335	Starter–Rewind	851	493880	Terminal–Spark Plug
356K	695731	Wire–Stop	613	697812	Screw (Muffler)	863	699849	Bracket–Muffler
358	699638	Set–Engine Gasket	613A	699230	Screw (Muffler)	864	699232	Adapter–Muffler
363	19069	Puller–Flywheel	615	692576	Retainer–Governor Shaft			
			616	692547	Crank–Governor			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

⊘ Included in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

5723–8

Assemblies include all parts shown in frames.

07/22/2004



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
868	★Ø692044	Seal-Valve	990	695756	Key-Set	1058	275697	Owner's Manual
883	★692237	Gasket-Exhaust	993	★Ø694088	Gasket-Cylinder Head Plate	1070	699201	Screw (Flywheel Fan)
883A	★691893	Gasket-Exhaust	1005	692592	Fan-Flywheel	1095	698215	Gasket Set-Valve
892	695747	Switch-Key	1019	695751	Kit-Label	1196	696692	Screw (Snow Hood)
914	699481	Screw (Rocker Cover) (Bottom)	1022	★Ø691890	Gasket-Rocker Cover			
914A	692557	Screw (Rocker Cover) (Top)	1023	499924	Cover-Rocker Arm	1196A	696685	Screw (Snow Hood) (Muffler)
914B	697551	Screw (Rocker Cover) (Center)	1026	790287	Rod-Push	1210	498144	Pulley/Spring Assembly (Pulley)
930	696709	Guard-Rewind	1029	691230	Arm-Rocker	1211	498144	Pulley/Spring Assembly (Spring)
957	695737	Cap-Fuel Tank	1034	691343	Guide-Push Rod	1224	696824	Nut (Carburetor Primer)
958	698180	Valve-Fuel Shut Off	1036	790634	Label-Emission (Used After Code Date 04063000).	1230	699847	Screw (Control Bracket)
972	695728	Tank-Fuel			<b>Note</b> _____	1251	696699	Shield-Snow
975	493640	Bowl-Float			699946 Label-Emission (Used Before Code Date 04070100 and After Code Date 03093000).	1252	699234	Screw (Snow Shield)
976	790221	Primer-Carburetor (Snap Fit)			697004 Label-Emission (Used Before Code Date 03100100).	1330	272147	Repair Manual
		<b>Note</b> _____						
		695750 Primer-Carburetor						
977	697001	Gasket Set-Carburetor						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**