



Illustrated Parts List

Model Series

12G600

TYPE NUMBERS
0100 through 0110.

TABLE OF CONTENTS


Air Cleaner	5
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	6






PRINTED IN U.S.A.





COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12G600




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5376-2 Assemblies include all parts shown in frames. 10/08/2004





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5376-5 Assemblies include all parts shown in frames. 10/08/2004

12G600


1036 Emission Label

930A



78

305



65


592

332


455




1005



363




23



608

55




65

592

1211

1210



459


689

456

597

58

60



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5376-6 Assemblies include all parts shown in frames. 10/08/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697893	Cylinder Assembly	24	222698	Key–Flywheel	32	691664	Screw
2	399269	Kit–Bushing/Seal (Magneto Side)	25	790359	Piston Assembly (Standard)			(Connecting Rod)
3	★299819	Seal–Oil (Magneto Side)			(Used After Code Date 04040400).	32A	695759	Screw
4	493279	Sump–Engine			Note			(Connecting Rod)
		Note			690021 Piston Assembly (Standard)	33	499642	Valve–Exhaust
		498983 Sump–Engine Used on Type No(s). 0110.			(Used Before Code Date 04040500).	34	499641	Valve–Intake
5	695276	Head–Cylinder			694167 Piston Assembly (.010" Oversize)	35	691304	Spring–Valve (Intake)
7	★△695166	Gasket–Cylinder Head			694168 Piston Assembly (.020" Oversize)	36	691304	Spring–Valve (Exhaust)
8	495786	Breather Assembly			694169 Piston Assembly (.030" Oversize)	37	694086	Guard–Flywheel
9	★272481	Gasket–Breather			Ring Set (Standard)	40	692194	Retainer–Valve
10	691125	Screw (Breather Assembly)			(Used After Code Date 04040400).	43	691486	Slinger–Governor/Oil
11	499675	Tube–Breather			Note			691997 Slinger– Governor/Oil Used on Type No(s). 0110.
12	★692232	Gasket–Crankcase	26	790360	499631 Ring Set (Standard)	45	690977	Tappet–Valve
13	691137	Screw (Cylinder Head)			(Used Before Code Date 04040500).	46	694039	Camshaft
15	691680	Plug–Oil Drain (Square Socket)			692785 Ring Set (.010" Oversize)	51★♦♦△692799		Gasket–Intake
16	692803	Crankshaft			692786 Ring Set (.020" Oversize)	55	691421	Housing–Rewind Starter
		Note			692787 Ring Set (.030" Oversize)	58	697316	Rope–Starter (Cut To Required Length)
		691457 Crankshaft Used on Type No(s). 0110.			Lock–Piston Pin	60	281434	Grip–Starter Rope
20	★399781	Seal–Oil (PTO Side)	27	691866	Pin–Piston	65	690837	Screw (Rewind Starter)
22	691092	Screw (Crankcase Cover/Sump)	28	499423	Rod–Connecting	78	691108	Screw (Flywheel Guard)
23	697610	Flywheel	29	499424		95	691636	Screw (Throttle Valve)
		Note				97	499682	Shaft–Throttle
		697586 Flywheel Used on Type No(s). 0110.				98	398185	Kit–Idle Speed
						104	●691242	Pin–Float Hinge
						108	692567	Valve–Choke

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

♦ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12G600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
109	693866	Shaft—Choke	267	691044	Screw (Casing Clamp)	425	690670	Screw (Air Cleaner Cover)
117A	498976	Jet—Main (Standard)	268	691025	Casing—Control Wire (Cut To Required Length)	443	691637	Screw (Air Cleaner Primer Base)
118A	694975	Jet—Main (High Altitude)	269	691026	Wire—Control (Cut To Required Length)	443A	692523	Screw (Air Cleaner Primer Base)
121	692703	Kit—Carburetor Overhaul	270	691027	Nut (Control Wire Casing)	445	491588	Filter—Air Cleaner Cartridge
122	692799	Spacer—Carburetor	271	691028	Lever—Control	455	695161	Cup—Flywheel
125A	698953	Carburetor	276	271716	Washer—Sealing	456	692299	Plate—Pawl Friction
127	694468	Plug—Welch	287	690940	Screw (Dipstick Tube)	459	281505	Ratchet—Pawl
127A	691739	Plug—Welch	300	697590	Muffler—Exhaust	472	693809	Knob—Choke Bracket
130	691181	Valve—Throttle	304	499676	Housing—Blower	493	692877	Bracket—Mounting
133	398187	Float—Carburetor	305	691108	Screw (Blower Housing)	505	691251	Nut (Governor Control Lever)
134	398188	Kit—Needle/Seat	306	691232	Shield—Cylinder	523	499621	Dipstick
137	693981	Gasket—Float Bowl	307	690345	Screw (Cylinder Shield)	524	692296	Seal—Dipstick Tube
146	690979	Key—Timing	332	690662	Nut (Flywheel)	525	495265	Tube—Dipstick
163A	692667	Gasket—Air Cleaner	333	802574	Armature—Magneto	529A	691923	Grommet
187	691050	Line—Fuel (Cut to Required Length)	334	691061	Screw (Magneto Armature)	532	692851	Nut (Mounting Bracket)
188	691147	Screw (Control Bracket)	337	692051	Plug—Spark	562	691119	Bolt (Governor—Control Lever)
190	690940	Screw (Fuel Tank)	341	690368	Stud (Mounting Bracket)	564A	693808	Screw (Control Cover)
192	694543	Adjuster—Rocker Arm	347	691396	Switch—Rocker	584	697734	Cover—Breather Passage
202	691303	Link—Mechanical Governor	356	692390	Wire—Stop	585	691879	Gasket—Breather Passage
209	693032	Spring—Governor	356A	693010	Wire—Stop	592	690800	Nut (Rewind Starter)
		Note	358	694090	Gasket Set—Engine	597	691696	Screw (Pawl Friction Plate)
		691290 Spring— Governor Used on Type No(s). 0110.	363	19069	Puller—Flywheel	601	95162	Clamp—Hose
222A	693378	Bracket—Control	365	691136	Screw (Carburetor)	604A	693807	Cover—Control
222B	693897	Bracket—Control	383	19374	Wrench—Spark Plug			
227	691467	Lever—Governor Control	404	690272	Washer (Governor Crank)			
238	691300	Cap—Valve						
265	690798	Clamp—Casing						

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

△ Included in Valve Gasket Set—Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
608	497680	Starter–Rewind	830	694544	Stud–Rocker Arm	993	★Δ694088	Gasket–Cylinder Head Plate
613	691108	Screw (Muffler)	832	691466	Guard–Muffler	1005	691346	Fan–Flywheel
613A	691140	Screw (Muffler)	836	691147	Screw (Muffler Guard)	1019	695247	Kit–Label
615	690340	Retainer–Governor Shaft	836A	697551	Screw (Muffler Guard)	1022	★Δ691890	Gasket–Rocker Cover
616	698801	Crank–Governor	842	★691031	Seal–O Ring (Dipstick Tube)	1023	499624	Cover–Rocker Arm
619	691108	Screw (Cylinder Head Plate)	843	692310	Sleeve–Lever	1026	692045	Rod–Push
621	692310	Switch–Stop	847	692047	Dipstick/Tube Assembly	1029	691230	Arm–Rocker
633	◆693867	Seal–Choke/Throttle Shaft (Choke Shaft)	851	493880	Terminal–Spark Plug	1034	691343	Guide–Push Rod
633A	◆◆691321	Seal–Choke/Throttle Shaft (Throttle Shaft)	868	★Δ692044	Seal–Valve	1036	790635	Label–Emission (Used After Code Date 04063000).
635	66538	Boot–Spark Plug	883	★Δ691893	Gasket–Exhaust	———— Note ————		
670	692294	Spacer–Fuel Tank	886	696268	Gasket Set–Cylinder Head/Plate	696767		Label– Emission (Used Before Code Date 04070100).
684	690345	Screw (Breather Passage Cover)	914	691108	Screw (Rocker Cover)	1058	274979	Manual–Owner’s
689	691855	Spring–Friction	930A	692675	Guard–Rewind	1059	692311	Kit–Screw/Washer
692	690572	Spring–Detent	957	692046	Cap–Fuel Tank (Plastic)	1095	694091	Gasket Set–Valve
718	690959	Pin–Locating	966A	693863	Base–Air Cleaner Primer (Choke System)	1102	691255	Pilot–Guide
741	790345	Gear–Timing (Use Without Woodruff Key)	968	692298	Cover–Air Cleaner	1210	498144	Pulley/Spring Assembly (Pulley)
———— Note ————			972	693377	Tank–Fuel (Plastic)	1211	498144	Pulley/Spring Assembly (Spring)
691830 Gear–Timing (Uses Woodruff Key)			975	493640	Bowl–Float	1330	272147	Manual–Repair
			977	692704	Gasket Set–Carburetor			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

Δ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.