

12K300

Illustrated Parts List

Model Series

12K300

TYPE NUMBERS
0153.

TABLE OF CONTENTS


Air Cleaner	4
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	4
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Flywheel	5
Governor Spring	4
Ignition	4
Kits/Gaskets – Carburetor	4
Kits/Gaskets – Engine	2
Kits/Gaskets – Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	5





PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.




12K300




1019 LABEL KIT
1058 OWNER'S MANUAL
1330 REPAIR MANUAL





15A







24













17A






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
6145-2 Assemblies include all parts shown in frames. 10/20/2004



12K300



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6145-4 Assemblies include all parts shown in frames. 10/20/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6145-5 Assemblies include all parts shown in frames. 10/20/2004

12K300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699490	Cylinder Assembly			Rod	130	691181	Valve-Throttle
2	399269	Kit-Bushing/Seal (Magneto Side)	32	691664	Screw (Connecting Rod)	133	398187	Float-Carburetor
3	★299819	Seal-Oil (Magneto Side)	32A	695759	Screw (Connecting Rod)	134	●398188	Kit-Needle/Seat
5	699486	Head-Cylinder	33	499642	Valve-Exhaust	137	●◆693981	Gasket-Float Bowl
7	★∅698210	Gasket-Cylinder Head	34	499641	Valve-Intake	146	690979	Key-Timing
11	692600	Tube-Breather (Flat Panel Air Cleaner)	35	691304	Spring-Valve (Intake)	155	★698214	Plate-Cylinder Head
12	★699485	Gasket-Crankcase	36	691304	Spring-Valve (Exhaust)	161	699207	Base-Air Cleaner (Metal) (Flat Panel Air Cleaner)
13	699482	Screw (Cylinder Head)	37	699661	Guard-Flywheel	163B	★◆◆696024	Gasket-Air Cleaner (Flat Panel Air Cleaner)
15	691686	Plug-Oil Drain (Square Head)	40	692194	Retainer-Valve	186	692317	Connector-Hose
15A	691682	Plug-Oil Drain (Flush)	45	690977	Tappet-Valve	188	699479	Screw (Control Bracket)
16	790568	Crankshaft	46A	696813	Camshaft	192	694543	Adjuster-Rocker Arm
17	692517	Bearing-Ball	51	★◆◆∅692555	Gasket-Intake (2 Required)	209	692571	Spring-Governor
17A	690824	Bearing-Ball	55	691422	Housing-Rewind Starter	219	693578	Gear-Governor
18A	699672	Cover-Crankcase	58	693389	Rope-Starter (Cut to Required Length)	220	691724	Washer (Governor Gear)
20	★692550	Seal-Oil (PTO Side)	59	490653	Grip-Insert	222C	699493	Bracket-Control
21	281658	Cap-Oil Fill	60	490652	Grip-Starter Rope (2 Piece)	227	692573	Lever-Governor Control
22	699478	Screw (Crankcase Cover/ Sump)	65	699228	Screw (Rewind Starter)	238	691300	Valve-Cap
23	699488	Flywheel	78	699205	Screw (Flywheel Guard)	265	691024	Clamp-Casing
24	222698	Key-Flywheel	95	691636	Screw (Throttle Valve)	267	699492	Screw (Casing Clamp)
25	499627	Piston Assembly (Standard)	97	690024	Shaft-Throttle	268	691025	Casing-Control Wire (72" Long) (Cut to Required Length)
		Note _____	98	398185	Kit-Idle Speed (Carburetor)	269	691026	Wire-Control (78" Long) (Cut to Required Length)
		692789 Piston Assembly (.020" Oversize)	104	◆691242	Pin-Float Hinge	270	691027	Nut (Control Wire Casing)
26	499631	Ring Set (Standard)	108	692567	Valve-Choke	271	691028	Lever-Control
		Note _____	109	690023	Valve-Choke	276	◆271716	Washer-Sealing
		692786 Ring Set (.020" Oversize)	117	790570	Jet-Main (Standard)	286	698611	Module-Oil Sensor
27	691866	Lock-Piston Pin	121A	696998	Kit-Carburetor Overhaul	304	699598	Housing-Blower
28	499423	Pin-Piston	122	★◆693749	Spacer-Carburetor	305	699480	Screw (Blower Housing)
29	690124	Rod-Connecting	125	790569	Carburetor			
30	692562	Dipper-Connecting	127	◆691739	Plug-Welch			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
306	693610	Shield–Cylinder	608	693394	Starter–Rewind	968	692584	Cover–Air Cleaner (Flat Panel)
307	699483	Screw (Cylinder Shield)	615	692576	Retainer–Governor Shaft	971	690370	Screw (Air Cleaner Base To Carburetor)
332	699359	Nut (Flywheel)	616	692547	Crank–Governor			
333	695711	Armature–Magneto	619	699230	Screw (Cylinder Head Plate)	975	493640	Bowl–Float
334	699477	Screw (Magneto Armature)	632	693408	Spring/Link–Mechanical Governor	976A	692666	Primer–Carburetor
337	491055	Plug–Spark	633	●693867	Seal–Choke/Throttle Shaft	977A	697001	Gasket Set–Carburetor
347	698338	Switch–Rocker	633A	●691321	Seal–Choke/Throttle Shaft	993	∅694088	Gasket–Cylinder Head Plate
356	692602	Wire–Stop				1005	692592	Fan–Flywheel
358	699638	Gasket Set–Engine				1019	694852	Kit–Label
363	19069	Puller–Flywheel	635	692927	Boot–Spark Plug	1022	★∅691890	Gasket–Rocker Cover
364	695693	Terminal–Oil Plug	643	696264	Retainer–Air Filter	1023	499924	Cover–Rocker Arm
365	699484	Screw (Carburetor)	689	691855	Spring–Friction	1026	693517	Rod–Push
383	19374	Wrench–Spark Plug	692	690572	Spring–Detent	1029	691230	Arm–Rocker
415	693463	Plug	718	690959	Pin–Locating	1034	691343	Guide–Push Rod
425	699208	Screw (Air Cleaner Cover)	741	695087	Gear–Timing	1052	698674	Sensor–Oil
455	692591	Cup–Flywheel	742	692564	Retainer–E Ring	1058	276057	Owner's Manual
456	692299	Plate–Pawl Friction	746	692566	Gear–Idler	1070	699201	Screw (Flywheel Fan)
459	281505	Pawl–Ratchet	799	699202	Screw (Oil Sensor)	1095	698215	Gasket Set–Valve
505	691251	Nut (Governor Control Lever)	830	694544	Stud–Rocker Arm (Muffler Guard)	1210	498144	Pulley/Spring Assembly (Pulley)
535	696263	Filter–Air Cleaner Foam	851	493880	Terminal–Spark Plug			
552	692346	Bushing–Governor Crank	868	★∅692044	Seal–Valve	1211	498144	Pulley/Spring Assembly (Spring)
562	691119	Bolt (Governor Control Lever)	914	699481	Screw (Rocker Cover) (Bottom)	1305	699691	Screw (Oil Sensor Module)
597	691696	Screw (Pawl Friction Plate)	914A	692557	Screw (Rocker Cover) (Top)	1330	272147	Repair Manual
			914B	697551	Screw (Rocker Cover) (Center)			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.