



# Illustrated Parts List

## Model Series

# 12X800

TYPE NUMBERS  
0015 through 0119.

### TABLE OF CONTENTS


Air Cleaner .....	4
Blower Housing/Shrouds .....	5
Camshaft .....	2
Carburetor .....	3
Controls .....	4
Crankshaft .....	2
Cylinder .....	2
Electrical .....	4
Engine Sump .....	2
Exhaust System .....	4
Flywheel .....	5
Flywheel Brake .....	4
Fuel Supply .....	4
Governor Spring .....	4
Ignition .....	4
Kits/Gaskets .....	2 & 3
Lubrication .....	2
Piston Group .....	2
Rewind Starter .....	5
Valves .....	2







PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

# 12X800




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 6336-2 Assemblies include all parts shown in frames. 09/28/2004








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 6336-3 Assemblies include all parts shown in frames. 09/28/2004



# 12X800



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 6336-4 Assemblies include all parts shown in frames. 09/28/2004



1036 EMISSION LABEL



# 12X800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
1	697322	Cylinder Assembly	22	691092	Screw (Crankcase Cover/Sump)	29	499424	Rod-Connecting (Standard)	
2	399269	Kit-Bushing/Seal (Magneto Side)				32	691664	Screw (Connecting Rod)	
3	★299819	Seal-Oil (Magneto Side)	23	692315	Flywheel (Rewind Start)	32A	695759	Screw (Connecting Rod (Used After Code Date 00042200).	
4	493279	Sump-Engine  <b>Note</b> 498983 Sump-Engine Used on Type No(s). 0119.	23A	691992	Flywheel (Electric Start)	33	262651	Valve-Exhaust	
4A	493365	Sump-Engine (Auxiliary PTO)	24	222698	Key-Flywheel	34	262652	Valve-Intake	
5	691160	Head-Cylinder	25	790359	Piston Assembly (Standard) (Used After Code Date 04031400).	35	691270	Spring-Valve (Intake)	
7	★Ø692249	Gasket-Cylinder Head			<b>Note</b> 499429 Piston Assembly (Standard) (Used Before Code Date 04031500).	36	691270	Spring-Valve (Exhaust)	
8	695250	Breather Assembly			499430 Piston Assembly (.010" Oversize)	37	694086	Guard-Flywheel	
9	★Ø272481	Gasket-Breather			499431 Piston Assembly (.020" Oversize)	40	692194	Retainer-Valve	
10	691125	Screw (Breather Assembly)			499432 Piston Assembly (.030" Oversize)	43	691997	Slinger-Governor/Oil	
11	691781	Tube-Breather			26	790360	Ring Set (Standard) (Used After Code Date 04031400).		
12	★692232	Gasket-Crankcase			<b>Note</b> 499425 Ring Set (Standard) (Used Before Code Date 04031500).	45	690548	Tappet-Valve	
13	690912	Screw (Cylinder Head)			499426 Ring Set (.010" Oversize)	46	691449	Camshaft	
15	691680	Plug-Oil Drain (Square Socket)			499427 Ring Set (.020" Oversize)	46A	691459	Camshaft (Counterclockwise)	
15A	691093	Plug-Oil Drain (Hex Socket)			499428 Ring Set (.030" Oversize)	50	497465	Manifold-Intake	
16	691451	Crankshaft  <b>Note</b> 691482 Crankshaft Used on Type No(s). 0119. 691454 Crankshaft Used on Type No(s). 0116, 0117. 691452 Crankshaft Used on Type No(s). 0115. 691450 Crankshaft Used on Type No(s). 0113.			27	691866	Lock-Piston Pin		
20	★399781	Seal-Oil (PTO Side)			28	499423	Pin-Piston (Standard)		
20A	★691952	Seal-Oil (PTO Side) (Auxiliary PTO)					54	691650	Screw (Intake Manifold)
							55	691421	Housing-Rewind Starter
							58	697316	Rope-Starter (Cut To Required Length)
							60	281434	Grip-Starter Rope
							65	690837	Screw (Rewind Starter)
							78	691108	Screw (Flywheel Guard)
							81	691740	Lock-Muffler Screw
							83	691778	Shaft-Auxiliary Drive
							95	691636	Screw (Throttle Valve)
							97	493267	Shaft-Throttle
							101	691623	Pin-Shaft
							104	●691242	Pin-Float Hinge
							108	691182	Valve-Choke
							109A	498593	Shaft-Choke

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117	494870	Jet—Main (Standard)	227	690783	Lever—Governor Control	333	802574	Armature—Magneto
117A	498978	Jet—Main (Standard)	236	691826	Link—Lockout	334	691061	Screw (Magneto Armature)
118	497315	Jet—Main (High Altitude)	265	690798	Clamp—Casing	337	802592	Plug—Spark (Resistor)
118A	498975	Jet—Main (High Altitude)	267	691044	Screw (Casing Clamp)	<b>Note</b> _____		
121	498260	Kit—Carburetor Overhaul	268	691072	Casing—Control Wire (48" Long) (Cut To Required Length)	697451	Plug—Spark (EMS)	
125	694882	Carburetor	<b>Note</b> _____		347	691396	Switch—Rocker	
125A	499059	Carburetor	691025	Casing— Control Wire (72" Long) (Cut To Required Length)	356	692390	Wire—Stop	
127	694468	Plug—Welch	269	691589	Wire—Control (54" Long) (Cut To Required Length)	356B	693010	Wire—Stop
130	691203	Valve—Throttle	<b>Note</b> _____		358	497316	Gasket Set—Engine	
133	398187	Float—Carburetor	691026	Wire—Control (78" Long) (Cut To Required Length)	363	19069	Puller—Flywheel	
134	398188	Kit—Needle/Seat	270	691027	Nut (Control Wire Casing)	365	692524	Screw (Carburetor)
137	693981	Gasket—Float Bowl	271	691028	Lever—Control	374	691074	Washer (Camshaft)
146	690979	Key—Timing	276	271716	Washer—Sealing	383	89838	Wrench—Spark Plug
159	691753	Bracket—Air Cleaner Primer	287	690940	Screw (Dipstick Tube)	404	690272	Washer (Governor Crank)
163	272653	Gasket—Air Cleaner	300B	694048	Muffler (Super Lo Tone Catalyst)	425A	690670	Screw (Air Cleaner Cover)
187	691050	Line—Fuel (Cut To Required Length)	304	694092	Housing—Blower <b>Note</b> _____	443A	692523	Screw (Air Cleaner Primer Base)
188	690877	Screw (Control Bracket)	694879	Housing— Blower Used on Type No(s). 0113, 0119.	445A	491588	Filter—Air Cleaner Cartridge	
190	690940	Screw (Fuel Tank)	305	691108	Screw (Blower Housing)	455	695161	Cup—Flywheel
202	691829	Link—Mechanical Governor	306	690450	Shield—Cylinder	456	692299	Plate—Pawl Friction
209	690241	Spring—Governor Used on Type No(s). 0119.	307	690345	Screw (Cylinder Shield)	459	281505	Pawl—Ratchet
209B	691292	Spring—Governor <b>Note</b> _____	332	690662	Nut (Flywheel)	497	690664	Screw (Stopswitch Bracket)
		691851 Spring— Governor Used on Type No(s). 0113.	<b>Note</b> _____		505	691251	Nut (Governor Control Lever)	
222	692031	Bracket—Control (Remote/Manual Friction) (Primer)	<b>Note</b> _____		523	495264	Dipstick	
222E	692982	Bracket—Control (Fixed Speed and 5 Position Manual Choke)	<b>Note</b> _____		524	692296	Seal—Dipstick Tube	
			<b>Note</b> _____		525	495265	Tube—Dipstick	
			<b>Note</b> _____		529	691923	Grommet	
			<b>Note</b> _____		562	92613	Bolt (Governor Control Lever)	
			<b>Note</b> _____		578	398153	Wire Assembly	
			<b>Note</b> _____		584	697734	Cover—Breather Passage	
			<b>Note</b> _____		585	691879	Gasket—Breather Passage	

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

⊘ Included in Valve Gasket Set—Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 12X800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
592	690800	Nut (Rewind Starter)	743	691772	Gear–Drive (Counterclockwise)	967A	493537	Filter–Pre Cleaner
597	691696	Screw (Pawl Friction Plate)	745	691648	Screw (Brake)	968B	692298	Cover–Air Cleaner
601	95162	Clamp–Hose (Green)	832B	497683	Guard–Muffler (Used with Super Lo Tone Catalyst Muffler)	969A	691138	Screw (Blower Housing Cover)
608	497680	Starter–Rewind	836	690664	Screw (Muffler Guard)	970	691669	Screw (Air Cleaner Primer Bracket)
613B	691114	Screw (Muffler)	836B	691147	Screw (Muffler Guard)	972B	693377	Tank–Fuel (Plastic)
615	690340	Retainer–Governor Shaft	842	★691031	Seal–O Ring (Dipstick Tube)	975	493640	Bowl–Float
616	698801	Crank–Governor	843	691884	Lever–Sleeve (Speed Control)	976	694395	Primer–Carburetor
617	◆691321	Seal–O Ring (Intake Manifold)	843A	691895	Lever–Sleeve (Choke)	977	498261	Gasket Set–Carburetor
621	692310	Switch–Stop	847	692017	Dipstick/Tube Assembly	1005	691346	Fan–Flywheel
627	692872	Bracket–Stopswitch	851	493880	Terminal–Spark Plug	1019	494256	Kit–Label
633	◆691321	Seal–Choke/Throttle Shaft (Throttle Shaft)	869	691155	Seat–Valve (Intake)	1036	790412	Label–Emission (Used After Code Date 04063000).
633A	◆693867	Seal–Choke/Throttle Shaft (Choke Shaft)	870	690380	Seat–Valve (Exhaust)	————— <b>Note</b> —————		
635	66538	Boot–Spark Plug	871	262001	Guide–Valve Bushing (Exhaust Valve)	695111	Label– Emission (Used After Code Date 99093000 and Before Code Date 04070100).	
668	★493823	Spacer (Includes 2)	————— <b>Note</b> —————		63709	Label– Emission (Used Before Code Date 99100100).		
670	692294	Spacer–Fuel Tank	883	★∅691881	Gasket–Exhaust	1058	275177	Manual–Owner’s
676	356548	Deflector–Muffler (Single Louver)	921C	694889	Cover–Blower Housing (Static Guard) (Satin Black)	1059	692311	Kit–Screw/Washer
677	690661	Screw (Muffler Deflector)	922	691831	Spring–Brake	1095	498528	Gasket Set–Valve
684	690345	Screw (Breather Passage Cover)	923	691994	Brake	1102	691255	Pilot–Guide
689	691855	Spring–Friction	957	397974	Cap–Fuel Tank (Plastic)	1210	498144	Pulley/Spring Assembly (Pulley)
715	691147	Screw (Stop Shaft)	966A	496116	Base–Air Cleaner Primer	1211	498144	Pulley/Spring Assembly (Spring)
718	690959	Pin–Locking			1330	270962	Manual–Repair	
721	690449	Stop–Shaft						
741	790345	Gear–Timing (Use Without Woodruff Key)						
		————— <b>Note</b> —————						
		691830 Gear–Timing (Uses Woodruff Key)						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

6336–8

Assemblies include all parts shown in frames.

09/28/2004