



Illustrated Parts List

Model Series

12Z800

TYPE NUMBERS
0100.

TABLE OF CONTENTS


Air Cleaner	4
Blower Housing/Shrouds	5
Cams	2
Carburetor	3
Controls	4
Crankshaft	2
Cylinder Group	2
Electrical	4
Engine Sump	2
Exhaust System	4
Flywheel	5
Fuel Supply	3
Governor Spring	4
Ignition	4
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewind Starter	5
Valves	2

PRINTED IN U.S.A.













COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12Z800






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6745-2 Assemblies include all parts shown in frames. 09/28/2004





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6745-4 Assemblies include all parts shown in frames. 09/28/2004



12Z800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697322	Cylinder Assembly	26	790360	Ring Set (Standard) (Used After Code Date 04031400).	95	691636	Screw (Throttle Valve)
2	399269	Kit-Bushing/Seal (Magneto Side)				97	696565	Shaft-Throttle
3	★299819	Seal-Oil (Magneto Side)				104	●691242	Pin-Float Hinge
4	493279	Sump-Engine				117	498978	Jet-Main (Standard)
5	691160	Head-Cylinder				118	497466	Jet-Main (High Altitude)
7	★∅692249	Gasket-Cylinder Head				121	498260	Kit-Carburetor Overhaul
8	695250	Breather Assembly				125	498170	Carburetor
9	★∅272481	Gasket-Breather				127	●694468	Plug-Welch (3/8" Diameter)
10	691125	Screw (Breather Assembly)				130	696564	Valve-Throttle
11	691781	Tube-Breather				133	398187	Float-Carburetor
12	★692232	Gasket-Crankcase				134	●398188	Kit-Needle/Seat
13	690912	Screw (Cylinder Head)	27	691866	Lock-Piston Pin	137	●●693981	Gasket-Float Bowl
15	691680	Plug-Oil Drain (Square Socket)	28	499423	Pin-Piston (Standard)	146	690979	Key-Timing
16	691451	Crankshaft	29	499424	Rod-Connecting (Standard)	159	691753	Bracket-Air Cleaner Primer
20	★399781	Seal-Oil (PTO Side)	32	691664	Screw (Connecting Rod)	163	★●●272653	Gasket-Air Cleaner
22	691092	Screw (Crankcase Cover/Sump)	32A	695759	Screw (Connecting Rod)	187	691050	Line-Fuel (Cut to Required Length)
23A	691992	Flywheel	33	262651	Valve-Exhaust	188	690877	Screw (Control Bracket)
24	222698	Key-Flywheel	34	262652	Valve-Intake	190	690940	Screw (Fuel Tank)
25	790359	Piston Assembly (Standard) (Used After Code Date 04031400).	35	691270	Spring-Valve (Intake)	202	691829	Link-Mechanical Governor
		Note	36	691270	Spring-Valve (Exhaust)	209B	691291	Spring-Governor (Red)
		499429 Piston Assembly (Standard) (Used Before Code Date 04031500).	37	694086	Guard-Flywheel	222	692031	Bracket-Control (Remote/Manual Friction) (Primer)
		499430 Piston Assembly (.010" Oversize)	40	692194	Retainer-Valve	227	690783	Lever-Governor Control
		499431 Piston Assembly (.020" Oversize)	43	691997	Slinger-Governor/Oil	265	690798	Clamp-Casing
		499432 Piston Assembly (.030" Oversize)	45	690548	Tappet-Valve	267	691044	Screw (Casing Clamp)
			46	691449	Camshaft	268	691025	Casing-Control Wire (Cut to Required Length)
			50	497465	Manifold-Intake	269	691026	Wire-Control (Cut to Required Length)
			51	★272199	Gasket-Intake	270	691027	Nut (Control Wire Casing)
			54	691650	Screw (Intake Manifold)	271	691028	Lever-Control
			55	691421	Housing-Rewind Starter	276	●●271716	Washer-Sealing
			58	697316	Rope-Starter (Cut To Required Length)			
			60	281434	Grip-Starter Rope			
			65	690837	Screw (Rewind Starter)			
			73	691222	Screen-Rotating			
			78	691108	Screw (Flywheel Guard)			
			81	691740	Lock-Muffler Screw			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

6745-6

Assemblies include all parts shown in frames.

09/28/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
287	690940	Screw (Dipstick Tube)	584	697734	Cover-Breather Passage	870	690380	Seat-Valve (Exhaust)
300	692038	Muffler (Tuned)	585	★691879	Gasket-Breather Passage	871	262001	Bushing-Valve Guide (Exhaust)
304A	696307	Housing-Blower	592	690800	Nut (Rewind Starter)	————— Note —————		
305	691108	Screw (Blower Housing)	597	691696	Screw (Pawl Friction Plate)	63709		Bushing-Valve- Guide (Intake)
306	690450	Shield-Cylinder	601	95162	Clamp-Hose (Green)	883	★∅691881	Gasket-Exhaust
307	690345	Screw (Cylinder Shield)	604	691757	Cover-Control	949	696306	Guard-Debris Screen
332	690662	Nut (Flywheel)	608	497680	Starter-Rewind	957	397974	Cap-Fuel Tank (Plastic)
333	802574	Armature-Magneto	613	691340	Screw (Muffler)	966A	496116	Base-Air Cleaner Primer
334	691061	Screw (Magneto Armature)	615	690340	Retainer-Governor Shaft	967A	493537	Filter-Pre Cleaner
337	802592	Plug-Spark	616	698801	Crank-Governor	968B	692298	Cover-Air Cleaner
356	692390	Wire-Stop	617	★◆270344	Seal-O Ring (Intake Manifold)	970	691681	Screw (Air Cleaner Primer Bracket)
358	497316	Gasket Set-Engine	621	692310	Switch-Stop	972B	693377	Tank-Fuel (Plastic)
363	19069	Puller-Flywheel	633	◆691321	Seal-Choke/Throttle Shaft	975	493640	Bowl-Float
365	692524	Screw (Carburetor)	635	66538	Boot-Spark Plug	976	694395	Primer-Carburetor
383	89838	Wrench-Spark Plug	668	★493823	Spacer (Includes 2)	977	498261	Gasket Set-Carburetor
404	690272	Washer (Governor Crank)	670	692294	Spacer-Fuel Tank	997	696310	Shield-Debris
425A	690670	Screw (Air Cleaner Cover)	684	690345	Screw (Breather Passage Cover)	1005	691346	Fan-Flywheel
443A	692523	Screw (Air Cleaner Primer Base)	689	691855	Spring-Friction	1019	696438	Kit-Label
445A	491588	Filter-Air Cleaner Cartridge	703	696309	Clip	1036	790412	Label-Emission (Used After Code Date 04063000).
455	695161	Cup-Flywheel	718	690959	Pin-Locating	————— Note —————		
456	692299	Plate-Pawl Friction	741	790345	Gear-Timing (Use Without Woodruff Key)	695111		Label- Emission (Used After Code Date 04063000).
459	281505	Plate-Ratchet	————— Note —————		691830		Gear-Timing (Uses Woodruff Key)	
505	691251	Nut (Governor Control Lever)	842	★691031	Seal-O Ring (Dipstick Tube)	1058	274978	Manual-Owner's
523	495264	Dipstick	843	691884	Sleeve-Lever (Control Bracket)	1059	692311	Kit-Screw/Washer
524	★692296	Seal-Dipstick Tube	847	692017	Dipstick/Tube Assembly	1095	498528	Gasket Set-Valve
525	495265	Tube-Dipstick	851	493880	Terminal-Spark Plug	1210	498144	Pulley/Spring Assembly (Pulley)
529	691923	Grommet	869	691155	Seat-Valve (Intake)	1211	498144	Pulley/Spring Assembly (Spring)
562	92613	Bolt (Governor Control Lever)			1229	696308	Extension-Blower Housing	
563	691138	Screw (Debris Guard Screen)			1330	270962	Manual-Repair	
564	690664	Screw (Control Cover)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.