

212400

Illustrated Parts List

Model Series

212400

TYPE NUMBERS
0100.


TABLE OF CONTENTS

Air Cleaner	5
Blower Housing/Shrouds	7
Cams	2
Carburetor #1	4
Controls	7
Crankcase Cover/Sump	2
Crankshaft	2
Cylinder	2
Flywheel	6
Fuel Tank	8
Governor Spring	7
Head/Valves	3
Kit/Gasket Sets-Carburetor	4
Kit/Gasket Sets-Engine	2
Kit/Gasket Sets-Valve	3
Muffler	5
Oil	2
Piston Group	2
Rewind	6



PRINTED IN U.S.A.







COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.







Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
 5854-3 Assemblies include all parts shown in frames.







Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.










Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

1036 EMISSION LABEL



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.







5854-7 *Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.*

Assemblies include all parts shown in frames.

4/30/2004

212400



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

5854-8

Assemblies include all parts shown in frames.

4/30/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	790038	Cylinder Assembly	33	499596	Valve-Exhaust	130A	696139	Valve-Throttle
2	698340	Kit-Bushing/Seal (Magneto Side)	34	697464	Valve-Intake	133A	694914	Float-Carburetor
3	★391086	Seal-Oil (Magneto Side)	35	694865	Spring-Valve (Intake)	135	696142	Tube-Fuel Transfer
5	697233	Head-Cylinder	36	694865	Spring-Valve (Exhaust)	137A	◆●695426	Gasket-Float Bowl
7	★△697690	Gasket-Cylinder Head	40	499586	Retainer-Valve	141B	696145	Kit-Choke Shaft
11C	696796	Tube-Breather	42	499586	Keeper-Valve	146	690979	Key-Timing
12	★694953	Gasket-Crankcase	45	690977	Tappet-Valve	161	695384	Base-Air Cleaner (Metal)
13	690360	Screw (Cylinder Head)	46	790040	Camshaft	163	★◆●692277	Gasket-Air Cleaner
15	691686	Plug-Oil Drain	51	●△◆●694874	Gasket-Intake	176	★◆●691917	Seal-O Ring (Air Cleaner Base)
16	695369	Crankshaft	51A	●△◆●694875	Gasket-Intake	187	691050	Line-Fuel (Cut To Required Length)
18	696914	Cover-Crankcase	53	694869	Stud (Carburetor)	187A	695429	Line-Fuel
19	698340	Kit-Bushing/Seal (PTO Side)	55	695288	Housing-Rewind Starter	188	690877	Screw (Control Bracket)
20	★391086	Seal-Oil (PTO Side)	58	693389	Rope-Starter	190	692127	Screw (Fuel Tank)
21	281658	Cap-Oil Fill	59	805957	Insert-Grip	192	690083	Adjuster Rocker Arm
22	695174	Screw (Crankcase Cover/Sump)	60	490652	Grip-Starter Rope	209	694867	Spring-Governor
23	694954	Flywheel	65	690837	Screw (Rewind Starter)	211	695307	Spring-Governed Idle
24	222698	Key-Flywheel	81	695400	Lock-Muffler Screw	212B	695917	Link-Throttle (Use With Nikki Carburetor)
25	790041	Piston Assembly (.020" Oversize)	95A	690718	Screw (Throttle Valve)	219	693578	Gear-Governor
		----- Note -----	97A	696387	Shaft-Throttle	220	691724	Washer (Governor Gear)
		697698 Piston Assembly (Standard)	98A	●695408	Kit-Idle Speed	222	695380	Bracket-Control
26	697692	Ring Set (Standard)	104A	●694918	Pin-Float Hinge	227	694864	Lever-Governor Control
		----- Note -----	105A	●696136	Valve-Float Needle	231	691636	Screw (Choke Valve)
		697698 Ring Set (.020" Undersize)	108A	696143	Valve-Choke	265	691024	Clamp-Casing
27	690975	Lock-Piston Pin	109B	696145	Shaft-Choke	267	692577	Screw (Casing Clamp)
28	696581	Pin-Piston	117	●696134	Jet-Main (Standard)	268	691025	Casing-Control Wire
29	694691	Rod-Connecting	118	696135	Jet-Main (High Altitude)	269	691026	Wire-Control
30	694692	Dipper-Connecting Rod	121A	696146	Kit-Carburetor Overhaul (Nikki)	270	691027	Nut (Control Wire Casing)
32	690976	Screw (Connecting Rod)	122	△◆●694876	Spacer-Carburetor	271	691028	Lever-Control
			125B	695919	Carburetor	271A	695381	Lever-Control
			127A	690727	Plug-Welch			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

212400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
281	697268	Panel - Control	597	691696	Screw (Pawl Friction Plate)	958	698180	Valve - Fuel Shut Off (Plastic)
300	697252	Muffler	601	95162	Clamp - Hose	967	491435	Filter - Pre Cleaner
304	697250	Housing - Blower (Black)	608	695287	Starter - Rewind	968A	697061	Cover - Air Cleaner
305	691108	Screw (Blower Housing)	613	695312	Screw (Muffler)	971	695181	Screw (Air Cleaner Base to Carburetor)
306	697240	Shield - Cylinder	613A	695399	Screw (Muffler)	972	694260	Tank - Fuel (Plastic)
307	691660	Screw (Cylinder Shield)	615	694676	Retainer - Governor Shaft	975A	696138	Bowl - Float
332	694685	Nut (Flywheel)	616	694675	Crank - Governor	977A	696147	Gasket Set - Carburetor (Use With Nikki Carburetor)
333	715231	Armature - Magneto	621	692310	Switch - Stop	1005	694684	Fan - Flywheel
334	691061	Screw (Magneto Armature)	633B	◆690998	Seal - Choke/Throttle Shaft	1019	790142	Kit - Label
337	491055	Plug - Spark	635	710901	Boot - Spark Plug	1022	*Δ690971	Gasket - Rocker Cover
356A	692390	Wire - Stop	663B	692577	Screw (Control Panel)	1023	697691	Cover - Rocker
358	695438	Gasket Set - Engine	668	694257	Spacer (Control Bracket)	1026	695177	Rod - Push
369	695422	Spring - Float Bowl	689	691855	Spring - Friction	1029	690972	Arm - Rocker
383	19374	Wrench - Spark Plug	718	690959	Pin - Locating	1036	274020	Label - Emissions
410	695382	Link - Control	741	691288	Gear - Timing	1058	275092	Manual - Owner's
415	691363	Plug	742	692564	Retainer - E Ring	1070	690364	Screw (Flywheel Fan)
425	790043	Screw (Air Cleaner Cover)	746	694679	Gear - Idler	1095	695440	Gasket Set - Valve
445	491588	Filter - Air Cleaner Cartridge	773	694258	Retainer	1100	690973	Pivot - Rocker Arm
455	694683	Cup - Flywheel	798	697890	Screw (Rocker Arm)	1127A	695407	Screw (Float Bowl)
456	692299	Plate - Pawl Friction	868	*Δ690968	Seal - Valve	1138	694255	Nut (Control Bracket)
459	281505	Pawl - Ratchet	883	*Δ697255	Gasket - Exhaust	1210	498144	Pulley/Spring Assembly
504	695383	Washer Set - Friction	914	693732	Screw (Rocker Cover)	1330	272147	Repair Manual
552	694674	Bushing - Governor Crank	957	694261	Cap - Fuel Tank (Plastic)			
592	690800	Nut (Rewind Starter)						

★ Included in Engine Gasket Set - Ref. No. 358.

● Included in Carburetor Overhaul Kit - Ref. No. 121.

◆ Included in Carburetor Gasket Set - Ref. No. 977.

Δ Included in Valve Gasket Set - Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.