



Illustrated Parts List

Model Series

217800

TYPE NUMBER
0111Through 0393.


TABLE OF CONTENTS

Air Cleaner	6
Alternator	9
Blower Housing	6
Camshaft	3
Carburetor	5
Controls	8
Engine Sump	2
Crankshaft	3
Cylinder	2
Cylinder Head	4
Electric Starter	7
Exhaust System	6
Flywheel	7
Fuel System	8
Gasket Set – Engine	4
Gasket Set – Valve	4
Ignition	8
Intake Manifold	4
Kit – Carburetor Overhaul	5
Lubrication	3
Piston, Rings, Connecting Rod	3
Valves	4

PRINTED IN U.S.A.






COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.










1019 LABEL KIT

1058 OWNER'S MANUAL




1330 REPAIR MANUAL









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5498-2 Assemblies include all parts shown in frames. 12/16/2004





5498-3 *Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.* Assemblies include all parts shown in frames. 12/16/2004








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5498-4 Assemblies include all parts shown in frames. 12/16/2004








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5498-5 Assemblies include all parts shown in frames. 12/16/2004






305A
305





823















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5498-6 Assemblies include all parts shown in frames.







729A
697




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5498-7 Assemblies include all parts shown in frames. 12/16/2004



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5498-8 Assemblies include all parts shown in frames.

DC ONLY	DUAL CIRCUIT
474A 877A 	474B 877 
578 	878 

NOTE: All stators use a No. 1119 mounting screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.

217800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION			
1	697377	Cylinder Assembly	24	222698	Key-Flywheel	42	499586	Keeper-Valve			
2	399265	Kit-Bushing/Seal (Magneto Side)	25	698767	Piston Assembly (Standard)	43	691968	Slinger-Governor/Oil			
3	★391086	Seal-Oil (Magneto Side)			Used on Type No(s). 0111, 0117, 0381.	45	690564	Tappet-Valve			
4	697106	Sump-Engine Used on Type No(s). 0113, 0114, 0115, 0117, 0118, 0381, 0393.			Note	46	790390	Camshaft Used on Type No(s). 0113, 0114, 0115, 0117, 0118, 0381, 0393.			
4A	697188	Sump-Engine Used on Type No(s). 0111.			698769 Piston Assembly (.020" Oversize) Used on Type No(s). 0111, 0117, 0381.			Note			
5	697396	Head-Cylinder			698371 Piston Assembly (Standard)	50	697361	Manifold-Intake			
7	★△273280	Gasket-Cylinder Head			Used on Type No(s). 0113, 0114, 0115, 0118, 0393.	51★△◆692137		Gasket-Intake			
9	★697109	Gasket-Breather			698394 Piston Assembly (.020" Oversize) Used on Type No(s). 0113, 0114, 0115, 0118, 0393.	53	690227	Stud (Carburetor)			
10	697157	Screw (Breather Assembly)			26	698375		Ring Set (Standard)			
11	697113	Tube-Breather			Note			697384			
12	★697110	Gasket-Crankcase (.015" Thick)(Standard)			698376 Ring Set (.010" Oversize)			Screen-Rotating (Used Before Code Date 03031700)			
13	690360	Screw (Cylinder Head)			698377 Ring Set (.020" Oversize)			74	697897	Screw (Rotating Screen)	
14	790560	Stud (Cylinder Head) Used on Type No(s). 0114, 0115, 0117, 0118.			698378 Ring Set (.030" Oversize)			78	691003	Screw (Flywheel Guard)	
15	690946	Plug-Oil Drain (Square Head)			27	698469		Lock-Piston Pin	78A	690364	Screw (Flywheel Guard)
16	698382	Crankshaft Used on Type No(s). 0111, 0117, 0381.			28	697099		Pin-Piston	81	691178	Lock-Muffler Screw
		Note			29	697364		Rod-Connecting (Standard)	93	◆690602	Bushing-Throttle Shaft
		697390 Crankshaft Used on Type No(s). 0113, 0114, 0115, 0118, 0393.			Note			697262 Rod-Connecting (.020" Undersize)	94	498030	Kit-Idle Mixture
20	★690947	Seal-Oil (PTO Side)			32	692852		Screw (Connecting Rod)	94A	695425	Kit-Idle Mixture
22	692125	Screw (Crankcase Cover/Sump)			33	695760		Valve-Exhaust	95	◆691636	Screw (Throttle Valve)
23	698281	Flywheel Used on Type No(s). 0118, 0381, 0393.			34	695761		Valve-Intake	95A	◆690718	Screw (Throttle Valve)
		Note			35	691279		Spring-Valve (Intake)			
		698283 Flywheel Used on Type No(s). 0113, 0114, 0115, 0117.			36	691279		Spring-Valve (Exhaust)			
		790922 Flywheel (Painted Flywheel) Used on Type No(s). 0111.			37	697352		Guard-Flywheel			
					37A	697626		Guard-Flywheel Used on Type No(s). 0113, 0114, 0115, 0117.			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
98	495800	Kit-Idle Speed	127	●694524	Plug-Welch	216	691840	Link-Choke
98A	695408	Kit-Idle Speed	127A	●690727	Plug-Welch	222	694042	Bracket-Control
104	●690525	Pin-Float Hinge	130	790024	Valve-Throttle	227	691374	Lever-Governor Control
104A	●694918	Pin-Float Hinge			Used on Type No(s). 0111.	231	691636	Screw (Choke Valve)
105	●231855	Valve-Float Needle	130A	698774	Valve-Throttle	232	691842	Spring-Governor Link
105A	●696136	Valve-Float Needle	131	494885	Kit-Throttle Shaft	237	690409	Retainer-Muffler Guard
106	●690577	Seat-Inlet (Gravity Feed)	131A	698776	Kit-Throttle Shaft			Used on Type No(s). 0114, 0117.
		———— Note ————	133	494381	Float-Carburetor			Used on Type No(s). 0114, 0117.
		●691780 Seat-Inlet (Pump Feed)	133A	694914	Float-Carburetor	238	691843	Cap-Valve
108	691227	Valve-Choke	135A	790030	Tube-Fuel Transfer	240	394358	Filter-Fuel (White, 75 Microns)
108A	698773	Valve-Choke	137	◆281165	Gasket-Float Bowl			Used on Type No(s). 0113, 0381.
117	●699897	Jet-Main (Standard)	137A	◆698781	Gasket-Float Bowl			———— Note ————
118	699898	Jet-Main (High Altitude)	141	790902	Kit-Choke Shaft			298090 Filter-Fuel (Red, 150 Microns)
121	790031	Kit-Carburetor Overhaul (Walbro)	141A	698778	Kit-Choke Shaft			Used on Type No(s). 0393.
121A	698787	Kit-Carburetor Overhaul (Nikki)	142	●790025	Nozzle-Carburetor (Standard)	240B	691035	Filter-Fuel (Includes Paper Element With A 40 Micron Rating)
125	790019	Carburetor (Walbro) (Gravity Feed)	143	790028	Nozzle-Carburetor (High Altitude)			Used on Type No(s). 0111, 0114, 0115, 0117, 0118.
		Used on Type No(s). 0113, 0381, 0393.	146	691639	Key-Timing	261	697176	Screw (Control Slide)
		———— Note ————	186	698174	Connector-Hose (Straight)	263	691083	Screw (Muffler Guard Retainer)
		790020 Carburetor (Walbro)(Pump Feed)	187	699331	Line-Fuel (Formed)(Cut To Required Length)	265	691024	Clamp-Casing
		Used on Type No(s). 0111.	188	691693	Screw (Control Bracket)	267	690804	Screw (Casing Clamp)
		790021 Carburetor (Walbro)(Pump Feed)	190	790931	Screw (Fuel Tank)	276	◆692255	Washer-Sealing
		Used on Type No(s). 0114.	192	691986	Adjuster-Rocker Arm	300	697048	Muffler
		———— Note ————	202	691841	Link-Mechanical Governor			Used on Type No(s). 0111, 0114, 0115, 0117.
		790020 Carburetor (Walbro)(Pump Feed)	209	691798	Spring-Governor	300A	697349	Muffler
		Used on Type No(s). 0111.			Used on Type No(s). 0111, 0113, 0114, 0118.			Used on Type No(s). 0118.
		790021 Carburetor (Walbro)(Pump Feed)			———— Note ————			
		Used on Type No(s). 0114.			690480 Spring-Governor			
		0114.			Used on Type No(s). 0115, 0393.			
		———— Note ————			691278 Spring-Governor			
		790020 Carburetor (Walbro)(Pump Feed)			Used on Type No(s). 0117.			
		Used on Type No(s). 0111.			265902 Spring-Governor			
		790021 Carburetor (Walbro)(Pump Feed)			Used on Type No(s). 0381.			
		Used on Type No(s). 0114.						
125A	791266	Carburetor (Nikki)(Pump Feed)						
		Used on Type No(s). 0115, 0117.						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

217800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
304	698473	Housing-Blower (Black) Used on Type No(s). 0113, 0114, 0115, 0117, 0118.	387	697090	Pump-Fuel (Includes Mounting Bracket) Used on Type No(s). 0111, 0114, 0115, 0117, 0118.	507	691972	Insulator
		————— Note —————	387A	808656	Pump-Fuel Used on Type No(s). 0111, 0114, 0115, 0117, 0118.	510	693699	Drive-Starter
		699085 Housing- Blower (Red) Used on Type No(s). 0111, 0381.	404	691691	Washer (Governor Crank)	513	692024	Clutch-Drive
305	697102	Screw (Blower Housing)	415	690283	Plug (Sump) Used on Type No(s). 0111.	520	691084	Terminal-Ground
305A	697103	Screw (Blower Housing)				521	690581	Shield-Cable
306	697359	Shield-Cylinder	431	697122	Elbow-Intake	523	699908	Dipstick
307	691003	Screw (Cylinder Shield)	431A	698937	Elbow-Intake Used on Type No(s). 0393.	524	★691032	Seal-Dipstick Tube
309	693551	Motor-Starter Used on Type No(s). 0111, 0118, 0381, 0393.	445	698413	Filter-Air Cleaner Cartridge (Non Washable)	525	697085	Tube-Dipstick Used on Type No(s). 0111, 0114, 0115, 0117, 0118.
310	690323	Screw (Starter Motor)	455	695113	Cup-Flywheel Used on Type No(s). 0113, 0114, 0115, 0117.			————— Note —————
311	497608	Brush Set	456	695128	Plate-Pawl Friction	697184	Tube-Dipstick Used on Type No(s). 0113, 0381, 0393.	
333	492341	Armature-Magneto	459	281505	Pawl-Ratchet	536	698973	Cleaner-Air Used on Type No(s). 0393.
334	691061	Screw (Magneto Armature)	474A	696578	Alternator (DC Only) Used on Type No(s). 0118, 0393.	544	692034	Armature-Starter
337	491055	Plug-Spark Used on Type No(s). 0113, 0114, 0115, 0117, 0118.	474B	696459	Alternator (Dual Circuit) Used on Type No(s). 0111, 0381.	552	697144	Bushing-Governor Crank
		————— Note —————	505	691251	Nut (Governor Control Lever)	559	697561	Screw (Remote Choke Stop)
		691043 Plug-Spark Used on Type No(s). 0111, 0381, 0393.				562	691119	Bolt (Governor Control Lever)
356	697397	Wire-Stop Used on Type No(s). 0111, 0118, 0393.				578	692306	Wire Assembly Used on Type No(s). 0118, 0393.
356A	398808	Wire-Stop Used on Type No(s). 0113, 0114, 0115, 0117.				579	691029	Nut (Starter Cable)
358	697151	Gasket Set-Engine				584	697112	Cover-Breather Passage
359	691077	Washer (Ground Terminal)				597	691696	Screw (Pawl Friction Plate)
363	19203	Puller-Flywheel				601	95162	Clamp-Hose (Zinc Plate)(Spring Wire)
373	691612	Nut (Ground Terminal)				601A	691038	Clamp-Hose (Black)(Spring Steel)
383	89838	Wrench-Spark Plug				608	695058	Starter-Rewind Used on Type No(s). 0113, 0114, 0115, 0117.
385	694476	Screw (Fuel Pump)				613	691416	Screw (Muffler)
385A	690297	Screw (Fuel Pump)				613A	691678	Screw (Muffler)
						613B	690297	Screw (Muffler)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
614	691620	Pin-Cotter	801	691283	Cap-Drive	957	694261	Cap-Fuel Tank (Plastic)		
616	692012	Crank-Governor	802	691286	Cap-End	958	698183	Valve-Fuel Shut Off (Plastic)		
617	★692138	Seal-O Ring (Intake Manifold)	803	693757	Housing-Starter			Used on Type No(s). 0111.		
621	692310	Switch-Stop	823	698941	Screw (Muffler Adapter)	965	499613	Cover-Oil Pump Used on Type No(s). 0111.		
634	●690802	Spring/Seal Assembly	830	691095	Stud-Rocker Arm	967	697292	Filter-Pre Cleaner		
634A	●698779	Spring/Seal Assembly	832	692361	Guard-Muffler Used on Type No(s). 0114, 0117.	968	697420	Cover-Air Cleaner (Black)		
635	691909	Boot-Spark Plug	836	690367	Screw (Muffler Guard)			Note		
643	697155	Retainer-Air Filter	842	★691031	Seal-O Ring (Dipstick Tube)			697422 Cover-Air Cleaner (Red)		
654	690958	Nut (Carburetor)	843	697158	Sleeve-Lever	972	699710	Tank-Fuel (Plastic) Used on Type No(s). 0114, 0115, 0117, 0118.		
676	393761	Deflector-Muffler (Side Out) Used on Type No(s). 0114, 0117.	847	790443	Dipstick/Tube Assembly Used on Type No(s). 0111, 0114, 0115, 0117, 0118.	975	495933	Bowl-Float		
676A	396903	Deflector-Muffler (Direct Out) Used on Type No(s). 0111.			Note	975A	698783	Bowl-Float		
677	690661	Screw (Muffler Deflector)			790442 Dipstick/Tube Assembly Used on Type No(s). 0113, 0381, 0393.	977	690192	Gasket Set-Carburetor (Walbro)		
687	697175	Slide-Control	851	692424	Terminal-Spark Plug	977A	790032	Gasket Set-Carburetor (Nikki)		
688	690395	Cap-Friction	864	697346	Adapter-Muffler Used on Type No(s). 0111, 0114, 0115, 0117, 0118.	987	●691326	Seal-Throttle Shaft		
689	691855	Spring-Friction	868	★Δ690968	Seal-Valve	987A	●698777	Seal-Throttle Shaft		
689A	690529	Spring-Friction	877	393456	Wire/Connector-Alternator (Dual Circuit) Used on Type No(s). 0111, 0381.	1005	699044	Fan-Flywheel		
691	★692407	Seal-Governor Shaft	877A	393814	Wire/Connector-Alternator (DC Only) Used on Type No(s). 0118, 0393.	1017	690770	Screen-Oil Pump Used on Type No(s). 0111.		
692	691301	Spring-Detent			878	691237	Harness-Alternator Used on Type No(s). 0111, 0381.	1019	699196	Kit-Label
697	690372	Screw (Drive Cap)	883	★692236	Gasket-Exhaust	1022	★Δ272475	Gasket-Rocker Cover		
705	790561	Nut (Fuel Tank)	914	691108	Screw (Rocker Cover)	1023	692492	Cover-Rocker		
718	690959	Pin-Locating	918	697091	Hose-Vacuum (Molded)	1024	499054	Pump-Oil Used on Type No(s). 0111.		
729	691335	Clip-Wire (Wire Retainer)	943	★690589	Seal-O Ring (Oil Pump Cover)	1026	697395	Rod-Push (Exhaust)		
729A	691224	Clip-Wire (Starter Motor)	950	691657	Screw-Float Bowl (Bottom Of Bowl)			Note		
741	697128	Gear-Timing			883	★692236	Gasket-Exhaust	697394 Rod-Push (Intake)		
750	790832	Screw (Oil Pump Cover)			914	691108	Screw (Rocker Cover)	1027	492932	Filter-Oil Used on Type No(s). 0111.
757	697607	Link-Counterweight Used on Type No(s). 0113, 0114, 0115, 0118, 0393.			918	697091	Hose-Vacuum (Molded)	1029	691751	Arm-Rocker
758	697391	Counterweight Used on Type No(s). 0113, 0114, 0115, 0118, 0393.			943	★690589	Seal-O Ring (Oil Pump Cover)	1032	491710	Ball-Oil Pump Used on Type No(s). 0111.
783	693713	Gear-Pinion			950	691657	Screw-Float Bowl (Bottom Of Bowl)			
789	695050	Harness-Wiring Used on Type No(s). 0381.								
797	693167	Nut (Brush Retainer)								

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

217800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1034	690822	Guide-Push Rod	1044	698139	Screw (Flywheel)	1263	697124	Reed-Breather
1036	790465	Label-Emissions (Used After Code Date 04063000)	1051	691265	Ring-Retaining	1264	697104	Screw (Breather Reed)
		Note	1054	280275	Tie-Cable	1266	★●691917	Seal-O Ring (Intake Elbow)
	790186	Label-Emissions (Used After Code Date 03123100 and Before Code Date 04070100).	1058	275935	Operator's Manual	1266A	★●697123	Seal-O Ring (Intake Elbow)
	697221	Label-Emissions (Used Before Code Date 04010100)	1070	690372	Screw (Flywheel Fan)	1267	697419	Latch-Blower Housing (Black)
1040	698368	Plate-Trim Used on Type No(s). 0111, 0118, 0381.	1090	691293	Retainer-Brush	1270	697156	Plug-AVS Counterweight Used on Type No(s). 0113, 0114, 0115, 0118, 0393.
			1091	691333	Cap-Limiter	1330	272147	Repair Manual
			1095	691581	Gasket Set-Valve			
			1119	691183	Screw (Alternator)			
			1127	695407	Screw (Float Bowl)(Nikki)			
			1136	690278	Screw (Control Bracket)(High Speed Control)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.