

12E100

Illustrated Parts List

Model Series

12E100

TYPE NUMBERS
0007 through 0268.

TABLE OF CONTENTS

Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	5
Exhaust System	6
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets – Carburetor	4
Kits/Gaskets – Engine	2
Kits/Gaskets – Valves	3
Lubrication	2
Piston Group	2
Rewind Starter	5

PRINTED IN U.S.A.














COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.

12E100





1019 LABEL KIT

1058 OWNER'S MANUAL










1330 REPAIR MANUAL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5958-2 Assemblies include all parts shown in frames. 07/22/2004












12E100




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5958-4 Assemblies include all parts shown in frames.

07/22/2004





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5958-5 Assemblies include all parts shown in frames. 07/22/2004

12E100



1036 EMISSION LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5958-6 Assemblies include all parts shown in frames. 07/22/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699510	Cylinder Assembly	30	692562	Dipper-Connecting Rod	117	690048	Jet-Main (Standard)
2	399269	Kit-Bushing/Seal (Magneto Side)	32	691664	Screw (Connecting Rod)	118	498977	Jet-Main (High Altitude)
3	★299819	Seal-Oil (Magneto Side)	32A	695759	Screw (Connecting Rod)	121	696998	Kit-Carburetor Overhaul
5	699486	Head-Cylinder	33	499642	Valve-Exhaust	122	●693749	Spacer-Carburetor
7	★∅698210	Gasket-Cylinder Head	34	499641	Valve-Intake	125A	790558	Carburetor
11B	695745	Tube-Breather	35	691304	Spring-Valve (Intake)	127	●694468	Plug-Welch
12	★699485	Gasket-Crankcase	36	691304	Spring-Valve (Exhaust)	127A	●691739	Plug-Welch
13	699482	Screw (Cylinder Head)	37	699661	Guard-Flywheel	130	691181	Valve-Throttle
15	691686	Plug-Oil Drain	40	692194	Retainer-Valve	133	398187	Float-Carburetor
15B	695757	Plug-Oil Drain	45	690977	Tappet-Valve	134	●398188	Kit-Needle/Seat
16	699454	Crankshaft	46	696813	Camshaft	137	●693981	Gasket-Float Bowl
18	699804	Cover-Crankcase	51	★●∅692555	Gasket-Intake (2 Required)	146	690979	Key-Timing
20	★692550	Seal-Oil (PTO Side)	55A	696710	Housing-Rewind Starter	155	698214	Plate-Cylinder Head
21	281658	Cap-Oil Fill	58	693389	Rope-Starter (Cut To Required Length)	186	692317	Connector-Hose
22	699478	Screw (Crankcase Cover/ Sump)	60B	699334	Grip-Starter Rope	187A	692601	Line-Fuel (Molded)
23	699516	Flywheel	65	699228	Screw (Rewind Starter)	187B	693401	Line-Fuel (Molded)
24	222698	Key-Flywheel	65A	699851	Screw (Rewind Starter)	188	699479	Screw (Control Bracket)
25	690021	Piston Assembly (Standard)	78	699205	Screw (Flywheel Guard)	190	699220	Screw (Fuel Tank)
		Note	95	691636	Screw (Throttle Valve)	192	694543	Ball-Rocker Arm
		694168 Piston Assembly (.020" Oversize)	97	690024	Shaft-Throttle	209	692571	Spring-Governor
26	499631	Ring Set (Standard)	98	398185	Kit-Idle Speed	219	693578	Gear-Governor
		Note	104	●691242	Pin-Float Hinge	220	691724	Washer (Governor Gear)
		692786 Ring Set (.020" Oversize)	108	695807	Valve-Choke	222D	790549	Bracket-Control
27	691866	Lock-Piston Pin	109B	695729	Shaft-Choke	227	692573	Lever-Governor Control
28	499423	Pin-Piston				238	691300	Cap-Valve
29	690124	Rod-Connecting						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5958-7

Assemblies include all parts shown in frames.

07/22/2004

12E100

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
268	691072	Control Wire Casing (Cut to Required Length)	365	699484	Screw (Carburetor)	616	692547	Crank-Governor
269	691589	Control Wire (Cut to Required Length)	383	19374	Wrench-Spark Plug	619	699230	Screw (Cylinder Head Plate)
270	691027	Nut (Control Wire Casing)	455	692591	Cup-Flywheel	632	692653	Spring/Link-Mechanical Governor
271	691028	Lever-Control	456	692299	Plate-Pawl Friction	633	◆693867	Seal-Choke/Throttle Shaft (Choke)
276	◆271716	Washer-Sealing	459	281505	Pawl-Ratchet	633A	◆◆691321	Seal-Choke/Throttle Shaft (Throttle)
281A	699639	Panel-Control	472A	790553	Knob-Choke Shaft	635A	692927	Boot-Sparkplug
287	699629	Screw (Dipstick Tube)	474	694457	Alternator	663	699854	Screw (Control Panel)
300E	790548	Muffler	493A	695744	Bracket-Mounting	689	691855	Spring-Friction
304	699598	Housing-Blower	505	691251	Nut (Governor Control Lever)	692	690572	Spring-Detent
305	699480	Screw (Blower Housing)	523	693618	Dipstick	718	690959	Pin-Locating
306A	695710	Shield-Cylinder	Note _____			731A	790554	Hood-Snow
307	699483	Screw (Cylinder Shield)	524	281370	Seal-Dipstick Tube	731B	790547	Hood-Snow
307A	699234	Screw (Cylinder Shield)	528	695746	Hose-Primer	741	695087	Gear-Timing
307B	790557	Screw (Cylinder Shield)	552	692346	Bushing-Governor Crank	742	692564	Retainer-E Ring
309A	696818	Motor-Starter	562	691119	Bolt (Governor Control Lever)	746	692566	Gear-Idler
318	690370	Screw (Mounting Bracket)	564	699854	Screw (Control Cover)	830	694544	Stud (Rocker Arm)
332	699359	Nut (Flywheel)	578A	790481	Wire Assembly	842	691031	Seal-O Ring (Dipstick Tube)
333	695711	Armature-Magneto	597	691696	Screw (Pawl Friction Plate)	847	693617	Dipstick/Tube Assembly
334	699477	Screw (Magneto Armature)	598	220624	Shim-End Play	Note _____		
337	491055	Spark-Plug	601	95162	Clamp-Hose	790545	Dipstick/Tube Assembly	
347	698338	Switch-Rocker	604A	695749	Cover-Control	Used on Type No(s). 0252, 0268.		
356C	695630	Wire-Stop	604B	790473	Cover-Control	851	493880	Terminal-Spark Plug
356L	790552	Wire-Stop	608A	699335	Starter-Rewind	868	★∅692044	Seal-Valve
358	699638	Set-Engine Gasket	613D	699209	Screw (Muffler)	883A	★691893	Gasket-Exhaust
363	19069	Puller-Flywheel	615	692576	Retainer-Governor Shaft	892	695747	Switch-Key

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5958-8

Assemblies include all parts shown in frames.

07/22/2004

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
914	699481	Screw (Rocker Cover) (Bottom)	998	696683	Pipe–Oil	1119	699772	Screw (Alternator)
914A	692557	Screw (Rocker Cover) (Top)	1005	692592	Fan–Flywheel	1196	696692	Screw (Snow Hood)
914B	697551	Screw (Rocker Cover) (Center)	1019	790459	Kit–Label	1196A	699854	Screw (Snow Hood)
930	696709	Guard–Rewind	1022	★∅691890	Gasket–Rocker Cover	1210	498144	Pulley/Spring Assembly (Pulley)
957	695737	Cap–Fuel Tank (Plastic)	1023	499924	Cover–Rocker Arm	1211	498144	Pulley/Spring Assembly (Spring)
958	698180	Valve–Fuel Shut Off (Plastic)	1026	790287	Rod–Push	1230	699847	Screw (Control Bracket)
972	695736	Tank–Fuel (Plastic)	1029	691230	Arm–Rocker	1251A	790555	Shield–Snow
975	493640	Bowl–Float	1036	790414	Label–Emission (Used After Code Date 04063000).	1251B	790556	Shield–Snow
976	790221	Primer–Carburetor	Note			1252	699234	Screw (Snow Shield)
977	697001	Gasket Set–Carburetor	790550 Label– Emission (Used Before Code Date 04070100).			1252A	699632	Screw (Snow Shield)
990	695756	Key–Set	1034	691343	Guide–Push Rod	1330	272147	Repair Manual
993	★∅694088	Gasket–Cylinder Head Plate	1054	280275	Tie–Cable			
			1058	275964	Owner’s Manual			
			1070	699201	Screw (Flywheel Fan)			
			1095	698215	Gasket Set–Valve			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.