

407600

Illustrated Parts List

Model Series

407600

TYPE NUMBERS
0101 through 0259.



TABLE OF CONTENTS

Air Cleaner	5
Alternators/Ignition	7
Blower Housing/Shrouds	5
Cam	3
Carburetor	4
Controls	6
Crankcase Cover/Sump	2
Crankshaft	2
Cylinder	2
Electric Starter	6
Flywheel	6
Head/Valves	3
Kit/Gasket Sets	4
Oil	2
Pistons	2







PRINTED IN U.S.A.





COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.





10



24



750









1019 LABEL KIT







1058 OPERATOR'S MANUAL







1330 REPAIR MANUAL

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5558-2 Assemblies include all parts shown in frames. 06/15/2003






5558-3 *Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.* Assemblies include all parts shown in frames. 06/15/2003






1036 EMISSIONS LABEL



5558-5 *Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*




Assemblies include all parts shown in frames.

06/15/2003



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5558-6 Assemblies include all parts shown in frames. 06/15/2003

DUAL CIRCUIT		10 - 16 AMP	
474B	877	474D	877C
		1059	
<p>NOTE: All Stators Use a No. 1119 Mounting Screw. </p> <p>NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.</p>		526	
		501	



407600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699751	Cylinder Assembly (Used After Code Date 03082800) ----- Note ----- 690231 Cylinder Assembly (Used Before Code Date 03082900)	20	★690947	Seal - Oil (PTO Side)	33	499596	Valve - Exhaust
2	499585	Kit - Bushing/Seal (Magneto Side)	22	694966	Screw (Crankcase Cover/Sump)	34	697464	Valve - Intake
3	★391086	Seal - Oil (Magneto Side)	23	691053	Flywheel ----- Note ----- 691054 Flywheel Used on Type No(s). 0101, 0182, 0229, 0233, 0258, 0259.	35	690963	Spring - Valve (Intake)
4	699747	Sump - Engine (Used After Code Date 03082800) ----- Note ----- 690069 Sump - Engine (Used Before Code Date 03082900)	24	222698	Key - Flywheel	36	690963	Spring - Valve (Exhaust)
5	693998	Head - Cylinder (Cylinder 1)	25	499588	Piston Assembly (Standard) ----- Note ----- 499590 Piston Assembly (.020" Oversize)	42	499586	Keeper - Valve
5A	693999	Head - Cylinder (Cylinder 2)	26	499604	Ring Set (Standard) ----- Note ----- 499606 Ring Set (.020" Oversize)	45	690977	Tappet - Valve
7	★△690962	Gasket - Cylinder Head	27	690975	Lock - Piston Pin	46	699748	Camshaft (Used After Code Date 03082800) ----- Note ----- 690978 Camshaft (Used Before Code Date 03082900)
8	499601	Breather Assembly	28	690229	Pin - Piston (Standard)	50A	695241	Manifold - Intake
9	★690937	Gasket - Breather	29	699699	Rod - Connecting (Standard) (Used After Code Date 03122700) ----- Note ----- (For Replacement Connecting Rod, See Reference 16A)	51A★●690950	690950	Gasket - Intake (Plastic)
10	691108	Screw (Breather Assembly)				53	690951	Stud (Carburetor)
11	690942	Tube - Breather				54	695240	Screw (Intake Manifold)
12	★697227	Gasket - Crankcase (Cylinder Head)				73	494439	Screen - Rotating
13	690360	Screw (Cylinder Head)				74	698425	Screw (Rotating Screen)
15A	690946	Plug - Oil Drain (3/8" Standard)				75	691056	Washer (Flywheel)
16	699700	Crankshaft (Used After Code Date 03122700)				95	690718	Screw (Throttle Valve)
16A	699701	Crankshaft (Includes Connecting Rod) (Used Before Code Date 03122800)				98	499802	Kit - Idle Speed
			32	690976	Screw (Connecting Rod)	104	●690984	Pin - Float Hinge
						105	●690985	Valve - Float Needle
						108	690986	Valve - Choke
						117	●690232	Jet - Main (Standard)
						118	●690989	Jet - Main (High Altitude)
						121	499811	Kit - Carburetor Overhaul
						122	690952	Spacer - Carburetor
						125	499804	Carburetor

★ Included in Engine Gasket Set - Ref. No. 358.

● Included in Carburetor Overhaul Kit - Ref. No. 121.

◆ Included in Carburetor Gasket Set - Ref. No. 977.

△ Included in Valve Gasket Set - Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
130	690993	Valve-Throttle	222	698761	Bracket-Control	310	691263	Screw
131	499805	Kit-Throttle Shaft			----- Note -----			(Starter Motor)
133	499806	Float-Carburetor			698757			----- Note -----
135	499803	Tube-Fuel Transfer			Bracket-Control			690323 Screw
137	◆690994	Gasket-Float Bowl			Used on Type No(s).			(Starter Motor)
141	499807	Kit-Choke Shaft			0232, 0233.	311	497608	Brush Set
142	●499808	Nozzle-Carburetor (Standard)	227	691048	Lever-Governor Control	332	691059	Nut (Flywheel)
146	690979	Key-Timing	231	690718	Screw (Choke Valve)	333	691060	Armature-Magneto
150	◆690995	Gasket-Nozzle	239	491657	Switch-Oil Pressure	334	691061	Screw (Magneto Armature)
160	690996	Retainer-Solenoid	240	691035	Filter-Fuel	337	491055	Plug-Spark
163	★△691001	Gasket-Air Cleaner	250	690957	Retainer-Breather			----- Note -----
165	693148	Nut (Ring Gear)	252	690956	Collector-Oil			691043 Plug-Spark
187	691050	Line-Fuel (Cut To Required Length)	265	691024	Clamp-Casing			Used on Type No(s).
187A	691049	Line-Fuel (Molded)	267	691044	Screw (Casing Clamp)			0182, 0201, 0229, 0232, 0233, 0258, 0259.
188	691108	Screw (Control Bracket)	268	691025	Casing-Control Wire (Cut To Required Length)	358	694012	Gasket Set-Engine
192	690083	Adjuster-Rocker Arm	269	691026	Wire-Control (Cut To Required Length)	363	19203	Puller-Flywheel
209	697674	Spring-Governor	270	691027	Nut (Control Wire Casing)	383	19374	Wrench-Spark Plug
		----- Note -----	271	691028	Lever-Control	385	691108	Screw (Fuel Pump)
		693102	276	★◆690997	Washer-Sealing	387	808656	Pump-Fuel
		Spring-Governor Used on Type No(s).	287	691108	Screw (Dipstick Tube)	404	690442	Washer (Governor Crank)
		0259.	304	695277	Housing-Blower (Black)	405A	697820	Screw (Back Plate)(Mounting)
		698071	305	691005	Screw (Blower Housing)	415	690283	Plug (Sump)
		Spring-Governor Used on Type No(s).	305A	698336	Screw (Blower Housing)	418	690999	Plate-Carburetor
		0101.			Used on Type No(s).	445	499486	Filter-Air Cleaner Cartridge
211	691019	Spring-Governed Idle			0182, 0201.	447	691003	Screw (Air Guide Cover)
212	695238	Link-Throttle	309	497595	Motor-Starter	447A	691108	Screw (Air Guide Cover)
213	691021	Bracket-Choke Control						
216	691022	Link-Choke						
219	698231	Gear-Governor						
220	690412	Washer (Governor Gear)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

407600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
474B	696459	Alternator (Dual Circuit)	628	691108	Screw (Fuel Pump Bracket)	842	★691031	Seal-O Ring (Dipstick Tube)
474D	696458	Alternator (10-16 Amp Regulated) Used on Type No(s). 0201, 0232.	633	◆690998	Seal-Choke/Throttle Shaft	847	499602	Dipstick/Tube Assembly
501	691185	Regulator (10-16 Amp Regulated) Used on Type No(s). 0201, 0232.	635	66538	Boot-Spark Plug	851	493880	Terminal-Spark Plug
505	691029	Nut (Governor Control Lever)	654	690958	Nut (Carburetor)	855	691011	Adapter-Air Cleaner
510	696541	Drive-Starter	668	691215	Spacer	865	691012	Cover-Air Guide (Cylinder 1)
513	692024	Clutch-Drive	672	◆690234	Gasket-Carburetor Plate	----- Note -----		
523	691036	Dipstick	691	★690657	Seal-Governor Shaft	691014	Cover-Air Guide (Cylinder 2)	
524	★691032	Seal-Dipstick Tube	695	693149	Screw (Ring Gear)	865B	691015	Cover-Air Guide (Valley)
525	691037	Tube-Dipstick	697	690372	Screw (Drive Cap)	868	★△690968	Seal-Valve
526	691108	Screw (Regulator)(10-16 Amp Regulated)	703	691010	Clip	877	393456	Wire/Connector- Alternator (Dual Circuit)
544	692034	Armature-Starter	710	697474	Cover-Oil Filter	877C	399916	Wire/Connector- Alternator (10 to 16 Amp Regulated)
552	690552	Bushing-Governor Crank	718	690959	Pin-Locating	883	★△690970	Gasket-Exhaust
552A	690553	Bushing-Governor Crank	726	499612	Gear-Ring	914	691127	Screw (Rocker Cover)
562	690311	Bolt (Governor Control Lever)	729	694123	Clip-Wire	918	694000	Hose-Vacuum
573	790444	Plate-Back	741	690980	Gear-Timing	929	695239	Screw (Choke Control Bracket)
578	691208	Wire Assembly	742	690328	Retainer-E Ring	943	★690589	Seal-O Ring (Oil Pump Cover)
579	691029	Nut (Starter Cable)	750	696999	Screw (Oil Pump Cover)	947	499809	Solenoid-Fuel
601	95162	Clamp-Hose	783	695708	Gear-Pinion	965	499613	Cover-Oil Pump
615	698290	Retainer-Governor Shaft	788	691039	Bracket-Fuel Pump	967	273638	Filter-Pre Cleaner
616	691045	Crank-Governor	789	691220	Harness-Wiring			
			789A	698330	Harness-Wiring (6 Pin Customer Conversion)			
			797	693167	Nut (Brush Retainer)			
			798	697890	Screw (Rocker Arm)			
			801	691283	Cap-Drive			
			802	691286	Cap-End			
			803	693757	Housing-Starter			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
968	790095	Cover-Air Cleaner	1027	492932	Filter-Oil	1126	690991	Screw
975	499810	Bowl-Float	1029	690972	Arm-Rocker			(Fuel Transfer Tube)
977	499812	Gasket Set-Carburetor	1035	691042	Shaft-Pump	1127	690992	Screw
987	◆691000	Seal-Throttle Shaft	1036	695704	Label-Emissions			(Float Bowl)
1005	499603	Fan-Flywheel	1051	691265	Ring-Retaining	1128	◆690990	Screw
1013	690954	Nipple-Oil Filter	1054	280275	Tie-Cable			(Carburetor Nozzle)
1017	690770	Screen-Oil Pump	1058	275475	Operator's Manual	1146	690718	Screw
1019	790094	Kit-Label	1070	690372	Screw			(Choke Shaft)
1022	★△690971	Gasket-Rocker Cover			(Flywheel Fan)	1169	693140	Screw
1023	499599	Cover-Rocker	1090	691293	Retainer-Brush			(Carburetor Cover Plate)
		(Cylinder 1)	1095	694013	Gasket Set-Valve	1280	697475	Seal-O Ring
1023A	499600	Cover-Rocker	1100	690973	Pivot-Rocker Arm			(Oil Filter Cover)
		(Cylinder 2)	1119	691183	Screw	1330	273521	Repair Manual
1024	499054	Pump-Oil			(Alternator)	1342	699731	Extension-Fuel
1026	690981	Rod-Push	1123	◆◆690987	Seal-O Ring			Transfer Tube
		(Steel)			(Solenoid Retainer)	1353	699725	Seal-O Ring
1026A	690982	Rod-Push	1124	◆◆690988	Seal-O Ring			(Fuel Transfer Tube Extension)
		(Aluminum)			(Fuel Transfer Tube)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.