

9K900

Illustrated Parts List

Model Series

9K900

TYPE NUMBER
0100, 0323.







TABLE OF CONTENTS

Air Cleaner	6
Blower Housing	7
Brake	9
Cams	3
Carburetor	4
Controls	5
Covers	7
Crankcase Cover/Sump	3
Crankshaft	3
Cylinder	2
Flywheel	7
Fuel Tank	4
Governor Spring	5
Head	2
Ignition	5
Kits/Gaskets – Sets	2
Muffler Group	6
Oil Group	2
Piston Group	3
Rewind/Blower Housing 1	8
Valves	3



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.






1019 LABEL KIT

1058 OWNER'S MANUAL




1330 REPAIR MANUAL











Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5806-5 Assemblies include all parts shown in frames. 05/19/2004









9K900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699650	Cylinder Assembly	33	296676	Valve—Exhaust	180	494406	Tank—Fuel (Metal)
2	399269	Kit—Bushing/Seal (Magneto Side)	34	296677	Valve—Intake	188	692198	Screw (Control Bracket)
3	★299819	Seal—Oil (Magneto Side)	35	690520	Spring—Valve (Intake)	190	691640	Screw (Fuel Tank)
4	698691	Sump—Engine	36	690520	Spring—Valve (Exhaust)	190A	692198	Screw (Fuel Tank)
5	690386	Head—Cylinder	37A	691209	Guard—Flywheel (Muffler Side)	202	698835	Link—Mechanical Governor
7	★△698717	Gasket—Cylinder Head	37B	697403	Guard—Flywheel (Carburetor Side)	209	698726	Spring—Governor (Pink)
8	699640	Breather Assembly	40	692194	Retainer—Valve	————— Note —————		
9	★△695890	Gasket—Breather	43	697799	Slinger—Governor/Oil	222B	697410	Bracket—Control
10	691666	Screw (Breather Assembly)	45	691762	Tappet—Valve	227	697402	Lever—Governor Control
11	691245	Tube—Breather	46	691998	Camshaft	236	691867	Link—Lockout
12	★692218	Gasket—Crankcase	50	699644	Manifold—Intake	265	692179	Clamp—Casing
13	691640	Screw (Cylinder Head)	51	★699649	Gasket—Intake	265A	690798	Clamp—Casing
15	691680	Plug—Oil Drain (Flush)	54	691111	Screw (Intake Manifold)	267	691044	Screw (Casing Clamp)
16	492086	Crankshaft	55	692144	Housing—Rewind Starter	268	691072	Casing—Control Wire (Cut To Required Length)
		————— Note —————	58	697316	Rope—Starter (Cut To Required Length)	269	691589	Wire—Control (Cut To Required Length)
		692990 Crankshaft Used on Type No(s). 0100.	60	691915	Grip—Starter Rope	270	691027	Nut (Control Wire Casing)
20	★391483	Seal—Oil (PTO Side)	65	690837	Screw (Rewind Starter)	271	691028	Lever—Control
22	691662	Screw (Crankcase Cover/Sump)	73A	699850	Screen—Rotating	287	691002	Screw (Dipstick Tube)
22A	691108	Screw (Crankcase Cover/Sump)	74	691627	Screw (Rotating Screen)	298	691720	Locknut—Muffler/Elbow
23	692009	Flywheel	75	691736	Washer (Flywheel)	300A	394569	Muffler (Round Lo Tone)
24	222698	Key—Flywheel	78	692198	Screw (Flywheel Guard)	303	690291	Elbow—Exhaust
25	699657	Piston Assembly	90	697800	Carburetor			
26	699658	Ring Set	97	697414	Shaft—Throttle			
27	691588	Lock—Piston Pin	106	691901	Seat—Inlet			
28	699659	Pin—Piston	130	691190	Valve—Throttle			
29	699654	Rod—Connecting	163	★271139	Gasket—Air Cleaner			
32	691664	Screw (Connecting Rod)						

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

△ Included in Valve Gasket Set—Ref. No.1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
304	698046	Housing-Blower	562	691119	Bolt (Governor Control Lever)	842	★691870	Seal-O Ring (Dipstick Tube)	
305	692198	Screw (Blower Housing)				851	493880	Terminal-Spark Plug	
332	690662	Nut (Flywheel)	592	690800	Nut (Rewind Starter)	868	697338	Seat-Valve	
333	496914	Armature-Magneto	597	691696	Screw (Pawl Friction Plate)	869	699641	Seat-Valve (Intake)	
334	691061	Screw (Magneto Armature)	608	499706	Starter-Rewind	870	699642	Seat-Valve (Exhaust)	
335	691107	Screw (Magneto Armature With Air Vane)	612	496046	Tube-Pick Up	871	699643	Bushing-Valve Guide (Exhaust Valve)	
337	802592	Plug-Spark	616	697405	Crank-Governor	Note		63709	Bushing-Valve Guide (Intake Valve)
356	692390	Wire-Stop	617	270344	Seal-O Ring (Intake Manifold)	913	494409	Seat-Check Valve	
358	699933	Gasket Set-Engine	621	692310	Switch-Stop	922	692135	Spring-Brake	
363	19069	Puller-Flywheel	633	691321	Seal-Choke/Throttle Shaft	923	691487	Brake	
365	692200	Screw (Carburetor)	635	66538	Boot-Spark Plug	925	691349	Cover-Linkage	
383	89838	Wrench-Spark Plug	668	692889	Spacer	957	497929	Cap-Fuel Tank (Plastic)	
390	691839	Spring-Choke Diaphragm	670	691633	Spacer-Fuel Tank (Compliance Engines)	976	694394	Primer-Carburetor	
393	691837	Screen-Carburetor	689	691855	Spring-Friction (Ratchet Pawl)	1019	699934	Kit-Label	
394	495770	Diaphragm-Carburetor	718	690959	Pin-Locating (Cylinder)	1036	699930	Label-Emissions	
404	690272	Washer (Governor Crank)	718A	499047	Pin-Locating (Crankshaft)	1058	275508	Operator's Manual (Emission)	
455	691236	Cup-Flywheel	724	697478	Retainer-Seal	1095	498526	Gasket Set-Valve	
456	692299	Plate-Pawl Friction	729	690586	Clip-Wire	1210	499901	Pulley/Spring Assembly (Pulley)	
459	281505	Pawl-Ratchet	741	691805	Gear-Timing	1211	499901	Pulley/Spring Assembly (Spring)	
505	691251	Nut (Governor Control Lever)	745	691146	Screw (Brake)	1218	695866	Seal-O Ring (Carburetor)	
523A	691913	Dipstick	745A	690859	Screw (Brake)	1277	698718	Guard-Governor Nut	
524	★692296	Seal-Dipstick Tube	772	691111	Screw (Linkage Cover)	1278	691002	Screw (Governor Guard Nut)	
525	691320	Tube-Dipstick	772A	690345	Screw (Linkage Cover)	1330	270962	Repair Manual	
529	692189	Grommet (Breather)							
534	691417	Screw (Air Cleaner)							
535A	698369	Filter-Air Cleaner Foam							
536A	698472	Cleaner-Air (Plastic)							

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.