

RYOBI
HAMMER DRILL
MODEL NO. D550H
REPAIR SHEET

RYOBI HAMMER DRILL – MODEL NUMBER D550H

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **HAMMER DRILL** or when ordering repair parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	6613402	* SCREW (M6 X 27 mm)	1	27	690443001	DRILL MODE INSERT	1
2	690090003	CHUCK	1	28	900722002	OIL SEAL	1
3	984723001	GEAR & SPINDLE ASSEMBLY	1	29	6341203	GUIDE ROD GAUGE	1
4	984722001	OUTPUT SPINDLE/GEAR ASSEMBLY	1	30	3018808	AUXILIARY HANDLE ASSEMBLY	1
5	6620310	* SCREW (M3 X 14 mm)	1	31	6620805	* SCREW (M4 X 16 mm)	2
6	630636001	SPRING WASHER	1	32	660208013	* SCREW (M4 X 20 mm)	9
7	690497001	WASHER	1	33	940214045	DATA PLATE	1
8	900701001	FELT WASHER	1	34	984717001	HOUSING ASSEMBLY	1
9	610305001	SPEED ADJUST GEAR	1	35	5678001	CHUCK KEY STRAP	1
10	690441001	SLIPPING RACK	1	36	6917601	CHUCK KEY	1
11	690541001	COPPER CAP	1	37	5927402	BEND RELIEF	1
12	690542001	SPRING	1	38	730202006	POWER CORD	1
13	400234001	SPEED BUTTON	1	39	984719001	SWITCH ASSEMBLY	1
14	690457001	STEEL TRACK ROD	1	40	6620801	* SCREW (M4 X 12 mm)	2
15	660290004	* SCREW (M3 X 5 mm)	1	41	6906901	CORD CLAMP	1
16	660099001	* SCREW (M2.6 X 8 mm)	1	42	984720001	BRUSH ASSEMBLY	2
17	660206018	* SCREW (M3.5 X 15 mm)	2	43	740399001	FIELD ASSEMBLY	1
18	680379001	SPRING WASHER	2	44	6899901	BEARING (607ZZ)	1
19	690942003	ARAMTURE SHAFT SUPPORT	1	45	984718001	ARMATURE ASSEMBLY (INCLUDES KEY NOS. 44 & 46)	1
20	690885001	WASHER	2	46	6906201	BEARING (608LLB)	1
21	590233001	HAMMER ADJUST LEVER	1	47	900694001	FELT SEAL	1
22	690477001	HAMMER ADJUST PLATE	1	48	590296001	MODE SELECTOR	1
23	6721901	STEEL BALL	1	49	940213032	LOGO PLATE	1
24	6703001	SPRING WASHER	2		983000-129	OPERATOR'S MANUAL	
25	660237005	* SCREW (M4 X 37 mm)	2		3-04		
26	984721001	BEARING PLATE ASSEMBLY	1				

WARNING: Improper repair of a double insulated tool can result in damage to the double insulation system possibly causing electrical shock or electrocution. Any repairs requiring disassembly of your tool requires safety testing and should only be performed by a Ryobi Authorized Service Center. For the service center nearest you call 1-800-525-2579.

* Standard Hardware Item – May Be Purchased Locally