


PARTS LIST



C1M TYPE

C1M TYPE



REF. NO.	PART NAME
1	STRAINER
2	STRAINER
3	PLUG, WELCH
4	PLUG, WELCH
5	RETAINER, SYRINGE
6	NOZZLE ASS'Y, CHECK VALVE
7	SHAFT ASSEMBLY, THROTTLE
8	LEVER, THROTTLE
9	SPRING, THROTTLE RETURN
10	VALVE, THROTTLE
11	DIAPHRAGM ASS'Y, METERING
12	DIAPHRAGM, PUMP
13	DIAPHRAGM, PUMP
14	GASKET, METERING CHAMBER
15	GASKET, PUMP
16	COVER, PUMP
17	VALVE, INLET NEEDLE
18	SPRING, METERING LEVER
19	LEVER, METERING
20	PIN
21	COVER, METERING CHAMBER
22	SPRING, ADJUST SCREW
23	SPRING, ADJUST SCREW
24	SCREW, MAIN MIXTURE
25	SCREW, IDLE MIXTURE
26	SCREW, THROTTLE ADJUST
27	PIECE, FRICTION
28	SPRING, FRICTION
29	SHAFT ASS'Y, CHOKE
30	VALVE, CHOKE
31	POST
32	COLLAR
33	PLUNGER
34	SPRING, PLUNGER RETURN
35	BASE ASSEMBLY, PRIMER
36	SYRINGE
37	SCREW (PIN)
38	SCREW (THROTTLE VALVE)
39	SCREW (CHOKE VALVE)
40	SCREW (POST)
41	SCREW (METERING COVER)
42	SCREW (PUMP COVER)
43	SCREW (THROTTLE LEVER)
44	BALL, STEEL
45	E-RING (THROTTLE SHAFT)
46	E-RING (POST)
47	O-RING (PLUNGER)
48	SCREW, RETAINER
49	E-RING (CHOKE SHAFT)
50	LIMITER, MIXTURE (H)
51	LIMITER, MIXTURE (L)
52	WASHER (LIMITER)
53	RETAINER (LIMITER)
54	SPRING, CHOKE
55	LEVER, CHOKE CONTROL
56	LEVER, CHOKE
57	COLLAR, CHOKE SHAFT
58	SCREW, CHOKE SHAFT
59	GOVERNOR ASS'Y
60	WASHER (GOVERNOR)
61	WASHER (POST)
62	REMOTE JET
63	BOOT, RETAINER
64	SHAFT ASS'Y, AIRHEAD
65	SPRING, AIRHEAD RETURN
66	VALVE, THROTTLE AIRHEAD
67	E-RING (SHAFT AIRHEAD)
68	SCREW (VALVE AIRHEAD)
69	SCREW
70	GASKET, AIRHEAD
71	ROD LINKAGE, AIRHEAD
72	LEVER, THROTTLE AIRHEAD

PARTS LIST

C1M TYPE

REF	PART NAME	C1M EL28	C1M EL28A	C1M FR1	C1M FR1A	C1M FR1B	C1M H57	C1M H58,A
	Venturi	13.5mm	13.5mm	13.5 mm	13.5 mm	13.5 mm	12.5mm	13.5 mm
★	Rebuild Kit	RB-130	RB-130	RB-70	RB-70	RB-70	RB-57	RB-57
●	Gasket & Diaphragm Kit	GND-71	GND-71	GND-43	GND-43	GND-43	GND-43	GND-43
▲	Cover Kit, Pump	K017080	K017080	K017021	K017021	K017021	K017070	K017070
■	Base Kit, Primer	-----	-----	-----	-----	-----	-----	-----
+	Body Ass'y, Airhead	A088003	A088003	-----	-----	-----	-----	-----
1	Strainer	★ 0004011	★ 0004011	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009
2	Strainer	-----	-----	-----	-----	-----	-----	-----
3	Plug, Welch	-----	★ 0005009	-----	-----	-----	-----	-----
4	Plug, Welch	★ 0005004	★ 0005004	★ 0005005	★ 0005005	★ 0005005	★ 0005005	★ 0005005
5	Retainer, Syringe	-----	-----	0009010	0009010	0009065	-----	-----
6	Nozzle Ass'y, Check Valve	A007212	A007239	A007103	A007103	A007103	A007169	A007169
7	Shaft Ass'y, Throttle	A011218	A011218	A011133	A011133	A011133	A011176	A011176
8	Lever, Throttle	0012189	0012189	0012109	0012109	0012109	0012166	0012166
9	Spring, Throttle Return	0013095	0013095	0013018	0013018	0013018	0013018	0013018
10	Valve, Throttle	0014120	0014120	0014036	0014036	0014036	0014004	0014004
11	Diaphragm Ass'y, Metering	★● A015016	★● A015016	★● A015019	★● A015019	★● A015019	★● A015016	★● A015016
12	Diaphragm, Pump	★● 0015047	★● 0015047	★● 0015047	★● 0015047	★● 0015047	★● 0015047	★● 0015047
13	Diaphragm, Pump	0015080	0015080	-----	-----	-----	-----	-----
14	Gasket, Metering Chamber	★● 0016035	★● 0016035	★● 0016021	★● 0016021	★● 0016021	★● 0016047	★● 0016021
15	Gasket, Pump	★● 0016033	★● 0016033	★● 0016047	★● 0016047	★● 0016047	★● 0016021	★● 0016047
16	Cover, Pump	▲ A017046	▲ A017046	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034
17	Valve, Inlet Needle	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004
18	Spring, Metering Lever	★ 0019011	★ 0019011	★ 0019002	★ 0019002	★ 0019002	★ 0019014	★ 0019014
19	Lever, Metering	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012
20	Pin	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001
21	Cover, Metering Chamber	0028039	0028039	-----	-----	-----	0028023	0028023
22	Spring, Adjust Screw	-----	-----	-----	-----	-----	-----	0029007
23	Spring, Adjust Screw	-----	-----	-----	-----	-----	▲ 0029007	-----
24	Screw, Main Mixture	0030199	0030199	0030140	0030140	0030140	0030174	0030174
25	Screw, Idle Mixture	0031225	0031225	0031134	0031134	0031134	0031154	0031154
26	Screw, Throttle Adjust	▲ 0035079	▲ 0035079	▲ 0035007	▲ 0035007	▲ 0035007	▲ 0035033	▲ 0035033
27	Piece, Friction	▲ 0036001	▲ 0036001	▲ 0036001	▲ 0036001	▲ 0036001	▲ 0036001	▲ 0036001
28	Spring, Friction	0038001	0038001	-----	-----	-----	0038001	0038001
29	Shaft Ass'y, Choke	A041108	A041108	A041073	A041073	A041073	A041087	A041087
30	Valve, Choke	0043010	0043010	0043028	0043028	0043028	0043027	0043018
31	Post	-----	-----	0045002	0045002	0045002	-----	-----
32	Collar	-----	-----	0052005	0052005	0052005	-----	0052011
33	Plunger	-----	-----	-----	-----	-----	-----	-----
34	Spring (Plunger Return)	-----	-----	-----	-----	-----	-----	-----
35	Base Ass'y, Primer	-----	-----	-----	-----	A056075	-----	-----
36	Syringe	-----	-----	0057004	0057004	0057004	-----	-----
37	Screw (Pin)	14803006	14803006	14803006	14803006	14803006	14803006	14803006
38	Screw (Throttle Valve)	156030045	156030045	156030045	156030045	156030045	15603004	15603004
39	Screw (Choke Valve)	-----	-----	156030045	156030045	156030045	156030045	156030045
40	Screw (Post)	-----	-----	-----	-----	-----	-----	-----
41	Screw (Metering Cover)	17203006	17203006	17103008	17103008	-----	17203006	17203006
42	Screw (Pump Cover)	17004010	17004010	17004010	17004010	17004010	17004010	17004010
43	Screw (Throttle Lever)	17103004	17103004	17103004	17103004	17103004	17103004	17103004
44	Ball, Steel	19290030	19290030	-----	-----	-----	19290030	19290030
45	E-Ring (Throttle Shaft)	19500030	19500030	19500040	19500040	19500040	19500040	19500040
46	E-Ring (Post)	-----	-----	19500040	19500040	19500040	-----	-----
47	O-Ring (Plunger)	-----	-----	-----	-----	-----	-----	-----
48	Screw, Retainer	-----	-----	17203012	17203012	17203012	-----	-----
49	E-Ring (Choke Shaft)	-----	-----	19500030	-----	-----	19500025	19500025
50	Limit, Mixture (H)	0061060	0061060	0061009	0061009	0061009	0061025	0061058
51	Limit, Mixture (L)	0061059	0061059	0061010	0061010	0061010	0061026	0061026
52	Washer (Limit)	0026014	0026014	-----	-----	-----	0026014	0026014
53	Retainer (Limit)	0009031	0009031	-----	-----	-----	0009028	0009028
54	Spring, Choke	0013096	0013096	0013065	0013065	0013065	0013065	0013065
55	Lever, Choke Control	A042027	A042027	0042022	0042022	0042022	-----	0042098
56	Lever, Choke	0042111	0042152	0042055	0042055	0042055	0042098	0042103
57	Collar, Choke Shaft	-----	-----	-----	0052010	0052010	0052011	-----
58	Screw, Choke Shaft	-----	-----	-----	-----	17103004	-----	-----
59	Governor Ass'y	-----	-----	-----	-----	-----	-----	-----
60	Washer (Governor)	-----	-----	-----	-----	-----	-----	-----
61	Washer (Post)	-----	-----	-----	-----	-----	-----	-----
62	Remote Jet	-----	-----	-----	-----	-----	-----	-----
63	Boot, Retainer	0051027	0051027	-----	-----	-----	0051027	0051027
64	Shaft Ass'y, Airhead	+ A011219	+ A011240	-----	-----	-----	-----	-----
65	Spring, Airhead Return	+ 0013097	+ 0013097	-----	-----	-----	-----	-----
66	Valve, Throttle Airhead	+ 0014098	+ 0014098	-----	-----	-----	-----	-----
67	E-Ring (Shaft Airhead)	+ 19500040	+ 19500040	-----	-----	-----	-----	-----
68	Screw (Valve Airhead)	+ 156030045	+ 156030045	-----	-----	-----	-----	-----
69	Screw	14902509	14902509	-----	-----	-----	-----	-----
70	Gasket Airhead	0016090	0016090	-----	-----	-----	-----	-----
71	Rod Linkage, Air Head	0063025	0063027	-----	-----	-----	-----	-----
72	Lever, Throttle for Airhead	0012199	0012199	-----	-----	-----	-----	-----

PARTS LIST

C1M TYPE

REF	PART NAME	C1M H58B	C1M H58C	C1M K24	C1M K24A	C1M K24B	C1M K25A	C1M K25B
	Venturi	13.5 mm	13.5 mm	9.5 mm	9.5 mm	9.5 mm	13.5 mm	13.5 mm
★	Rebuild Kit	RB-57	RB-127	RB-44	RB-44	RB-44	RB-44	RB-44
●	Gasket & Diaphragm Kit	★ GND-43	★ GND-43	★ GND-31	★ GND-31	★ GND-31	★ GND-31	★ GND-31
▲	Cover Kit, Pump	K017070	K017070	K017021	K017021	K017064	K017021	K017064
■	Base Kit, Primer	-----	-----	-----	-----	-----	-----	-----
⊕	Body Ass'y, Airhead	-----	-----	-----	-----	-----	-----	-----
1	Strainer	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009
2	Strainer	-----	-----	-----	-----	-----	-----	-----
3	Plug, Welch	-----	-----	-----	-----	-----	-----	-----
4	Plug, Welch	★ 0005005	★ 0005005	★ 0005005	★ 0005005	★ 0005005	★ 0005005	★ 0005005
5	Retainer, Syringe	-----	-----	0009010	0009027	0009027	0009027	0009027
6	Nozzle Ass'y, Check Valve	A007169	A007169	A007045	A007045	A007045	A007045	A007045
7	Shaft Ass'y, Throttle	A011176	A011176	A011073	A011073	A011073	A011073	A011073
8	Lever, Throttle	0012166	0012166	0012023	0012023	0012023	0012023	0012023
9	Spring, Throttle Return	0013018	0013018	0013036	0013036	0013036	0013036	0013036
10	Valve, Throttle	0014004	0014036	0014004	0014004	0014004	0014004	0014004
11	Diaphragm Ass'y, Metering	★● A015016	★● A015016	★● A015016	★● A015016	★● A015016	★● A015016	★● A015016
12	Diaphragm, Pump	★● 0015047	★● 0015047	★● 0015044	★● 0015044	★● 0015047	★● 0015044	★● 0015047
13	Diaphragm, Pump	-----	-----	-----	-----	-----	-----	-----
14	Gasket, Metering Chamber	★● 0016021	★● 0016021	★● 0016021	★● 0016021	★● 0016021	★● 0016021	★● 0016021
15	Gasket, Pump	★● 0016047	★● 0016047	★● 0016033	★● 0016033	★● 0016033	★● 0016033	★● 0016033
16	Cover, Pump	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034
17	Valve, Inlet Needle	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004
18	Spring, Metering Lever	★ 0019014	★ 0019002	★ 0019002	★ 0019002	★ 0019002	★ 0019002	★ 0019002
19	Lever, Metering	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012
20	Pin	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001
21	Cover, Metering Chamber	0028023	0028023	-----	-----	-----	-----	-----
22	Spring, Adjust Screw	0029007	0029007	0029005	0029005	▲ 0029032	0029005	0029005
23	Spring, Adjust Screw	-----	-----	-----	-----	-----	-----	▲ 0029032
24	Screw, Main Mixture	0030174	0030174	0030051	0030051	0030051	0030054	0030054
25	Screw, Idle Mixture	0031154	0031154	0031053	0031053	0031053	0031054	0031054
26	Screw, Throttle Adjust	▲ 0035033	▲ 0035033	▲ 0035007	▲ 0035007	▲ 0035033	▲ 0035007	▲ 0035033
27	Piece, Friction	▲ 0036001	▲ 0036001	▲ 0036001	▲ 0036001	-----	▲ 0036001	-----
28	Spring, Friction	0038001	0038001	-----	-----	-----	-----	-----
29	Shaft Ass'y, Choke	A041087	A041087	-----	-----	-----	-----	-----
30	Valve, Choke	0043058	0043058	-----	-----	-----	-----	-----
31	Post	-----	-----	-----	-----	-----	-----	-----
32	Collar	0052011	0052011	-----	-----	-----	-----	-----
33	Plunger	-----	-----	-----	-----	-----	-----	-----
34	Spring (Plunger Return)	-----	-----	-----	-----	-----	-----	-----
35	Base Ass'y, Primer	-----	-----	A056014	A056014	A056014	A056014	A056014
36	Syringe	-----	-----	0057003	0057003	0057004	0057003	0057004
37	Screw (Pin)	14803006	14803006	14803006	14803006	14803006	14803006	14803006
38	Screw (Throttle Valve)	15603004	156030045	15603004	15603004	15603004	15603004	15603004
39	Screw (Choke Valve)	156030045	156030045	-----	-----	-----	-----	-----
40	Screw (Post)	-----	-----	-----	-----	-----	-----	-----
41	Screw (Metering Cover)	17203006	17203006	17103008	17103008	17103008	17103008	17103008
42	Screw (Pump Cover)	17004010	17004010	17004010	17004010	17004010	17004010	17004010
43	Screw (Throttle Lever)	17103004	17103004	17103004	17103004	17103004	17103004	17103004
44	Ball, Steel	19290030	19290030	-----	-----	-----	-----	-----
45	E-Ring (Throttle Shaft)	19500040	19500040	19500040	19500040	19500040	19500040	19500040
46	E-Ring (Post)	-----	-----	-----	-----	-----	-----	-----
47	O-Ring (Plunger)	-----	-----	-----	-----	-----	-----	-----
48	Screw, Retainer	-----	-----	17203012	17203012	17203012	17203012	17203012
49	E-Ring (Choke Shaft)	19500025	19500025	-----	-----	-----	-----	-----
50	Limit, Mixture (H)	0061058	0061058	-----	-----	-----	-----	-----
51	Limit, Mixture (L)	0061026	0061026	-----	-----	-----	-----	-----
52	Washer (Limit)	0026014	0026014	-----	-----	-----	-----	-----
53	Retainer (Limit)	0009028	0009028	-----	-----	-----	-----	-----
54	Spring, Choke	0013065	0013065	-----	-----	-----	-----	-----
55	Lever, Choke Control	0042098	0042098	-----	-----	-----	-----	-----
56	Lever, Choke	0042103	0042103	-----	-----	-----	-----	-----
57	Collar, Choke Shaft	-----	-----	-----	-----	-----	-----	-----
58	Screw, Choke Shaft	-----	-----	-----	-----	-----	-----	-----
59	Governor Ass'y	-----	-----	-----	-----	-----	-----	-----
60	Washer (Governor)	-----	-----	-----	-----	-----	-----	-----
61	Washer (Post)	-----	-----	-----	-----	-----	-----	-----
62	Remote Jet	-----	-----	-----	-----	-----	-----	-----
63	Boot, Retainer	0051027	0051027	-----	-----	-----	-----	-----
64	Shaft Ass'y, Airhead	-----	-----	-----	-----	-----	-----	-----
65	Spring, Airhead Return	-----	-----	-----	-----	-----	-----	-----
66	Valve, Throttle Airhead	-----	-----	-----	-----	-----	-----	-----
67	E-Ring (Shaft Airhead)	-----	-----	-----	-----	-----	-----	-----
68	Screw (Valve Airhead)	-----	-----	-----	-----	-----	-----	-----
69	Screw	-----	-----	-----	-----	-----	-----	-----
70	Gasket Airhead	-----	-----	-----	-----	-----	-----	-----
71	Rod Linkage, Air Head	-----	-----	-----	-----	-----	-----	-----
72	Lever, Throttle for Airhead	-----	-----	-----	-----	-----	-----	-----

PARTS LIST

C1M TYPE

REF	PART NAME	C1M K37A	C1M K37B-D	C1M K49	C1M K49A	C1M K49B,C	C1M K76	C1M K77
	Venturi	9.5 mm	9.5 mm	12.5 mm	12.5 mm	12.5mm	12.5mm	9.5mm
★	Rebuild Kit	RB-61	RB-61	RB-44	RB-44	RB-44	RB-44	RB-124
●	Gasket & Diaphragm Kit	GND-31	GND-31	GND-31	GND-31	GND-31	GND-31	GND-67
▲	Cover Kit, Pump	K017021	K017064	K017021	K017064	K017064	K017064	K017064
■	Base Kit, Primer	-----	-----	-----	-----	-----	-----	-----
+	Body Ass'y, Airhead	-----	-----	-----	-----	-----	-----	-----
1	Strainer	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009	★ 0004009
2	Strainer	-----	-----	-----	-----	-----	-----	-----
3	Plug, Welch	-----	-----	-----	-----	-----	-----	-----
4	Plug, Welch	★ 0005004	★ 0005004	★ 0005005	★ 0005005	★ 0005005	★ 0005005	★ 0005005
5	Retainer, Syringe	0009027	0009065	0009027	0009027	0009027	0009065	0009065
6	Nozzle Ass'y, Check Valve	A007187	A007187	A007077	A007077	A007077	-----	-----
7	Shaft Ass'y, Throttle	A011073	A011073	A011073	A011073	A011073	A011073	A011208
8	Lever, Throttle	0012023	0012023	0012023	0012023	0012023	0012023	0012023
9	Spring, Throttle Return	0013036	0013036	0013036	0013036	0013036	0013036	0013036
10	Valve, Throttle	0014038	0014038	0014004	0014004	0014004	0014004	0014004
11	Diaphragm Ass'y, Metering	★● A015016	★● A015016	★● A015016	★● A015016	★● A015016	★● A015016	★● A015050
12	Diaphragm, Pump	★● 0015044	★● 0015047	★● 0015044	★● 0015047	★● 0015047	★● 0015047	★● 0015047
13	Diaphragm, Pump	-----	-----	-----	-----	-----	-----	-----
14	Gasket, Metering Chamber	★● 0016021	★● 0016021	★● 0016021	★● 0016021	★● 0016021	★● 0016021	★● 0016077
15	Gasket, Pump	★● 0016033	★● 0016033	★● 0016033	★● 0016033	★● 0016033	★● 0016033	★● 0016033
16	Cover, Pump	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034	▲ 0017034
17	Valve, Inlet Needle	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004	★ 0018004
18	Spring, Metering Lever	★ 0019005	★ 0019005	★ 0019002	★ 0019002	★ 0019002	★ 0019002	★ 0019002
19	Lever, Metering	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012	★ 0020012
20	Pin	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001	★ 0021001
21	Cover, Metering Chamber	-----	-----	-----	-----	-----	-----	-----
22	Spring, Adjust Screw	0029005	0029032	0029005	0029005	-----	-----	-----
23	Spring, Adjust Screw	-----	▲ 0029032	-----	▲ 0029032	▲ 0029032	▲ 0029032	▲ 0029032
24	Screw, Main Mixture	0030083	0030170	0030103	0030103	0030169	0030212	0030216
25	Screw, Idle Mixture	A031082	0031169	0031101	0031101	0031168	0031158	0031168
26	Screw, Throttle Adjust	▲ 0035007	▲ 0035033	▲ 0035007	▲ 0035033	▲ 0035033	▲ 0035033	▲ 0035033
27	Piece, Friction	▲ 0036001	-----	▲ 0036001	-----	-----	-----	-----
28	Spring, Friction	-----	-----	-----	-----	-----	-----	-----
29	Shaft Ass'y, Choke	-----	-----	-----	-----	-----	-----	-----
30	Valve, Choke	-----	-----	-----	-----	-----	-----	-----
31	Post	-----	-----	-----	-----	-----	-----	-----
32	Collar	-----	-----	-----	-----	-----	-----	-----
33	Plunger	-----	-----	-----	-----	-----	-----	-----
34	Spring (Plunger Return)	-----	-----	-----	-----	-----	-----	-----
35	Base Ass'y, Primer	A056014	A056067	A056014	A056014	A056014	A056067	A056067
36	Syringe	0057003	0057004	0057004	0057004	0057004	0057004	0057004
37	Screw (Pin)	14803006	14803006	14803006	14803006	14803006	14803006	14803006
38	Screw (Throttle Valve)	156030045	156030045	15603004	15603004	15603004	15603004	15603004
39	Screw (Choke Valve)	-----	-----	-----	-----	-----	-----	-----
40	Screw (Post)	-----	-----	-----	-----	-----	-----	-----
41	Screw (Metering Cover)	17103008	17103008	17103008	17103008	17103008	-----	-----
42	Screw (Pump Cover)	17004010	17004010	17004010	17004010	17004010	17004010	17004010
43	Screw (Throttle Lever)	17103004	17103004	17103004	17103004	17103004	17103004	17103004
44	Ball, Steel	-----	-----	-----	-----	-----	-----	-----
45	E-Ring (Throttle Shaft)	19500040	19500040	19500040	19500040	19500040	19500040	19500040
46	E-Ring (Post)	-----	-----	-----	-----	-----	-----	-----
47	O-Ring (Plunger)	-----	-----	-----	-----	-----	-----	-----
48	Screw, Retainer	17203012	17203012	17203012	17203012	17203012	17203012	17203012
49	E-Ring (Choke Shaft)	-----	-----	-----	-----	-----	-----	-----
50	Limiter, Mixture (H)	0061007	0061007	0061009	0061009	-----	0061009	0061009
51	Limiter, Mixture (L)	0061010	0061010	0061010	0061010	-----	0061010	0061010
52	Washer (Limiter)	0026006	0026014	-----	-----	-----	-----	-----
53	Retainer (Limiter)	-----	-----	-----	-----	-----	-----	-----
54	Spring, Choke	-----	-----	-----	-----	-----	-----	-----
55	Lever, Choke Control	-----	-----	-----	-----	-----	-----	-----
56	Lever, Choke	-----	-----	-----	-----	-----	-----	-----
57	Collar, Choke Shaft	-----	-----	-----	-----	-----	-----	-----
58	Screw, Choke Shaft	-----	-----	-----	-----	-----	-----	-----
59	Governor Ass'y	-----	-----	-----	-----	-----	-----	-----
60	Washer (Governor)	-----	-----	-----	-----	-----	-----	-----
61	Washer (Post)	-----	-----	-----	-----	-----	-----	-----
62	Remote Jet	-----	-----	-----	-----	-----	-----	-----
63	Boot, Retainer	-----	-----	-----	-----	-----	-----	-----
64	Shaft Ass'y, Airhead	-----	-----	-----	-----	-----	-----	-----
65	Spring, Airhead Return	-----	-----	-----	-----	-----	-----	-----
66	Valve, Throttle Airhead	-----	-----	-----	-----	-----	-----	-----
67	E-Ring (Shaft Airhead)	-----	-----	-----	-----	-----	-----	-----
68	Screw (Valve Airhead)	-----	-----	-----	-----	-----	-----	-----
69	Screw	-----	-----	-----	-----	-----	-----	-----
70	Gasket Airhead	-----	-----	-----	-----	-----	-----	-----
71	Rod Linkage, Air Head	-----	-----	-----	-----	-----	-----	-----
72	Lever, Throttle for Airhead	-----	-----	-----	-----	-----	-----	-----

PARTS LIST

C1M TYPE

REF	PART NAME		C1M W26		C1M W26A														
	Venturi		8.0mm		8.0mm														
★	Rebuild Kit		RB-129		RB-129														
●	Gasket & Diaphragm Kit	★	GND-70	★	GND-70														
▲	Cover Kit, Pump		K017079		K017079														
■	Base Kit, Primer		-----		K056041														
+	Body Ass'y, Airhead		A088002		A088002														
1	Strainer	★	0004035	★	0004035														
2	Strainer		-----		0004002														
3	Plug, Welch		-----		-----														
4	Plug, Welch	★	0005004	★	0005004														
5	Retainer, Syringe		-----		-----														
6	Nozzle Ass'y, Check Valve		A007210		A007238														
7	Shaft Ass'y, Throttle		A011216		A011234														
8	Lever, Throttle		A012031		A012031														
9	Spring, Throttle Return		0013018		0013018														
10	Valve, Throttle		0014118		0014118														
11	Diaphragm Ass'y, Metering	★●	A015019	★●	A015019														
12	Diaphragm, Pump	★●	0015047	★●	0015047														
13	Diaphragm, Pump		-----		-----														
14	Gasket, Metering Chamber	★●	0016035	★●	0016035														
15	Gasket, Pump	★●	0016047	★●	0016047														
16	Cover, Pump	▲	0017091	▲	0017091														
17	Valve, Inlet Needle	★	0018004	★	0018004														
18	Spring, Metering Lever	★	0019012	★	0019012														
19	Lever, Metering	★	0020012	★	0020012														
20	Pin	★	0021001	★	0021001														
21	Cover, Metering Chamber		0028023		0028049														
22	Spring, Adjust Screw		-----		-----														
23	Spring, Adjust Screw	▲	0029033	▲	0029033														
24	Screw, Main Mixture		0030197		0030197														
25	Screw, Idle Mixture		0031223		0031223														
26	Screw, Throttle Adjust	▲	0035033	▲	0035033														
27	Piece, Friction	▲	0036001	▲	0036001														
28	Spring, Friction		0038001		0038001														
29	Shaft Ass'y, Choke		A041107		A041107														
30	Valve, Choke		0043007		0043007														
31	Post		-----		-----														
32	Collar		-----		-----														
33	Plunger		-----		0053047														
34	Spring (Plunger Return)		-----		0054065														
35	Base Ass'y, Primer		-----		-----														
36	Syringe		-----		-----														
37	Screw (Pin)		14803006		14803006														
38	Screw (Throttle Valve)		156030045		156030045														
39	Screw (Choke Valve)		156030045		156030045														
40	Screw (Post)		-----		-----														
41	Screw (Metering Cover)		17203006		17203006														
42	Screw (Pump Cover)		17004010		17004010														
43	Screw (Throttle Lever)		17103004		17103004														
44	Ball, Steel		19290030		19290030														
45	E-Ring (Throttle Shaft)		19500040		19500040														
46	E-Ring (Post)		-----		-----														
47	O-Ring (Plunger)		-----		195503010														
48	Screw, Retainer		-----		-----														
49	E-Ring (Choke Shaft)		-----		-----														
50	Limitter, Mixture (H)		-----		-----														
51	Limitter, Mixture (L)		-----		-----														
52	Washer (Limitter)		-----		-----														
53	Retainer (Limitter)		-----		-----														
54	Spring, Choke		0013071		0013071														
55	Lever, Choke Control		0042130		0042130														
56	Lever, Choke		0042128		0042128														
57	Collar, Choke Shaft		-----		-----														
58	Screw, Choke Shaft		-----		-----														
59	Governor Ass'y		-----		-----														
60	Washer (Governor)		-----		-----														
61	Washer (Post)		-----		-----														
62	Remote Jet		-----		-----														
63	Boot, Retainer		-----		-----														
64	Shaft Ass'y, Airhead	+	A011217	+	A011217														
65	Spring, Airhead Return	+	0013109	+	0013109														
66	Valve, Throttle Airhead	+	0014041	+	0014041														
67	E-Ring (Shaft Airhead)	+	19500030	+	19500030														
68	Screw (Valve Airhead)	+	156030045	+	156030045														
69	Screw		14902509		14902509														
70	Gasket Airhead		0016090		0016090														
71	Rod Linkage, Air Head		-----		-----														
72	Lever, Throttle for Airhead		-----		-----														