


PARTS LIST



G1L TYPE

G1L TYPE



REF.NO.	PART NAME
1	STRAINER
2	STRAINER
3	NOZZLE ASS'Y
4	SHAFT ASS'Y, THROTTLE
5	LEVER, THROTTLE
6	SPRING, THROTTLE RETURN
7	VALVE, THROTTLE
8	DIAPHRAGM ASS'Y, METERING
9	DIAPHRAGM, PUMP
10	GASKET, METERING CHAMBER
11	GASKET, PUMP
12	COVER, PUMP
13	VALVE, INLET NEEDLE
14	SPRING, METERING LEVER
15	LEVER, METERING
16	PIN
17	COVER, METERING CHAMBER
18	SPRING, ADJUST SCREW
19	SCREW, MAIN MIXTURE
20	SCREW, THROTTLE ADJUST
21	PIECE FRICTION
22	SPRING, FRICTION
23	SHAFT ASS'Y, CHOKE
24	VALVE, CHOKE
25	COLLAR
26	PLUNGER
27	SPRING (RETURN)
28	SCREW (PIN)
29	SCREW (THROTTLE VALVE)
30	SCREW (CHOKE VALVE)
31	SCREW (METERING COVER)
32	SCREW, PUMP COVER
33	SCREW (THROTTLE LEVER)
34	BALL, STEEL
35	O-RING (PLUNGER)
36	SCREW, RETAINER
37	E-RING
38	LIMITER, MIXTURE (H)
39	LIMITER, MIXTURE (L)
40	WASHER (LIMITER)
41	RETAINER (LIMITER)
42	SPRING, CHOKE
43	LEVER, CHOKE
44	SCREW, CHOKE SHAFT
45	BOOT, RETAINER
46	RETAINER, SPRING
47	PLUNGER KIT, CONTROL
48	LEVER, THROTTLE RAMP
49	SPRING

