


PARTS LIST



LA/LB/LE TYPE



LA/LB TYPE


REF.NO.	PART NAME
1	STRAINER
2	PLUG, WELCH
3	NOZZLE ASSEMBLY, CHECK VALVE
4	SHAFT ASSEMBLY , THROTTLE
5	LEVER ASSEMBLY, THROTTLE
6	SPRING, THROTTLE RETURN
7	VALVE, THROTTLE
8	DIAPHRAGM ASSEMBLY, METERING
9	DIAPHRAGM, PUMP
10	GASKET, PUMP
11	GASKET, METERING CHAMBER
12	GASKET, STRAINER
13	COVER,PUMP
14	VALVE, INLET NEEDLE
15	SPRING, METERING LEVER
16	LEVER, METERING
17	PIN
18	BODY, PUMP
19	SPRING, ADJUST SCREW
20	SPRING, ADJUST SCREW
21	WASHER (L.H. NEEDLE)
22	O-RING (L.H. NEEDLE)
23	SCREW, MAIN MIXTURE
24	SCREW, IDLE MIXTURE
25	SCREW, THROTTLE ADJUST
26	SPRING, FRICTION
27	SHAFT ASSEMBLY, CHOKE
28	VALVE, CHOKE
29	SCREW, (PIN)
30	SCREW (THROTTLE VALVE)
31	SCREW (CHOKE VALVE)
32	SCREW (PUMP COVER)
33	SCREW (THROTTLE, CHOKE LEVER)
34	SCREW
35	SCREW (PLASTIC COVER)
36	BALL, STEEL
37	RETAINER, SHAFT
38	COVER, PLASTIC
39	SEAT, INLET
40	WASHER (SEAT)
41	GOVERNOR ASSEMBLY
42	WASHER (GOVERNOR)
43	HOLDER, WIRE

PARTS LIST

LA/LB TYPE

REF	PART NAME	LA S6, A	LA S7, A	LA S8, A	LB S9									
	Venturi	16 mm	16 mm	16 mm	20.6 mm									
★	Rebuild Kit	RB-42	RB-42	RB-42	RB-42									
●	Gasket & Diaphragm Kit	GND-30	GND-30	GND-30	GND-30									
1	Strainer	★ 0004010	★ 0004010	★ 0004010	★ 0004010									
2	Plug, Welch	★ 0005008	★ 0005008	★ 0005008	★ 0005008									
3	Nozzle Ass'y, Check Valve	A007013	A007013	A007036	A007011									
4	Shaft Ass'y, Throttle	A011045	A011045	A011045	A011058									
5	Lever Ass'y, Throttle	A012001	A012002	A012001	-----									
6	Spring, Throttle Return	0013023	0013023	0013023	0013023									
7	Valve, Throttle	0014023	0014023	0014023	0014028									
8	Diaphragm Ass'y, Metering	★● A015015	★● A015015	★● A015015	★● A015015									
9	Diaphragm, Pump	★● 0015041	★● 0015041	★● 0015041	★● 0015041									
10	Gasket, Pump	★● 0016037	★● 0016037	★● 0016037	★● 0016037									
11	Gasket, Metering Chamber	★● 0016041	★● 0016041	★● 0016041	★● 0016041									
12	Gasket, Strainer	0016031	0016031	0016031	0016031									
13	Cover, Pump	0017024	0017024	0017075	0017049									
14	Valve, Inlet Needle	★ 0018002	★ 0018002	★ 0018002	★ 0018002									
15	Spring, Metering Lever	★ 0019013	★ 0019013	★ 0019013	★ 0019013									
16	Lever, Metering	★ 0020011	★ 0020011	★ 0020011	★ 0020011									
17	Pin	★ 0021007	★ 0021007	★ 0021007	★ 0021007									
18	Body, Pump	0049002	0049002	0049002	0049003									
19	Spring, Adjust Screw	0029005	0029005	0029005	0029005									
20	Spring, Adjust Screw	0029004	0029004	0029004	0029004									
21	Washer (L.H. Needle)	0026005	0026005	0026005	0026005									
22	O-Ring (L.H. Needle)	195503515	195503515	195503515	195503515									
23	Screw, Main Mixture	0030055	0030055	0030055	0030038									
24	Screw, Idle Mixture	0031031	0031031	0031031	0031031									
25	Screw, Throttle Adjust	0035017	0035017	0035017	0035017									
26	Spring, Friction	-----	0038002	-----	-----									
27	Shaft Ass'y, Choke	0041015	0041015	0041015	A041020									
28	Valve, Choke	0043014	0043014	0043014	0043017									
29	Screw (Pin)	14803006	14803006	14803006	14803006									
30	Screw (Throttle Valve)	156030055	156030055	156030055	156030055									
31	Screw (Choke Valve)	156030055	156030055	156030055	156030055									
32	Screw (Pump Cover)	17103519	17103519	17103519	16303520									
33	Screw (Throttle, Choke Lever)	17103004	17103004	17103004	17103004									
34	Screw	16304008	16304008	16304008	16304008									
35	Screw (Plastic Cover)	0058001	0058001	0058001	0058001									
36	Ball, Steel	-----	19290040	-----	-----									
37	Retainer, Shaft	0009017	0009017	0009017	0009017									
38	Cover, Plastic	0017023	0017023	0017023	0017023									
39	Seat, Inlet	0002025	0002025	0002025	0002025									
40	Washer (Seat)	0026003	0026003	0026003	0026003									
41	Governor Ass'y	A059001	A059002	-----	-----									
42	Washer (Governor)	0026003	0026003	-----	-----									
43	Holder, Wire	-----	0060001	-----	-----									

LE TYPE



REF. NO.	PART NAME
1	STRAINER
2	STRAINER
3	STRAINER
4	STRAINER (SCREEN PICK-UP)
5	PLUG,WELCH
6	PLUG,WELCH
7	RETAINER,SYRINGE
8	NOZZLE ASSY, CHECK VALVE
9	SHAFT ASS'Y, THROTTLE
10	LEVER, THROTTLE
11	SPRING, THROTTLE RETURN
12	SPRING, CHOKE RETURN
13	VALVE, THROTTLE
14	DIAPHRAGM ASS'Y, METERING
15	DIAPHRAGM , PUMP
16	DIAPHRAGM, START PUMP
17	DIAPHRAGM, SURGE
18	GASKET, METERING CHAMBER
19	GASKET, PUMP
20	GASKET, START PUMP
21	COVER, PUMP
22	START PUMP BODY KIT
23	VALVE, INLET NEEDLE
24	SPRING, METERING LEVER
25	LEVER, METERING
26	PIN
27	COVER, METERING CHAMBER
28	SPRING, ADJUST SCREW
29	SPRING, ADJUST SCREW
30	SCREW, MAIN MIXTURE
31	SCREW, IDLE MIXTURE
32	SCREW, THROTTLE ADJUST
33	PIECE, FRICTION
34	SPRING, FRICTION
35	SHAFT ASS'Y, CHOKE
36	VALVE, CHOKE
37	LEVER, CHOKE
38	POST
39	COLLAR
40	PLUNGER
41	SPRING (PLUNGER RETURN)
42	BASE ASS'Y, PRIMER
43	SYRINGE
44	SCREW (PIN)
45	SCREW (THROTTLE VALVE)
46	SCREW (CHOKE VALVE)
47	SCREW (POST)
48	SCREW (METERING COVER)
49	SCREW (PUMP COVER)
50	SCREW (THROTTLE LEVER)
51	SCREW (RETAINER)
52	BALL, STEEL
53	E-RING (THROTTLE SHAFT)
54	E-RING (POST)
55	E-RING (CHOKE)
56	O-RING (PLUNGER)
57	LIMITER, MIXTURE (H)
58	LIMITER, MIXTURE (L)
59	WASHER (LIMITER)
60	RETAINER (LIMITER)
61	BOOT

PARTS LIST

LE TYPE

REF	PART NAME	LE H53	LE H54, A	LE H55	LE H56				
	Venturi	9 mm	9 mm	9 mm	9 mm				
★	Rebuild Kit	RB-86	RB-86	RB-94	RB-94				
●	Gasket & Diaphragm Kit	★ GND-18	★ GND-49	★ GND-12	★ GND-12				
▲	Cover Kit, Pump	-----	-----	K017037	-----				
■	Base Kit, Primer	K056029	-----	-----	-----				
+	Start Pump Kit	-----	K049002	-----	-----				
1	Strainer	★ 0004004	★ 0004004	★ 0004004	★ 0004004				
2	Strainer	-----	-----	-----	-----				
3	Strainer	-----	-----	-----	-----				
4	Strainer (Screen Pick-up)	0004034	0004034	-----	-----				
5	Plug, Welch	★ 0005004	★ 0005004	★ 0005004	★ 0005004				
6	Plug, Welch	0005039	0005039	-----	-----				
7	Retainer, Syringe	0009015	0009015	0009065	0009065				
8	Nozzle Ass'y, Check Valve	-----	-----	-----	-----				
9	Shaft Ass'y, Throttle	K011023	K011025	K011024	K011026				
10	Lever, Throttle	-----	0012154	A012028	-----				
11	Spring, Throttle Return	0013035	0013035	0013035	0013075				
12	Spring, Choke Return	-----	0013068	-----	-----				
13	Valve, Throttle	0014049	0014049	0014088	0014094				
14	Diaphragm Ass'y, Metering	★● A015010	★● A015010	★● A015011	★● A015011				
15	Diaphragm, Pump	★● 0015051	★● 0015059	★● 0015051	★● 0015051				
16	Diaphragm, Start Pump	-----	★● 0015060	-----	-----				
17	Diaphragm, Surge	-----	-----	-----	-----				
18	Gasket, Metering Chamber	★● 0016019	★● 0016019	★● 0016021	★● 0016021				
19	Gasket, Pump	★● 0016046	★● 0016049	★● 0016046	★● 0016046				
20	Gasket, Start Pump	-----	★● 0016050	-----	-----				
21	Cover, Pump	-----	-----	▲ 0017046	0017079				
22	Start Pump Body Ass'y	-----	+	-----	-----				
23	Valve, Inlet Needle	★ 0018004	★ 0018004	★ 0018004	★ 0018004				
24	Spring, Metering Lever	★ 0019006	★ 0019006	★ 0019014	★ 0019014				
25	Lever, Metering	★ 0020012	★ 0020012	★ 0020012	★ 0020012				
26	Pin	★ 0021001	★ 0021001	★ 0021001	★ 0021001				
27	Cover, Metering Chamber	0028022	0028022	-----	-----				
28	Spring, Adjust Screw	-----	-----	-----	-----				
29	Spring, Adjust Screw	-----	-----	-----	-----				
30	Screw, Main Mixture	0030179	0030179	0030179	0030179				
31	Screw, Idle Mixture	0031180	0031180	0031175	0031175				
32	Screw, Throttle Adjust	■ 0035033	+	▲ 0035033	-----				
33	Piece, Friction	■ 0036001	+	▲ 0036001	-----				
34	Spring, Friction	0038001	-----	0038001	0038001				
35	Shaft Ass'y, Choke	0041095	A041085	0041096	0041096				
36	Valve, Choke	0043015	-----	0043015	0043015				
37	Lever, Choke	0042090	0042089	0042084	0042084				
38	Post	-----	-----	-----	0045003				
39	Collar	-----	0052006	0052006	-----				
40	Plunger	-----	-----	-----	-----				
41	Spring (Plunger Return)	-----	-----	-----	-----				
42	Base Ass'y, Primer	■ A056050	A056058	A056074	A056074				
43	Syringe	0057004	0057004	0057004	0057004				
44	Screw (Pin)	14903006	14903006	14903006	14903006				
45	Screw (Throttle Valve)	15603004	15603004	15603004	15603004				
46	Screw (Choke Valve)	156030045	-----	156030045	156030045				
47	Screw (Post)	-----	-----	-----	16103005				
48	Screw (Metering Cover)	17203006	17203006	-----	-----				
49	Screw (Pump Cover)	-----	-----	17104010	17104010				
50	Screw (Throttle Lever)	-----	17103004	17103004	-----				
51	Screw (Retainer)	17104015	17104023	17203012	17203012				
52	Ball, Steel	19290030	-----	19290030	19290030				
53	E-Ring (Throttle Shaft)	19500030	-----	-----	19500030				
54	E-Ring (Post)	-----	-----	-----	19500020				
55	E-Ring (Choke Shaft)	-----	19500030	-----	-----				
56	O-Ring (Plunger)	-----	-----	-----	-----				
57	Limiter, Mixture (H)	0061025	0061025	0061025	0061025				
58	Limiter, Mixture (L)	0061026	0061026	0061026	0061026				
59	Washer (Limiter)	0026014	0026014	0026014	0026014				
60	Retainer (Limiter)	0009028	0009028	0009028	0009028				
61	Boot	0051027	0051027	0051027	0051027				