MODEL: 66A
5 HP GEAR DRIVE ROTARY TILLER
w/REVERSE



PARTS LIST

Ref. No.	Part No.	Description
1	46-36	Knob – Throttle
2	20-282	Screw – Hex Hd.
3	4-185AS	Handle Bar Assembly
4	5-5	Grip – Handle
5	8-86	Control – Throttle
6	19-118	Nut – Hex
7	19-1	Nut – Hex
8	18-41	Bolt – Hex Hd.
9	20-280	Screw – Round Hd.
10	46-40	Knob – Plain
11	108-69	Lever – Engagement
12	46-41	Knob – Threaded
13	79-159	Arm – Wheel Adjusting
14	20-131	Screw – Hex Hd.
15	2-222AS	Gear Housing Assembly
16	17-131	Clip – Cable
17	41-206AS	Panel Assembly
18	28-20	Roll Pin
19	21-62	Washer – Flat
20	35-17	Stud – Control
21	21-33	Washer – Flat
22	28-111	Clevis Pin
23	19-139	Nut – Lock
24	76-104	Spring – Comp. Short
25	26-24	Spacer – Tubing
26	76-105	Spring – Comp. Long
27	21-113	Washer – Curved
28	18-44	Bolt – Hex Hd.
29	136-11	Drag Bar
30	105-87AS	Idler Pulley Assembly
31	19-111	Nut – Lock
32	26-76	Spacer – Idler Arm
33	20-46	Bolt – Hex Hd.
34	18-49	Bolt – Hex Hd.
35	82-184	Rod – Engagement Lever
36	28-7	Cotter – Hairpin
37	7-370AS	Drag Bracket Assembly
38	28-6	Pin – Clevis
39	18-88	Screw
40	79-110	Arm – Forward Idler
41	76-96	Spring – Extension
42	22-105	Plate – Idler Arm
43	28-16	Cotter Pin
44	26-103	Spacer – Idler Arm
45	79-151	Arm – Reverse Idler
46	19-117	Nut – Eslock
47	84-50AS	Tine Assembly – Outer L.H.
48	19-24	Nut – Hex
49	76-123	Spring
50	7-350	Bracket – Handle R.H.
51	7-349	Bracket – Handle L.H.
52	134-14	Link – Connecting
53	16-9	Woodruff Key
54	105-97	Pulley – Reverse
55	20-255	Set Screw – Pulley
56	16-7	Key – Square
57	105-61	Pulley – Forward
58	107-37	Belt – "V"
59	84-54AS	Tine Assembly – Inner L.H.
60	20-145	Bolt – Hex Hd.
61	10-123AS	Housing Cover Assembly
62	122-73	Belt Guide
63	98-70	Retainer – Belt
64	18-60	Bolt – Shoulder
65	79-202	Arm – Pivot
66	105-94AS	Pulley Assembly – Gear Box
67	18-43	Bolt – Hex Hd.
68	68-26	Hood – Tine
69	43-372AS	Main Support Assembly
70	19-119	Nut – Hex
71	122-44	Belt Guard
72	3-165	Wheel Assembly
73	21-159	Washer – Flat
74	65-65AS	Axle Assembly
75	20-45	Bolt – Shoulder
76	28-26	Cotter Pin
77	20-156	Bolt – Thread Forming
78	74-14	Seal – Oil
79	11-17	Bearing – Sleeve
80	16-39	Key
81	20-157	Bolt – Hex Hd.
82	11-18	Bearing – Needle
83	74-15	Seal – Oil
84	59-15	Shield – Bearing
85	89-51AS	Hub Assembly – Inner
86	84-8	Tine – Bolo L.H.
87	84-9	Tine – Bolo R.H.
88	84-48AS	Tine Assembly – Inner R.H.
89	89-50AS	Hub Assembly – Outer
90	84-49AS	Tine Assembly – Outer R.H.
91	20-67	Bolt – Hex Hd.
92	28-113	Pin – Roll
93	28-88	Pin – Roll
94	101-86	Worm
95	26-81	Spacer – Center Worm
96	11-94	Bearing – Ball
97	26-120	Spacer – End Worm
98	98-49	Retaining Ring
99	10-122	Plate – End Cover
100	102-141	Shaft – Worm
101	114-5	Plug – Gear Box
102	2-196	Housing – Gear
103	98-7	Retaining Ring
104	102-148	Shaft – Output
105	101-90	Gear – Bronze
106	98-6	"O" Ring
107	10-121	Cover – Gear Housing

OPTIONAL ACCESSORIES

108	23-54	Furrowing Kit
109	84-47	Tine Extension Kit
	129-8	Worm Gear Oil – 8 oz.