
For Your Safety:
Read all instructions carefully

### MS1250 OWNER'S MANUAL



# 12 INCH COMPOUND MITER SAW

# Call Us 1st

For any questions about:

- Operation
- Warranty (See back cover)
- Technical Assistance
- Repair Parts

at: 1-800-4 RIDGID

M-F 7:30 a.m. – 5:30 p.m. Sat. 8 a.m. – 3 p.m.(CST),


Or online at: www.ridgidwoodworking.com

> www.ridgidparts.com (parts only)

Part No. SP6287 Printed in Taiwan

# Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

RIDGID parts are available on-line at www.ridgidparts.com



# Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

### RIDGID parts are available on-line at www.ridgidparts.com Figure 1

#### Always order by part number - not by key number

| Key<br>No. | Part No.  | Description                     |  |
|------------|-----------|---------------------------------|--|
| 1          | 828102    | Fence Sliding                   |  |
| 2          | 141594-17 | Screw Soc Cap 5/16-18 x 1       |  |
| 3          | 821063-6  | *Washer 8 x 16 x 1.2            |  |
| 4          | 827439    | Knob Fence                      |  |
| 5          | 820244-6  | *Screw Pan Hd M6 x 1.0 x 18     |  |
| 6          | 828103    | Fence Stationary                |  |
| 7          | 816755-10 | *Screw Pan Hd. M5 x 0.8-8       |  |
| 8          | 826886    | Plate Throat                    |  |
| 9          | 828104    | Table                           |  |
| 10         | 827434    | Shaft Bevel Pivot               |  |
| 11         | 827438    | Indicator Bevel                 |  |
| 12         | 826882    | Stop Bevel Index                |  |
| 13         | 9421621   | *Screw Soc Cap 5/16-18 x 5/8    |  |
| 14         | 827449    | Screw Soc Set Lock M8 x 1.25-16 |  |
| 15         | 823331    | Shoe Left                       |  |
| 16         | 827879    | Plate Guard                     |  |
| 17         | 827886    | Screw Sems M5-10                |  |
| 18         | 823361    | Shoe Base Rear                  |  |
| 19         | 828105    | Base                            |  |
| 20         | 828116    | Washer Spring 16.3 x 25 x 0.4   |  |
| 21         | 60047     | Washer .630 x 1 x 1/32          |  |
| 22         | 823355    | Bolt Table Pivot                |  |


| Key<br>No. | Part No. | Description                  |
|------------|----------|------------------------------|
| 23         | 828106   | Arm Miter                    |
| 24         | 140785-6 | *Lockwasher Int. Tooth 5/16" |
| 25         | 9421622  | *Screw Soc Cap 5/16-18 x 3/4 |
| 26         | 828040-1 | Screw Set Lock M6 x 1.0-16   |
| 27         | 828032   | Knob Miter                   |
| 28         | 827886-1 | Screw Sems M5-5              |
| 29         | 828031   | Plate Clamp Miter            |
| 30         | 823356   | Shoe Base Front              |
| 31         | 828128   | Grip Miter Index             |
| 32         | 828029   | Spring Miter Index           |
| 33         | 821063-6 | *Washer 8 x 16 x 1.2         |
| 34         | 823335   | Grommet Wrench               |
| 35         | 823332   | Shoe Right                   |
| 36         | 826885   | Indicator Miter              |
| 37         | 823492   | Wrench Hex "L" 1/4           |
| 38         | 828109   | Table Extension              |
| 39         | 828048   | Clamp                        |
| 40         | 828119-1 | Screw Sems M5-12             |
| 41         | SP6287   | Owners Manual                |
| _          | 828050   | Bag Asm Ext. Hardware        |
|            |          | (Not Illustrated)            |
|            |          |                              |

<sup>\*</sup> Standard Hardware Item - May be purchased locally.

# Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

RIDGID parts are available on-line at www.ridgidparts.com

#### **Figure 2 Upper and Lower Guards**



# Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

RIDGID parts are available on-line at www.ridgidparts.com
Figure 2 Upper and Lower Guards ‡

Always order by part number - Not by key number

| Key |          |                                 |
|-----|----------|---------------------------------|
| No. | Part No. | Description                     |
| 1   | 823351   | Screw Arbor                     |
| 2 3 | 816720   | Washer Blade                    |
|     | 823348   | Collar Blade                    |
| 4   | 828042   | Blade                           |
| 5   | 827464   | Screw Sems M5 -35               |
| 6   | 821878   | Screw Shoulder 10-32 x 7/8"     |
| 7   | 827498   | Sleeve Rubber                   |
| 8   | 827512   | Lock Arbor                      |
| 9   | 827516   | Cap Grip                        |
| 10  | 823402   | •Spring                         |
| 11  | 828101-1 | Arm Guard Upper                 |
| 12  | 823353   | Plate Retainer Arbor Lock       |
| 13  | 823404   | Screw Flat Hd M5 x 0.8-6        |
|     | 823359   | Grommet Arbor Lock              |
| 15  | 828045   | Bag Dust                        |
| 16  | 828038   | Elbow                           |
| 17  | 828040-1 | Screw Soc. Set Lock M6 x 1.0-16 |
| 18  | 827543   | Chute Sawdust                   |
| 19  | 828119   | Screw Sems M5-25                |
| 20  | 816755-6 | * Screw Pan Hd M5 x 0.8-16      |
| 21  | 823360   | Bumper Lower Guard              |
|     |          |                                 |

| Key<br>No. | Part No.  | Description                 |
|------------|-----------|-----------------------------|
| 22         | 820238-2  | * Washer 6.5 x 11.8 x 1.6   |
| 23         | 821862    | Bearing                     |
| 24         | 821875-1  | Screw Shoulder M6-14        |
| 25         | 817449-1  | Nut Hex Lock M6 x 1.0       |
| 26         | 820238-5  | * Washer 6.5 x 13 x 0.8     |
| 27         | 823340-1  | Link Actuator               |
| 28         | 820725-01 | Spacer 7 x 10 x 4           |
| 29         | 820732-2  | Washer 5.5 x 16 x 0.8       |
| 30         | 826879    | Retainer Guard              |
| 31         | 826878    | Guard Lower                 |
| 32         | 816677    | Spring Guard                |
| 33         | 821873    | Screw Shoulder 10-32x.50    |
| 34         | 826876    | Pivot Lower Guard           |
| 35         | 817449-1  | Nut Hex Lock M6 x 1.0       |
| 36         | 809372-3  | * Screw Pan Hd 10-32 x 1/2  |
| 37         | 827409    | Retainer Bearing            |
| 38         | 828142    | * Screw Flat Hd M6 x 1.0-13 |
| 39         | 820732-1  | * Washer 7.5 x 16 x 0.6     |
| 40         | 820724-01 | Screw Shoulder M5 x 0.8-16  |
| 41         | 828141    | Washer 1/4 x 16 x 1         |

<sup>\*</sup> Standard Hardware Item - May Be Purchased Locally.

**‡ CAUTION: See Mechanical Assembly Caution below.** 


• WARNING: Uncontrolled spring release of misinstallation of these parts may create a Hazard unless repair is done by a qualified service technician.

CAUTION: Mechanical Assembly, to qualified service technician.

- 1. Wear approved eye protection when working with coil springs including spring, arbor lock 823402.
- 2. Incorrect re-assembly of torsion spring 828066 can cause an unsafe condition because cutting head fails to rise fully to stop, or because spring fails through over-stress.
- 3. Improper reassembly of mechanisms controlling movement of lower guard 826878 can cause an unsafe condition because guard fails to operate freely as cutting head is moved up and down.

# Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

RIDGID parts are available on-line at www.ridgidparts.com
Figure 3 - Handle and Motor Assembly



### Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

RIDGID parts are available on-line at www.ridgidparts.com
Figure 3 - Handle and Motor Assembly

#### Always order by Part Number - Not by Key Number

| Key<br>No. | Part No. | Description                   |
|------------|----------|-------------------------------|
| 1          | 828123   | Screw Pan Hd Ty E M5-30       |
| 2          | 828063   | Handle Carry                  |
| 3          | 820376-5 | *Screw Pan Hd Ty TT M4x0.7-20 |
| 4          | 828122   | Screw Pan Hd Ty E M4-14       |
| 5          | 828062   | Handle Upper                  |
| 6          | 828059   | Actuator Switch               |
| 7          | 816725   | Clamp Cord                    |
| 8          | 821122-1 | Guard Cord                    |
| 9          | 828057   | Cord w/Plug                   |
| 10         | 828056   | Handle Lower                  |
| 11         | 828125   | Motor                         |
| 12         | 816768   | Brush                         |
| 13         | 816770   | Cover Brush                   |
|            |          |                               |

| Key<br>No | Part No. | Description                  |
|-----------|----------|------------------------------|
| 14        | 828064   | Cover Rear Motor             |
| 15        | 816781   | Bearing Needle               |
| 16        | 828133   | Spindle Asm                  |
| 17        | 823271   | Retainer Bearing             |
| 18        | 828124   | *Screw Sems M5 x 0.8-15      |
| 19        | 820376-4 | Screw Pan Hd Ty TT M4x0.7-10 |
| 20        | 813303-4 | *Lockwasher M4               |
| 21        | 821102   | *Washer 4 x 9 x 0.8          |
| 22        | 828060   | Button Lock                  |
| 23        | 828061   | Spring Torsion               |
| 24        | 823493   | Switch                       |
| 25        | 828122-1 | Screw Pan Hd Ty E M4-10      |
| 26        | 803709-1 | *Connector Wire #12–#18      |


<sup>\*</sup> Standard hardware item - May be purchased locally.

WARNING: For your safety, this miter saw is specially insulated. To reduce the risk of electrical shock, fire or injury, use only parts identical to those identified in the parts list. Reassemble exactly as originally assembled.

<sup>•</sup> WARNING: Any attempt to repair or replace electrical parts on this unit may create a hazard unless repair is done by a qualified service technician.

# Parts List For RIDGID 12" Compound Miter Saw Model No. MS12501

RIDGID parts are available on-line at www.ridgidparts.com
Figure 4 - Pivot Assembly



Always order by Part Number - Not by Key Number

| Key<br>No. | Part No. | Description               |
|------------|----------|---------------------------|
| 1          | 828066   | ‡Spring Torsion           |
| 2          | 823320   | Spacer Torsion Spring     |
| 3          | 823344   | Shaft Arm Pivot           |
| 4          | 828034   | Cap Rubber                |
| 5          | 821421-2 | Ring "O"                  |
| 6          | 828035   | Pin Locking               |
| 7          | 828107-1 | Pivot                     |
| 8          | 828120   | Screw Set Lock M4 x 0.7-5 |
| 9          | 821063-1 | *Washer 8 x 16 x 0.5      |
| 10         | 828117   | Washer 12.5 x 22 x 2      |

| Key<br>No. | Part No. | Description                   |
|------------|----------|-------------------------------|
| 11         | 819179   | Washer Spring 12.7 x 22 x 0.3 |
| 12         | 818656   | Nut Lock M12 x 1.75           |
| 13         | 827488   | Knob Bevel                    |
| 14         | 821875-4 | Screw Shoulder M6 x 23        |
| 15         | 823742-2 | Ball 5mm                      |
| 16         | 828039   | Spring                        |
| 17         | 828040   | Screw Set Lock M6 x 1.0-10    |
| 18         | 828041-1 | Pin Bevel Index               |
| 19         | 828170   | * Washer 10 x 20 x 2          |
|            |          |                               |


<sup>\*</sup> Standard hardware item - May be purchased locally.

‡ CAUTION: See mechanical assembly caution on page 31.

<sup>■</sup> To remove this item use a 3mm hex "L" wrench.

<sup>☐</sup>To remove this item use a 2mm hex "L" wrench.


### Wiring Diagram



### Trouble Shooting of Brake by Qualified Service Person Only

- 1. Check commutation at no load. If there is a heavy sparking which follows the curvature of the commutator: replace the armature.
- 2. To continue trouble shooting, now unplug the power cord.
- Install service brushes, especially if delayed come-in of brake has been noticed before failure.
- 4. Check brake circuit for continuity: remove brush caps and brushes. Use ohmmeter to check continuity from brass brush holder to brush holder. If open, locate exact place using ohmmeter. As indicated by test, tighten connection or replace field assembly or replace switch.
- 5. After repair, check direction of blade rotation vs. guard arrow.

#### Motor Parts List for RIDGID 12 Inch Miter Saw Model No. MS12500 and MS12501



When ordering repair parts, always give the following Information as shown in this list:

- 1. The part number
  - e par chumper
- 2. The part name

- 3. The model number
- 4. The name of item

#### Always order by part number - Not by key number

#### Motor Assembly 828125

| Key<br>No. | Part No.  | Description            |
|------------|-----------|------------------------|
| 1          | 828055    | Field/Housing Asm.     |
| 2          | 828054    | Protector Cork         |
| 3          | 817394    | Retainer Bearing       |
| 4          | 820722-10 | Bearing Ball           |
| 5          | 628053    | Armature Asm.          |
| 6          | 823339    | Retainer Plate Bearing |

| Key<br>No. | Part No. | Description      |
|------------|----------|------------------|
| 7          | 816741   | Bearing 6002ZZ   |
| 8          | 828108   | Housing Gear     |
| 9          | 828118   | Screw Sems M4-20 |
| 10         | 816768   | Brush            |
| 11         | 816770   | Cover Brush      |
| 12         | 828119   | Screw Sems M5-25 |